


# Installation

## Residential/Commercial Generator Sets



Models:

**12RESM1**

**12RESL**

Controller:

DC 2200 Digital Control

**KOHLER**<sup>®</sup>  
POWER SYSTEMS

**ISO 9001**  
**KOHLER**  
POWER SYSTEMS  
NATIONALLY REGISTERED

TP-6397 4/07c



# Table of Contents

---

<b>Safety Precautions and Instructions</b> .....	<b>5</b>
<b>Introduction</b> .....	<b>9</b>
<b>Service Assistance</b> .....	<b>10</b>
<b>Section 1 Specifications</b> .....	<b>11</b>
1.1 Specifications .....	11
1.2 Components .....	11
<b>Section 2 Installation</b> .....	<b>13</b>
2.1 General .....	13
2.2 Lifting .....	13
2.3 Generator Set Inspection .....	13
2.4 Location and Mounting .....	13
2.4.1 Standard Mounting .....	13
2.4.2 High-Wind Enclosure Mounting .....	13
2.4.3 Exhaust Requirements .....	17
2.4.4 Air Requirements .....	17
2.5 Fuel System .....	17
2.5.1 Fuel Supply .....	17
2.5.2 Fuel Conversion .....	18
2.6 Electrical Connections .....	20
2.6.1 Generator Set Connections .....	20
2.6.2 Power Supply .....	21
2.6.3 Grounding .....	21
2.6.4 Battery .....	21
2.6.5 Battery Charger .....	23
2.7 Transfer Switch Connections .....	23
2.8 Carburetor Heater .....	24
2.9 Prestart Installation Check .....	25
2.10 Warranty Registration .....	25
<b>Section 3 Wiring Diagrams</b> .....	<b>27</b>
3.1 Specification Numbers .....	27
3.2 Controller Wiring Diagram Reference .....	27
<b>Appendix B Abbreviations</b> .....	<b>31</b>
<b>Appendix C Common Hardware Application Guidelines</b> .....	<b>33</b>
<b>Appendix D General Torque Specifications</b> .....	<b>34</b>

# Notes

# Safety Precautions and Instructions

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. **SAVE THESE INSTRUCTIONS.**

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.

## DANGER

Danger indicates the presence of a hazard that **will cause severe personal injury, death, or substantial property damage.**

## WARNING

Warning indicates the presence of a hazard that **can cause severe personal injury, death, or substantial property damage.**

## CAUTION

Caution indicates the presence of a hazard that **will or can cause minor personal injury or property damage.**


## NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

## Accidental Starting

### WARNING



**Accidental starting.  
Can cause severe injury or death.**

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

**Disabling the generator set. Accidental starting can cause severe injury or death.** Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

## Battery

### WARNING



**Sulfuric acid in batteries.  
Can cause severe injury or death.**

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

### WARNING



**Explosion.  
Can cause severe injury or death.  
Relays in the battery charger  
cause arcs or sparks.**

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.


**Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death.** Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

**Battery acid cleanup. Battery acid can cause severe injury or death.** Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

**Battery gases. Explosion can cause severe injury or death.** Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

**Battery short circuits. Explosion can cause severe injury or death.** Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

## Engine Backfire/Flash Fire


<b>⚠ WARNING</b>

<p><b>Fire.</b> <b>Can cause severe injury or death.</b></p> <p>Do not smoke or permit flames or sparks near fuels or the fuel system.</p>

**Servicing the air cleaner. A sudden backfire can cause severe injury or death.** Do not operate the generator set with the air cleaner removed.

**Servicing the fuel system. A flash fire can cause severe injury or death.** Do not smoke or permit flames or sparks near the carburetor, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Catch fuels in an approved container when removing the fuel line or carburetor.

**Combustible materials. A fire can cause severe injury or death.** Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or BC for electrical fires or as recommended by the local fire code or an authorized agency. Train all personnel on fire extinguisher operation and fire prevention procedures.

## Exhaust System

<b>⚠ WARNING</b>

<p><b>Carbon monoxide.</b> <b>Can cause severe nausea, fainting, or death.</b></p> <p>The exhaust system must be leakproof and routinely inspected.</p>


**Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death.** Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

**Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death.** Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea

If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

## Fuel System

<b>⚠ WARNING</b>

<p><b>Explosive fuel vapors.</b> <b>Can cause severe injury or death.</b></p> <p>Use extreme care when handling, storing, and using fuels.</p>

**The fuel system. Explosive fuel vapors can cause severe injury or death.** Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

**Gas fuel leaks. Explosive fuel vapors can cause severe injury or death.** Fuel leakage can cause an explosion. Check the LP vapor gas or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces per square inch (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

## Hazardous Noise

### ⚠ CAUTION



**Hazardous noise. Can cause hearing loss.**

Never operate the generator set without a muffler or with a faulty exhaust system.

**Engine noise. Hazardous noise can cause hearing loss.** Generator sets not equipped with sound enclosures can produce noise levels greater than 105 dBA. Prolonged exposure to noise levels greater than 85 dBA can cause permanent hearing loss. Wear hearing protection when near an operating generator set.

## Hazardous Voltage/ Moving Parts

### ⚠ DANGER



**Hazardous voltage. Will cause severe injury or death.**

Disconnect all power sources before opening the enclosure.

### ⚠ WARNING



**Hazardous voltage. Moving parts. Can cause severe injury or death.**

Operate the generator set only when all guards and electrical enclosures are in place.

### ⚠ WARNING



**Hazardous voltage. Backfeed to the utility system can cause property damage, severe injury, or death.**

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

### ⚠ CAUTION



**Welding the generator set. Can cause severe electrical equipment damage.**

Never weld components of the generator set without first disconnecting the battery, controller wiring harness, and engine electronic control module (ECM).

**Grounding electrical equipment. Hazardous voltage can cause severe injury or death.** Electrocutation is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

**Welding on the generator set. Can cause severe electrical equipment damage.** Before welding on the generator set perform the following steps: (1) Remove the battery cables, negative (-) lead first. (2) Disconnect all engine electronic control module (ECM) connectors. (3) Disconnect all generator set controller and voltage regulator circuit board connectors. (4) Disconnect the engine battery-charging alternator connections. (5) Attach the weld ground connection close to the weld location.

**Installing the battery charger. Hazardous voltage can cause severe injury or death.** An ungrounded battery charger may cause electrical shock. Connect the battery charger enclosure to the ground of a permanent wiring system. As an alternative, install an equipment grounding conductor with circuit conductors and connect it to the equipment grounding terminal or the lead on the battery charger. Install the battery charger as prescribed in the equipment manual. Install the battery charger in compliance with local codes and ordinances.

**Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death.** Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

**Short circuits. Hazardous voltage/current can cause severe injury or death.** Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

**Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death.** Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.

**⚠ WARNING**



**Airborne particles. Can cause severe injury or blindness.**

Wear protective goggles and clothing when using power tools, hand tools, or compressed air.

**Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death.** Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

## Heavy Equipment

**⚠ WARNING**



**Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.**

Do not use lifting eyes.  
Lift the generator set using lifting bars inserted through the lifting holes on the skid.

## Hot Parts

**⚠ WARNING**



**Hot engine and exhaust system. Can cause severe injury or death.**

Do not work on the generator set until it cools.

**Servicing the alternator. Hot parts can cause severe injury or death.** Avoid touching the alternator field or exciter armature. When shorted, the alternator field and exciter armature become hot enough to cause severe burns.

**Servicing the exhaust system. Hot parts can cause severe injury or death.** Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

**Servicing the engine heater. Hot parts can cause minor personal injury or property damage.** Install the heater before connecting it to power. Operating the heater before installation can cause burns and component damage. Disconnect power to the heater and allow it to cool before servicing the heater or nearby parts.

## Notice

**NOTICE**

**Canadian installations only.** For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code, Part 1.



This manual provides installation instructions for model 12RESM1 and 12RESL generator sets equipped with the Kohler® DC 2200 Digital Control. Refer to TPS-6398, Operation Manual, for generator set operating instructions.

The generator set is approved for use in stationary applications in locations served by a reliable utility power source.

Have an authorized distributor/dealer install the generator set outdoors according to the instructions in this manual. The generator set installation must comply with the National Electrical Code (NEC) and local code requirements. Do not install this generator set indoors.

Information in this publication represents data available at the time of print. The manufacturer of Spectrum® products Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual.

## List of Related Literature

Figure 1 identifies related literature available for the generator sets covered in this manual. Only trained and qualified personnel should install or service the generator set.

Literature Type	Part Number
Specification Sheet	G4-110
Installation Manual	TP-6397
Operation Manual	TP-6398
Parts Catalog*	TP-6399
Service Manual	TP-6196
* Includes the generator and engine information.	

**Figure 1** Generator Set Literature

# Service Assistance

---

For professional advice on generator set power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KohlerPower.com.
- Look at the labels and stickers on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

## **Headquarters Europe, Middle East, Africa (EMEA)**

Kohler Power Systems  
3 rue de Brennus  
93200 Saint Denis  
France  
Phone: (33) 1 49 178300  
Fax: (33) 1 49 178301

## **Asia Pacific**

Power Systems Asia Pacific Regional Office  
Singapore, Republic of Singapore  
Phone: (65) 6264-6422  
Fax: (65) 6264-6455

## **China**

North China Regional Office, Beijing  
Phone: (86) 10 6518 7950  
(86) 10 6518 7951  
(86) 10 6518 7952  
Fax: (86) 10 6518 7955

East China Regional Office, Shanghai  
Phone: (86) 21 6288 0500  
Fax: (86) 21 6288 0550

## **India, Bangladesh, Sri Lanka**

India Regional Office  
Bangalore, India  
Phone: (91) 80 3366208  
(91) 80 3366231  
Fax: (91) 80 3315972

## **Japan, Korea**

North Asia Regional Office  
Tokyo, Japan  
Phone: (813) 3440-4515  
Fax: (813) 3440-2727

## **Latin America**

Latin America Regional Office  
Lakeland, Florida, USA  
Phone: (863) 619-7568  
Fax: (863) 701-7131


# Section 1 Specifications

## 1.1 Specifications

Refer to the generator set specification sheet for engine and alternator specifications and generator set application data. See List of Related Materials for the spec sheet part number.

## 1.2 Components

See Figure 1-1 for generator set component locations.



**Figure 1-1** Generator Set Component Locations


# Notes

### 2.1 General

Have an authorized distributor/dealer install the generator set outdoors according to the instructions in this manual. The generator set installation must comply with the National Electrical Code (NEC) and local code requirements. Do not install this generator set indoors.

Use the specifications provided here only in the initial planning. Use the generator set and transfer switch spec sheets, dimension drawings, and wiring diagrams for installation.

### 2.2 Lifting



The generator set weighs approximately 180 kg (400 lb.). Use lifting bars inserted through the holes in the skid to lift the unit. See Figure 2-1 for lifting hole locations.

### 2.3 Generator Set Inspection

Complete a thorough inspection of the generator set. Check for the following:

- Inspect the generator set for loose or damaged parts or wires. Repair or tighten any loose parts before installation.
- Check the engine oil. Fill, if necessary, with the recommended viscosity and grade of oil. Use synthetic oil, API (American Petroleum Institute) Service Class SG or higher. See TP-6398, Operation Manual, for additional information.

### 2.4 Location and Mounting

See Figure 2-1 for the generator set dimensions and fuel and electric inlet locations. The drawing dimensions are shown in millimeters, with inches in brackets. The wiring kit is shown as packaged for shipping.

Locate the generator set outdoors. See Figure 2-2 for the minimum clearance around the generator set. Select a location where the generator set exhaust does not blow on plants or other combustible materials. Do not install the generator set where exhaust gas could accumulate and seep inside or be drawn into a potentially occupied building.

#### 2.4.1 Standard Mounting

The generator set is shipped on a plastic mounting pad. Prepare a flat, level mounting area covered with a weed barrier and gravel as shown in Figure 2-2. Set the plastic mounting pad directly on the gravel. Do not install the mounting pad directly on grass.

#### 2.4.2 High-Wind Enclosure Mounting

See Figure 2-3 for mounting details for the optional high-wind enclosure.





Figure 2-1 Generator Set Mounting Details and Dimensions, ADV-7023A-D



**Figure 2-2** Generator Set Clearances, ADV-7023B-C





Figure 2-3 High Wind Enclosure and Mounting, ADV-7023C-D



### 2.4.3 Exhaust Requirements

<b>⚠ WARNING</b>

<b>Carbon monoxide. Can cause severe nausea, fainting, or death.</b>
The exhaust system must be leakproof and routinely inspected.

**Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death.** Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

The exhaust system is complete for generator sets installed outdoors. Do not install this generator set indoors.


Figure 2-4 gives the exhaust flow and temperature at rated load. The engine exhaust mixes with the generator set cooling air at the exhaust end of the enclosure. Mount the generator set so that the hot exhaust does not blow on plants or other combustible materials. Maintain the clearances shown in Figure 2-2.

Exhaust System	
Exhaust flow at rated kW, m <sup>3</sup> /min. (cfm)	3.8 (135)
Engine exhaust temperature at rated kW, dry exhaust, °C (°F)	816 (1500)
Exhaust gas exiting the enclosure at rated kW, °C (°F)	316 (600)

**Figure 2-4** Exhaust Flow and Temperature

### 2.4.4 Air Requirements

The generator set requires correct air flow for cooling and combustion. The inlet and outlet openings in the sound enclosure provide the cooling and combustion air. Figure 2-5 shows the locations of the cooling air intake and exhaust vents. Inspect the air inlet and outlet openings inside and outside the housing to ensure that the air flow is not blocked.



**Figure 2-5** Cooling Air Intake and Exhaust

Cooling Air Requirements	
Cooling air, m <sup>3</sup> /min. (cfm)	26.9 (950)
Total inlet air requirement, m <sup>3</sup> /min. (cfm)	28.0 (990)
Combustion air, m <sup>3</sup> /min. (cfm)	1.1 (39.2)

**Figure 2-6** Cooling Air Requirements

## 2.5 Fuel System

The generator set operates using natural gas or LP vapor fuel. The generator set is CARB- and EPA-certified for both natural gas and LP vapor fuels.

The fuel system installation must comply with all applicable state and local codes.

### 2.5.1 Fuel Supply

Because of variable climates and geographical considerations, contact the local fuel supplier for fuel system planning and installation. Figure 2-7 lists the recommended fuel ratings for natural gas and LP vapor fuels.

Fuel System	
Fuel types	Natural Gas or LP Vapor
Fuel supply inlet	1/2 NPT
Fuel supply pressure, kPa (in. H <sub>2</sub> O):	
Natural gas	1.2-2.7 (5-11)
LP	1.7-2.7 (7-11)
Gas flow rate, Btu/hr.	193,000
Nominal Fuel Rating, Btu/ft <sup>3</sup>	
Natural gas	1000
LP vapor	2500

**Figure 2-7** Fuel Supply

Verify that the output pressure from the primary gas utility (or LP tank) pressure regulator is within the fuel supply pressure range shown in Figure 2-7 and that the utility gas meter flow rate is sufficient to supply the generator set plus all other gas-consuming appliances. Figure 2-7 shows the flow rate required for the generator set and Figure 2-8 shows the fuel consumption. Contact the fuel supplier for flow rate information or a gas meter upgrade.

Fuel Consumption at % rated load			
Natural Gas		m <sup>3</sup> /hr. (cfh)	
100%		5.4	(193)
75%		4.7	(163)
50%		3.5	(124)
25%		2.6	(93)
LP Vapor		m <sup>3</sup> /hr. (cfh)	kg/hr. (lb./hr.)
100%		2.3 (81)	4.3 (9.4)
75%		2.1 (75)	3.9 (8.7)
50%		1.8 (60)	3.4 (7.0)
25%		1.2 (45)	2.2 (5.2)

**Figure 2-8** Fuel Consumption


Ensure that the natural gas pipe size and length meet the specifications in Figure 2-9. Measure the pipe length from the primary gas pressure regulator to the pipe connection on the generator set fuel inlet. Add 2.4 m (8 ft.) to the measured length for each 90 degree elbow. Compare the pipe size and length with the chart in Figure 2-9. If the piping is longer than the maximum length shown for that size, replace it with the specified size before proceeding.

Pipe Size	Maximum Pipe Length, m (ft.)
3/4 in. NPT	9.2 (30)
1 in. NPT	30 (100)
1 1/4 in. NPT	68.6 (225)

**Figure 2-9** Maximum Natural Gas Pipe Length

Contact the local LP provider for LP pipe size information.

Figure 2-10 shows the location of the fuel inlet connection. Use flexible sections to prevent fuel line breakage caused by vibration. Hold the fuel solenoid valve with a wrench when tightening the fuel connections. Protect all fuel lines from machinery or equipment contact, adverse weather conditions, and environmental damage.



**Figure 2-10** Fuel System Locations, Air Inlet Side

## 2.5.2 Fuel Conversion

The multi-fuel system allows conversion from natural gas to LP vapor (or vice-versa) in the field while maintaining emissions-standard compliance. A trained technician or authorized distributor/dealer can convert the fuel system.

An LP fuel jet is included with the generator set. Conversion to LP fuel involves the following:

- Installation of the fuel jet.
- Disconnection of the digital spark-advance module (DSAM) leads.

Use the following procedure to convert from natural gas to LP vapor. See Figure 2-10 for the fuel system component locations.

### ⚠ WARNING




**Accidental starting.  
Can cause severe injury or death.**

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

**Disabling the generator set. Accidental starting can cause severe injury or death.** Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

---

**⚠ WARNING**



**Explosive fuel vapors.  
Can cause severe injury or death.**


Use extreme care when handling,  
storing, and using fuels.

---


### Fuel Conversion Procedure

1. Place the generator set master switch in the OFF position.
2. Disconnect the power to the battery charger.
3. Disconnect the generator set engine starting battery, negative (-) lead first.
4. Turn off the fuel supply.
5. Remove the enclosure roof or end panel to gain access to the fuel system. See Figure 2-10.
6. Remove the hose clamp and fuel hose from the hose fitting in the regulator. See Figure 2-10.
7. Use a screwdriver to install the LP fuel jet into the elbow fitting. See Figure 2-11.
8. Slide the hose onto the hose fitting and secure it with the clamp.
9. Disconnect the digital spark-advance module (DSAM) leads for LP. See Figure 2-12.
10. Connect and turn on the new fuel supply.
11. Check that the generator set master switch is in the OFF position.
12. Reconnect the generator set engine starting battery leads, negative (-) lead last.

13. Reconnect power to the battery charger.



**Figure 2-11** Fuel Conversion




**Figure 2-12** Digital Spark Advance Module (DSAM) Leads (located in generator set air intake area)

14. Start the generator set by moving the generator set master switch to the RUN position.
15. Check for leaks using a gas leak detector.
16. Move the generator set master switch to the OFF/RESET position to shut down the generator set.

To convert from LP vapor to natural gas, reverse the fuel conversion procedure, removing the LP fuel jet and connecting the DSAM leads for natural gas. See Figure 2-12.

## 2.6 Electrical Connections

<b>⚠ WARNING</b>

<b>Hazardous voltage. Backfeed to the utility system can cause property damage, severe injury, or death.</b>
If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

**Grounding electrical equipment. Hazardous voltage can cause severe injury or death.** Electrocutation is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

**Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death.** Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.

### NOTICE


**Canadian installations only.** For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code, Part 1.

Have an authorized distributor/dealer or a licensed electrician make the following electrical connections. Verify that the electrical installation complies with the National Electrical Code (NEC) and all applicable local codes. Ground generator set according to applicable codes.

### 2.6.1 Generator Set Connections

The factory-installed wiring kit eliminates the need to make field connections inside the generator set junction box. The wiring kit includes a wiring harness and an AC outlet mounted inside the generator set enclosure for the battery charger and accessories. See Figure 2-13.

The wiring harness includes the engine start leads, power leads to the AC outlet, and the emergency power leads. The leads exit the generator set in 1 1/4 inch conduit with liquid-tight connections. Cut a 2-inch hole through the building wall to bring the PVC end of the conduit into the building. Secure the PVC assembly to the wall using the clamp provided. Seal the gap around the conduit with caulk. Use duct seal inside the conduit if desired.



**Figure 2-13** Wiring Kit

Cut the leads to the length required and route the leads to the ATS. Add conduit if required by local codes. Refer to Figure 2-14 and the wiring diagram in Section 3 for the wiring kit connections. Connect and ground the system in accordance with the NEC and all applicable local codes.

Lead Identification		Connection
14 ga.	Red	Engine start leads 3 and 4 to the ATS
	White/Red	
	Black	120 VAC circuit on essential loads panel for battery charger and accessories. See Section 2.6.2.
	White	
	Uninsulated	
6 ga.	Red	ATS emergency source lugs EL1 and EL2
	Black	
	White	Neutral
	Uninsulated	Ground

Figure 2-14 Wiring Kit Field Connections

## 2.6.2 Power Supply

Power must be supplied to the generator set location for the battery charger and the optional carburetor heater. A 120 VAC receptacle is located inside the air intake compartment. Power to the receptacle must be supplied through leads in the wiring kit harness. See Figure 2-14.

Connect the power leads to a 120 VAC circuit in the essential loads panel so that the battery charger is powered by the generator set when utility power is not available. Figure 2-15 lists the power requirements for the battery charger and accessories.

Equipment	Power Requirement, Max.		
	Watts	Amps	Volts
Battery charger	192	1.60	120
Carburetor heater *	38	0.32	
* Not included on all models			

Figure 2-15 Power Requirements

## 2.6.3 Grounding

Ground the generator set. The grounding method must comply with NEC and local codes. The wiring kit includes 2 ground leads. See Figure 2-14 and also Figure 2-18 in Section 2.7, Transfer Switch Connections.

Kohler generator sets are shipped with the generator neutral attached to the generator in the junction box. At installation, the neutral can be grounded at the generator set or lifted from the ground stud and isolated if the installation requires an ungrounded neutral connection at the generator. The generator set will operate properly with the neutral either bonded to ground or isolated from ground at the generator.

Various regulations and site configurations including the National Electrical Code (NEC), local codes, and the type of transfer switch used in the application determine the grounding of the neutral at the generator. NEC 2002 Section 250.20 is one example that has a very good explanation of the neutral grounding requirements for generators.

## 2.6.4 Battery

### WARNING




**Sulfuric acid in batteries.**  
**Can cause severe injury or death.**

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

**Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death.** Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

**Battery acid cleanup. Battery acid can cause severe injury or death.** Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

<b>⚠ WARNING</b>

<p><b>Explosion.</b>  <b>Can cause severe injury or death.</b>  <b>Relays in the battery charger cause arcs or sparks.</b></p> <p>Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.</p>

**Battery gases. Explosion can cause severe injury or death.** Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.


**Battery short circuits. Explosion can cause severe injury or death.** Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

**Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death.** Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).


Use a 12-volt battery with a minimum rating of 525 cold cranking amps at 0°F. The generator set uses a negative ground with a 12-volt engine electrical system. See Figure 2-16 for battery connections. Make sure that the battery is correctly connected and the terminals are tight.

**Note:** The generator set will not start and circuit board damage may occur if the battery is connected in reverse.

Figure 2-17 shows the location of the engine starting battery. Standard battery cables provide easy connection to the battery. Use the following procedure to install and connect the battery.



**Figure 2-16** 12-Volt Engine Electrical System Single Starter Motor Typical Battery Connection



**Figure 2-17** Battery Location, Air Intake End

**Battery Installation Procedure**

1. Ensure that the starting battery is fully charged before placing the battery in service.
2. Clean the battery posts and/or adapters if necessary.
3. Install the battery post adapters, if needed.
4. Place the battery in the housing.
5. Verify that the controller master switch is in the OFF position.
6. Connect the positive (+) lead to the engine starting battery.
7. Connect the negative (-) lead to the engine starting battery.

## 2.6.5 Battery Charger

A 6-amp battery charger is factory-installed in the battery compartment. The battery charger's DC leads are factory-connected. The battery charger is required in order to keep the engine starting battery fully charged. Plug the battery charger's power cord into the 120 VAC receptacle inside the air intake compartment. See Section 2.6.2 for instructions to connect power to the receptacle. Refer to the generator set operation manual for battery charger operation information.

## 2.7 Transfer Switch Connections

Connect the engine start leads and power cables from the generator wiring kit to the transfer switch. See Figure 2-18 and the wiring diagrams in Section 3.

Follow the instructions in ATS Operation/Installation Manual TP-6345 for transfer switch installation, operation, test, and maintenance instructions.




Figure 2-18 Transfer Switch Connections

## 2.8 Carburetor Heater


Generator sets are available with or without the carburetor heater. The carburetor heater is recommended for improved cold starting in locations where the ambient temperature drops below 0°C (32 °F). The carburetor heater prevents condensation and carburetor icing. The heater turns on when the temperature at the thermostat falls below approximately 4°C (40°F) and turns off when the temperature rises above approximately 16°C (60°F).

The heater requires a continuous source of 120 VAC power. A 120 VAC receptacle is located inside the generator set housing air intake area. See Figure 1-1. The wiring kit includes leads for the receptacle. Connect the receptacle leads to a circuit breaker in the essential load panel in the ATS enclosure to ensure that the receptacle is always powered. See Section 2.6.1 for connection information.

The carburetor heater is installed between the carburetor and the air cleaner. See Figure 1-1 for the location.

The heater thermostat is installed in the cord. Figure 2-19 shows the location of the thermostat on the power cord. The thermostat is located in the air intake area.

**Note:** Do not place the heater thermostat inside the generator set engine compartment. The thermostat must be exposed to the ambient air. The thermostat will shut off power to the heater when the ambient temperature reaches approximately 16°C (60°F).



**Figure 2-19** Carburetor Heater with Thermostat



## 2.9 Prestart Installation Check

Review the entire installation section. Inspect all wiring and connections to verify that the generator set is ready for operation. Check all items in the following Prestart Checklist.

### Prestart Checklist

**Air Cleaner.** Check that a clean air cleaner element is installed to prevent unfiltered air from entering the engine.

**Air Inlets.** Check for clean and unobstructed air inlets.

**Battery.** Check for tight battery connections. Consult the battery manufacturer's instructions regarding battery care and maintenance.

**Exhaust System.** Check for exhaust leaks and blockages. Check the silencer and piping condition.

- Inspect the exhaust system components (exhaust manifold, exhaust line, flexible exhaust, clamps, silencer, and outlet pipe) for cracks, leaks, and corrosion. Check for tight exhaust system connections.

- Check for corroded or broken metal parts and replace them as needed.

- Check that the exhaust outlet is unobstructed.

**Oil Level.** Maintain the oil level at or near, not over, the full mark on the dipstick.

**Operating Area.** Check for obstructions that could block the flow of cooling air. Keep the air intake area clean. Do not leave rags, tools, or debris on or near the generator set.

## 2.10 Warranty Registration

Complete the startup and installation checklists supplied with the startup notification form. Complete and sign the startup notification form and return copies to Kohler Co. and the distributor/dealer as instructed on the form.

# Notes

## Section 3 Wiring Diagrams

### 3.1 Specification Numbers

At the time of print, this manual applied to the model numbers and specification (spec) numbers in Figure 3-1.

Model No.	Spec. No.
12RESL and 12RESM1	GM39503-SA1
	GM39503-SA2
	GM39503-SA3
	GM39503-SA4

**Figure 3-1** Generator Set Specification Numbers

### 3.2 Controller Wiring Diagram Reference

Figure 3-2 lists the wiring diagram numbers and locations.

Wiring Diagram Description	Drawing Number	Page
Schematic Diagram Sheet 1	ADV-7296A-	28
	ADV-7296B-	29
Point-to-Point Wiring Diagram	GM49761-A	30

**Figure 3-2** Controller Wiring Diagrams





Figure 3-3 Schematic Diagram, Sheet 1, ADV-7296A-



**Figure 3-4** Schematic Diagram, Sheet 2, ADV-7296B-





Figure 3-5 Point-to-Point Wiring Diagram, GM49761-A

# Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

A, amp	ampere	cfh	cubic feet per hour	ES	engineering special, engineered special
ABDC	after bottom dead center	cfm	cubic feet per minute	ESD	electrostatic discharge
AC	alternating current	CG	center of gravity	est.	estimated
A/D	analog to digital	CID	cubic inch displacement	E-Stop	emergency stop
ADC	advanced digital control; analog to digital converter	CL	centerline	etc.	et cetera (and so forth)
adj.	adjust, adjustment	cm	centimeter	exh.	exhaust
ADV	advertising dimensional drawing	CMOS	complementary metal oxide substrate (semiconductor)	ext.	external
Ah	amp-hour	cogen.	cogeneration	F	Fahrenheit, female
AHWT	anticipatory high water temperature	com	communications (port)	fglass.	fiberglass
AISI	American Iron and Steel Institute	coml	commercial	FHM	flat head machine (screw)
ALOP	anticipatory low oil pressure	Coml/Rec	Commercial/Recreational	fl. oz.	fluid ounce
alt.	alternator	conn.	connection	flex.	flexible
Al	aluminum	cont.	continued	freq.	frequency
ANSI	American National Standards Institute (formerly American Standards Association, ASA)	CPVC	chlorinated polyvinyl chloride	FS	full scale
AO	anticipatory only	crit.	critical	ft.	foot, feet
APDC	Air Pollution Control District	CRT	cathode ray tube	ft. lb.	foot pounds (torque)
API	American Petroleum Institute	CSA	Canadian Standards Association	ft./min.	feet per minute
approx.	approximate, approximately	CT	current transformer	ftp	file transfer protocol
AQMD	Air Quality Management District	Cu	copper	g	gram
AR	as required, as requested	cUL	Canadian Underwriter's Laboratories	ga.	gauge (meters, wire size)
AS	as supplied, as stated, as suggested	CUL	Canadian Underwriter's Laboratories	gal.	gallon
ASE	American Society of Engineers	cu. in.	cubic inch	gen.	generator
ASME	American Society of Mechanical Engineers	cw.	clockwise	genset	generator set
assy.	assembly	CWC	city water-cooled	GFI	ground fault interrupter
ASTM	American Society for Testing Materials	cyl.	cylinder	GND, 	ground
ATDC	after top dead center	D/A	digital to analog	gov.	governor
ATS	automatic transfer switch	DAC	digital to analog converter	gph	gallons per hour
auto.	automatic	dB	decibel	gpm	gallons per minute
aux.	auxiliary	dB(A)	decibel (A weighted)	gr.	grade, gross
avg.	average	DC	direct current	GRD	equipment ground
AVR	automatic voltage regulator	DCR	direct current resistance	gr. wt.	gross weight
AWG	American Wire Gauge	deg., °	degree	H x W x D	height by width by depth
AWM	appliance wiring material	dept.	department	HC	hex cap
bat.	battery	DFMEA	Design Failure Mode and Effects Analysis	HCHT	high cylinder head temperature
BBDC	before bottom dead center	dia.	diameter	HD	heavy duty
BC	battery charger, battery charging	DI/EO	dual inlet/end outlet	HET	high exhaust temp., high engine temp.
BCA	battery charging alternator	DIN	Deutsches Institut fur Normung e. V. (also Deutsche Industrie Normenausschuss)	hex	hexagon
BCI	Battery Council International	DIP	dual inline package	Hg	mercury (element)
BDC	before dead center	DPDT	double-pole, double-throw	HH	hex head
BHP	brake horsepower	DPST	double-pole, single-throw	HHC	hex head cap
blk.	black (paint color), block (engine)	DS	disconnect switch	HP	horsepower
blk. htr.	block heater	DVR	digital voltage regulator	hr.	hour
BMEP	brake mean effective pressure	E, emer.	emergency (power source)	HS	heat shrink
bps	bits per second	ECM	electronic control module, engine control module	hsg.	housing
br.	brass	EDI	electronic data interchange	HVAC	heating, ventilation, and air conditioning
BTDC	before top dead center	EFR	emergency frequency relay	HWT	high water temperature
Btu	British thermal unit	e.g.	for example ( <i>exempli gratia</i> )	Hz	hertz (cycles per second)
Btu/min.	British thermal units per minute	EG	electronic governor	IC	integrated circuit
C	Celsius, centigrade	EGSA	Electrical Generating Systems Association	ID	inside diameter, identification
cal.	calorie	EIA	Electronic Industries Association	IEC	International Electrotechnical Commission
CAN	controller area network	EI/EO	end inlet/end outlet	IEEE	Institute of Electrical and Electronics Engineers
CARB	California Air Resources Board	EMI	electromagnetic interference	IMS	improved motor starting
CB	circuit breaker	emiss.	emission	in.	inch
cc	cubic centimeter	eng.	engine	in. H <sub>2</sub> O	inches of water
CCA	cold cranking amps	EPA	Environmental Protection Agency	in. Hg	inches of mercury
ccw.	counterclockwise	ER	emergency power system	in. lb.	inch pounds
CEC	Canadian Electrical Code		emergency relay	Inc.	incorporated
cert.	certificate, certification, certified			ind.	industrial

IP	iron pipe	ms	millisecond	RHM	round head machine (screw)
ISO	International Organization for Standardization	m/sec.	meters per second	rly.	relay
J	joule	MTBF	mean time between failure	rms	root mean square
JIS	Japanese Industry Standard	MTBO	mean time between overhauls	rnd.	round
k	kilo (1000)	mtg.	mounting	ROM	read only memory
K	kelvin	MTU	Motoren-und Turbinen-Union	rot.	rotate, rotating
kA	kiloampere	MW	megawatt	rpm	revolutions per minute
KB	kilobyte (2 <sup>10</sup> bytes)	mW	milliwatt	RS	right side
KBus	Kohler communication protocol	μF	microfarad	RTU	remote terminal unit
kg	kilogram	N, norm.	normal (power source)	RTV	room temperature vulcanization
kg/cm <sup>2</sup>	kilograms per square centimeter	NA	not available, not applicable	RW	read/write
kgm	kilogram-meter	nat. gas	natural gas	SAE	Society of Automotive Engineers
kg/m <sup>3</sup>	kilograms per cubic meter	NBS	National Bureau of Standards	scfm	standard cubic feet per minute
kHz	kilohertz	NC	normally closed	SCR	silicon controlled rectifier
kJ	kilojoule	NEC	National Electrical Code	s, sec.	second
km	kilometer	NEMA	National Electrical Manufacturers Association	SI	<i>Systeme international d'unites</i> , International System of Units
kOhm, kΩ	kilo-ohm	NFPA	National Fire Protection Association	SI/EO	side in/end out
kPa	kilopascal	Nm	newton meter	sil.	silencer
kph	kilometers per hour	NO	normally open	SN	serial number
kV	kilovolt	no., nos.	number, numbers	SNMP	simple network management protocol
kVA	kilovolt ampere	NPS	National Pipe, Straight	SPDT	single-pole, double-throw
kVAR	kilovolt ampere reactive	NPSC	National Pipe, Straight-coupling	SPST	single-pole, single-throw
kW	kilowatt	NPT	National Standard taper pipe thread per general use	spec	specification
kWh	kilowatt-hour	NPTF	National Pipe, Taper-Fine	specs	specification(s)
kWm	kilowatt mechanical	NR	not required, normal relay	sq.	square
kWth	kilowatt-thermal	ns	nanosecond	sq. cm	square centimeter
L	liter	OC	overcrank	sq. in.	square inch
LAN	local area network	OD	outside diameter	SS	stainless steel
L x W x H	length by width by height	OEM	original equipment manufacturer	std.	standard
lb.	pound, pounds	OF	overfrequency	stl.	steel
lbm/ft <sup>3</sup>	pounds mass per cubic feet	opt.	option, optional	tach.	tachometer
LCB	line circuit breaker	OS	oversize, overspeed	TD	time delay
LCD	liquid crystal display	OSHA	Occupational Safety and Health Administration	TDC	top dead center
ld. shd.	load shed	OV	overvoltage	TDEC	time delay engine cooldown
LED	light emitting diode	oz.	ounce	TDEN	time delay emergency to normal
Lph	liters per hour	p., pp.	page, pages	TDES	time delay engine start
Lpm	liters per minute	PC	personal computer	TDNE	time delay normal to emergency
LOP	low oil pressure	PCB	printed circuit board	TDOE	time delay off to emergency
LP	liquefied petroleum	pF	picofarad	TDON	time delay off to normal
LPG	liquefied petroleum gas	PF	power factor	temp.	temperature
LS	left side	ph., ∅	phase	term.	terminal
L <sub>wa</sub>	sound power level, A weighted	PHC	Phillips® head Crimpitte® (screw)	THD	total harmonic distortion
LWL	low water level	PHH	Phillips® hex head (screw)	TIF	telephone influence factor
LWT	low water temperature	PHM	pan head machine (screw)	TIR	total indicator reading
m	meter, milli (1/1000)	PLC	programmable logic control	tol.	tolerance
M	mega (10 <sup>6</sup> when used with SI units), male	PLM	programmable magnet generator	turbo.	turbocharger
m <sup>3</sup>	cubic meter	PMG	permanent magnet generator	typ.	typical (same in multiple locations)
m <sup>3</sup> /hr.	cubic meters per hour	pot	potentiometer, potential	UF	underfrequency
m <sup>3</sup> /min.	cubic meters per minute	ppm	parts per million	UHF	ultrahigh frequency
mA	milliampere	PROM	programmable read-only memory	UL	Underwriter's Laboratories, Inc.
man.	manual	psi	pounds per square inch	UNC	unified coarse thread (was NC)
max.	maximum	psig	pounds per square inch gauge	UNF	unified fine thread (was NF)
MB	megabyte (2 <sup>20</sup> bytes)	pt.	pint	univ.	universal
MCCB	molded-case circuit breaker	PTC	positive temperature coefficient	US	undersize, underspeed
MCM	one thousand circular mils	PTO	power takeoff	UV	ultraviolet, undervoltage
meggar	megohmmeter	PVC	polyvinyl chloride	V	volt
MHz	megahertz	qt.	quart, quarts	VAC	volts alternating current
mi.	mile	qty.	quantity	VAR	voltampere reactive
mil	one one-thousandth of an inch	R	replacement (emergency) power source	VDC	volts direct current
min.	minimum, minute	rad.	radiator, radius	VFD	vacuum fluorescent display
misc.	miscellaneous	RAM	random access memory	VGA	video graphics adapter
MJ	megajoule	RDO	relay driver output	VHF	very high frequency
mJ	millijoule	ref.	reference	W	watt
mm	millimeter	rem.	remote	WCR	withstand and closing rating
mOhm, mΩ	milliohm	Res/Coml	Residential/Commercial	w/	with
MOhm, MΩ	megohm	RFI	radio frequency interference	w/o	without
MOV	metal oxide varistor	RH	round head	wt.	weight
MPa	megapascal			xfmr	transformer
mpg	miles per gallon				
mph	miles per hour				
MS	military standard				




# Appendix B Common Hardware Application Guidelines

Use the information below and on the following pages to identify proper fastening techniques when no specific reference for reassembly is made.

**Bolt/Screw Length:** When bolt/screw length is not given, use Figure 1 as a guide. As a general rule, a minimum length of one thread beyond the nut and a maximum length of 1/2 the bolt/screw diameter beyond the nut is the preferred method.

**Washers and Nuts:** Use split lock washers as a bolt locking device where specified. Use SAE flat washers with whiz nuts, spirallock nuts, or standard nuts and preloading (torque) of the bolt in all other applications.

See Appendix C, General Torque Specifications, and other torque specifications in the service literature.




**Figure 1** Acceptable Bolt Lengths

Steps for common hardware application:

1. Determine entry hole type: round or slotted.
2. Determine exit hole type: fixed female thread (weld nut), round, or slotted.

For round and slotted exit holes, determine if hardware is greater than 1/2 inch in diameter, or 1/2 inch in diameter or less. Hardware that is *greater than 1/2 inch* in diameter takes a standard nut and SAE washer. Hardware *1/2 inch or less* in diameter can take a properly torqued whiz nut or spirallock nut. See Figure 2.

3. Follow these SAE washer rules after determining exit hole type:
  - a. Always use a washer between hardware and a slot.
  - b. Always use a washer under a nut (see 2 above for exception).
  - c. Use a washer under a bolt when the female thread is fixed (weld nut).
4. Refer to Figure 2, which depicts the preceding hardware configuration possibilities.



**Figure 2** Acceptable Hardware Combinations

# Appendix C General Torque Specifications

American Standard Fasteners Torque Specifications					
Size	Torque Measurement	Assembled into Cast Iron or Steel			Assembled into Aluminum Grade 2 or 5
		Grade 2	Grade 5	Grade 8	
8-32	Nm (in. lb.)	1.8 (16)	2.3 (20)	—	See Note 3
10-24	Nm (in. lb.)	2.9 (26)	3.6 (32)	—	
10-32	Nm (in. lb.)	2.9 (26)	3.6 (32)	—	
1/4-20	Nm (in. lb.)	6.8 (60)	10.8 (96)	14.9 (132)	
1/4-28	Nm (in. lb.)	8.1 (72)	12.2 (108)	16.3 (144)	
5/16-18	Nm (in. lb.)	13.6 (120)	21.7 (192)	29.8 (264)	
5/16-24	Nm (in. lb.)	14.9 (132)	23.1 (204)	32.5 (288)	
3/8-16	Nm (ft. lb.)	24.0 (18)	38.0 (28)	53.0 (39)	
3/8-24	Nm (ft. lb.)	27.0 (20)	42.0 (31)	60.0 (44)	
7/16-14	Nm (ft. lb.)	39.0 (29)	60.0 (44)	85.0 (63)	
7/16-20	Nm (ft. lb.)	43.0 (32)	68.0 (50)	95.0 (70)	
1/2-13	Nm (ft. lb.)	60.0 (44)	92.0 (68)	130.0 (96)	
1/2-20	Nm (ft. lb.)	66.0 (49)	103.0 (76)	146.0 (108)	
9/16-12	Nm (ft. lb.)	81.0 (60)	133.0 (98)	187.0 (138)	
9/16-18	Nm (ft. lb.)	91.0 (67)	148.0 (109)	209.0 (154)	
5/8-11	Nm (ft. lb.)	113.0 (83)	183.0 (135)	259.0 (191)	
5/8-18	Nm (ft. lb.)	128.0 (94)	208.0 (153)	293.0 (216)	
3/4-10	Nm (ft. lb.)	199.0 (147)	325.0 (240)	458.0 (338)	
3/4-16	Nm (ft. lb.)	222.0 (164)	363.0 (268)	513.0 (378)	
1-8	Nm (ft. lb.)	259.0 (191)	721.0 (532)	1109.0 (818)	
1-12	Nm (ft. lb.)	283.0 (209)	789.0 (582)	1214.0 (895)	

Metric Fasteners Torque Specifications, Measured in Nm (ft. lb.)				
Size (mm)	Assembled into Cast Iron or Steel			Assembled into Aluminum Grade 5.8 or 8.8
	Grade 5.8	Grade 8.8	Grade 10.9	
M6 x 1.00	6.2 (4.6)	9.5 (7)	13.6 (10)	See Note 3
M8 x 1.25	15.0 (11)	23.0 (17)	33.0 (24)	
M8 x 1.00	16.0 (11)	24.0 (18)	34.0 (25)	
M10 x 1.50	30.0 (22)	45.0 (34)	65.0 (48)	
M10 x 1.25	31.0 (23)	47.0 (35)	68.0 (50)	
M12 x 1.75	53.0 (39)	80.0 (59)	115.0 (85)	
M12 x 1.50	56.0 (41)	85.0 (63)	122.0 (90)	
M14 x 2.00	83.0 (61)	126.0 (93)	180.0 (133)	
M14 x 1.50	87.0 (64)	133.0 (98)	190.0 (140)	
M16 x 2.00	127.0 (94)	194.0 (143)	278.0 (205)	
M16 x 1.50	132.0 (97)	201.0 (148)	287.0 (212)	
M18 x 2.50	179.0 (132)	273.0 (201)	390.0 (288)	
M18 x 1.50	189.0 (140)	289.0 (213)	413.0 (305)	

**Notes:**

1. The torque values above are general guidelines. Always use the torque values specified in the service manuals and/or assembly drawings when they differ from the above torque values.
2. The torque values above are based on new plated threads. Increase torque values by 15% if non-plated threads are used.
3. Hardware threaded into aluminum must have either two diameters of thread engagement or a 30% or more reduction in the torque to prevent stripped threads.
4. Torque values are calculated as equivalent stress loading on American hardware with an approximate preload of 90% of the yield strength and a friction coefficient of 0.125.



**TP-6397 4/07c**

© 2006, 2007, 2008 by Kohler Co. All rights reserved.

# **KOHLER**<sup>®</sup> POWER SYSTEMS

KOHLER CO. Kohler, Wisconsin 53044  
Phone 920-565-3381, Fax 920-459-1646  
For the nearest sales/service outlet in the  
US and Canada, phone 1-800-544-2444  
[KohlerPower.com](http://KohlerPower.com)

Kohler Power Systems  
Asia Pacific Headquarters  
7 Jurong Pier Road  
Singapore 619159  
Phone (65) 6264-6422, Fax (65) 6264-6455