Operation

Residential/Commercial Generator Sets



Models:

12RESM1 12RESL

Controller: DC 2200 Digital Control



KOHLER®
POVER SYSTEMS______TP-639

California Proposition 65



WARNING

Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Product Identification Information

Product identification numbers determine service parts. Record the product identification numbers in the spaces below immediately after unpacking the products so that the numbers are readily available for future reference. Record field-installed kit numbers after installing the kits.

Generator Set Identification Numbers

Record the product ic generator set nameplate	dentification numbers from the re(s).
Model Designation	
Specification Number _	
Serial Number	
Accessory Number	Accessory Description

Controller Identification
Record the controller description from the generator set operation manual, spec sheet, or sales invoice.
Controller Description DC2200
Engine Identification
Record the product identification information from the engine nameplate.
Manufacturer
Model Designation
Serial Number

Table of Contents

Product Identification Information				
Safety Precaution	ns an	d Instructions	5	
Introduction			9	
Service Assistance	се		10	
Section 1 Feature	es		11	
-	1.1	Specifications	11	
-	1.2	Generator	11	
-	1.3	Engine	11	
	1.4	Digital Control DC 2200	11	
	1.5	Generator Set Components	12	
	_		13	
		Dunatant Oh saldist		
-	2.1	Prestart Checklist	13	
2	2.2	Generator Set Operation	13	
		2.2.1 Controls and Indicators	13	
		2.2.2 Starting Generator Set	14	
		2.2.3 Stopping Generator Set	14	
	2.3	Exercising Generator Set	14	
2	2.4	Faults	15	
		2.4.1 Shutdowns	15	
		2.4.2 Warning	15	
,	<u> </u>	2.4.3 Resetting Controller After Fault Shutdown	16	
2	2.5	Battery Charger	16	
Section 3 Schedu	uled l	Maintenance	19	
(3.1	Routine Maintenance	19	
(3.2	Service Schedule	20	
(3.3	Lubrication System	21	
		3.3.1 Low Oil Pressure Shutdown	21	
		3.3.2 Oil Check	21	
		3.3.3 Engine Oil Recommendation	21	
		3.3.4 Oil Change Procedure	21	
(3.4	Spark Plugs	22	
(3.5	Air Cleaner Element and Precleaner	22	
		3.5.1 Precleaner Service	22	
		3.5.2 Paper Element Service	23	
(3.6	Cooling System	23	
(3.7	Exhaust System	23	
(3.8	Battery	24	
(3.9	Battery Charger	25	
(3.10	Circuit Protection	25	
		3.10.1 Line Circuit Breaker	25	
		3.10.2 Fuses	25	
(3.11	Storage Procedure	25	
		3.11.1 Lubricating System	25	
		3.11.2 Fuel System	26	
		3.11.3 Cylinder Lubrication	26	
		3.11.4 Exterior Preparation	26	
		3.11.5 Battery	26	

Table of Contents, continued

Section 4 Troublesho	poting	27
4.1	Introduction	27
4.2	Fault Codes	27
4.3	Generator Set Troubleshooting	28
4.4	Battery Charger Troubleshooting	29
Appendix A Abbrevia	ations	31

4 Table of Contents TP-6398 4/07

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. SAVE THESE INSTRUCTIONS.

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.



DANGER

Danger indicates the presence of a hazard that *will cause severe* personal injury, death, or substantial property damage.



WARNING

Warning indicates the presence of a hazard that *can cause severe personal injury, death,* or *substantial property damage*.



CAUTION

Caution indicates the presence of a hazard that *will* or *can cause minor personal injury* or *property damage*.

NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator Accidental starting can cause severe injury or death. working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

Battery

A

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

▲ WARNING



Explosion.

Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eves or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all iewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death.

Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Engine Backfire/Flash Fire



Fire.
Can cause severe injury or death.

Do not smoke or permit flames or sparks near fuels or the fuel system.


Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner removed.

Servicing the fuel system. A flash fire can cause severe injury or death.

Do not smoke or permit flames or sparks near the carburetor, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Catch fuels in an approved container when removing the fuel line or carburetor.

Combustible materials. A fire can cause severe injury or death. Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or BC for electrical fires or as recommended by the local fire code or an authorized agency. Train all fire extinguisher personnel on operation and fire prevention procedures.

Exhaust System



Carbon monoxide.
Can cause severe nausea, fainting, or death.

The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

Fuel System



Explosive fuel vapors.
Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

The fuel system. Explosive fuel vapors can cause severe injury or death. Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

Explosive fuel Gas fuel leaks. vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LP vapor gas or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces per square inch (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

Hazardous Noise

▲ CAUTION



Hazardous noise. Can cause hearing loss.

Never operate the generator set without a muffler or with a faulty exhaust system.

Engine noise. Hazardous noise can cause hearing loss. Generator sets not equipped with sound enclosures can produce noise levels greater than 105 dBA. Prolonged exposure to noise levels greater than 85 dBA can cause permanent hearing loss. Wear hearing protection when near an operating generator set.

Hazardous Voltage/ Moving Parts



Hazardous voltage.
Will cause severe injury or death.

Disconnect all power sources before opening the enclosure.

▲ WARNING





Hazardous voltage. Moving parts. Can cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

A WARNING



Hazardous voltage. Backfeed to the utility system can cause property damage, severe injury, or death.

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

A CAUTION



Welding the generator set.

Can cause severe electrical equipment damage.

Never weld components of the generator set without first disconnecting the battery, controller wiring harness, and engine electronic control module (ECM).

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Welding on the generator set. Can cause severe electrical equipment damage. Before welding on the generator set perform the following steps: (1) Remove the battery cables, negative (-) lead first. (2) Disconnect all engine electronic control module (ECM) connectors. (3) Disconnect all generator set controller and voltage regulator circuit board connectors. (4) Disconnect the engine battery-charging alternator connections. (5) Attach the weld ground connection close to the weld location.

Installing the battery charger. Hazardous voltage can cause severe injury or death. ungrounded battery charger may cause electrical shock. Connect the battery charger enclosure to the ground of a permanent wiring system. As an alternative, install an equipment grounding conductor with circuit conductors and connect it to the equipment grounding terminal or the lead on the battery charger. Install the battery charger as prescribed in the equipment manual. Install the battery charger in compliance with local codes and ordinances.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death. Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.





Airborne particles.
Can cause severe injury or blindness.

Wear protective goggles and clothing when using power tools, hand tools, or compressed air.

Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

Heavy Equipment



Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.

Do not use lifting eyes.

Lift the generator set using lifting bars inserted through the lifting holes on the skid.

Hot Parts



Hot engine and exhaust system. Can cause severe injury or death.


Do not work on the generator set until it cools.

Servicing the alternator. Hot parts can cause severe injury or death. Avoid touching the alternator field or exciter armature. When shorted, the alternator field and exciter armature become hot enough to cause severe burns.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Servicing the engine heater. Hot parts can cause minor personal injury or property damage. Install the heater before connecting it to power. Operating the heater before installation can cause burns and component damage. Disconnect power to the heater and allow it to cool before servicing the heater or nearby parts.

Notice



NOTICE

Voltage reconnection. Affix a notice to the generator set after reconnecting the set to a voltage different from the voltage on the nameplate. Order voltage reconnection decal 246242 from an authorized service distributor/dealer.

NOTICE

Canadian installations only. For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code, Part 1.

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), not a direct short, to ground.

This manual provides operation and maintenance instructions for model 12RESM1 and 12RESL generator sets equipped with the Kohler® DC 2200 Digital Control.

This generator set is approved for use in stationary applications in locations served by a reliable utility power source. Have the generator set installed by an authorized distributor/dealer or service technician. Refer to TP-6397, Installation Manual, for installation instructions.

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual. Keep this manual with the equipment for future reference.

The equipment service requirements are very important to safe and efficient operation. Inspect the parts often and perform required service at the prescribed intervals. Obtain service from an authorized service distributor/ dealer to keep equipment in top condition.

EPA and California Emission Certification

An engine or generator set with the following identification labels is certified to meet Small Off-Road Engine emission standards for EPA/CARB. All model 12RESM1/12RESL generator sets with multi-fuel systems are emission-certified.




Figure 1 Engine Emissions Label (CH740)




Figure 2 Engine Air Index Label

This engine/generator is certified to operate using natural gas or propane fuel.

The Emission Compliance Period referred to on the Emission Control or Air Index label indicates the number of operating hours for which the engine has been shown to meet CARB emission requirements. The following table provides the engine compliance period (in hours) associated with the category descriptor found on the certification label.

Emission Compliance Period (hours)						
CARB	Moderate, 125	Intermediate, 250	Extended, 500			

Refer to the certification label for engine displacement.

The exhaust emission control system for the 12RESM1/12RESL engine (CH740) is EM.

TP-6398 4/07 Introduction 9

Nameplate

The following illustration shows a typical generator set nameplate. Copy the model, serial, and specification numbers from the nameplate into the spaces provided in the product information section on the inside front cover of this manual. See Section 1.5, Generator Set Components, for the nameplate location.

KOHLER ® KOHLER CO. KOHLER WI. USA										
MODEL:			SERIA	L:						
SPEC:										
SERVICE	DUTY:									
HZ: RP	M:									
VOLTAGE	AMPS	PHASE	KW	KVA	P.F.					
GEN. MODEL: BATT. V										
GEN. MO					INSULATION: NEMA CLASS					
		MA CLAS	S	-,						
	ON: NEM									
INSULAT	ON: NEM									

Service Assistance

For professional advice on generator set power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KohlerPower.com.
- Look at the labels and stickers on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

Headquarters Europe, Middle East, Africa (EMEA)

Kohler Power Systems 3 rue de Brennus 93200 Saint Denis France

Phone: (33) 1 49 178300 Fax: (33) 1 49 178301

Asia Pacific

Power Systems Asia Pacific Regional Office Singapore, Republic of Singapore

Phone: (65) 6264-6422 Fax: (65) 6264-6455

China

North China Regional Office, Beijing

Phone: (86) 10 6518 7950 (86) 10 6518 7951 (86) 10 6518 7952

Fax: (86) 10 6518 7955

East China Regional Office, Shanghai

Phone: (86) 21 6288 0500 Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office Bangalore, India

Phone: (91) 80 3366208

(91) 80 3366231

Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office

Tokyo, Japan

Phone: (813) 3440-4515 Fax: (813) 3440-2727

Latin America

Latin America Regional Office Lakeland, Florida, USA

Phone: (863) 619-7568 Fax: (863) 701-7131

10 Service Assistance TP-6398 4/07

1.1 Specifications

The generator set specification sheets provide specific generator and engine information. Refer to the spec sheet for data not supplied in this manual. Consult the generator set service manual, engine operation manual, and engine service manual for additional specifications. Obtain copies of the latest spec sheets, manuals, diagrams, and drawings from your local distributor/ dealer.

1.2 Generator

The generator uses Kohler's unique PowerBoost $^{\text{\tiny M}}$ voltage regulation system, which provides instant response to load changes.

PowerBoost™ ensures reliable motor starting and consistent voltage levels. PowerBoost™ utilizes a voltage excitation system that employs a winding independent of the main output windings to provide excitation voltage.

1.3 Engine

The generator set has a four-cycle, twin cylinder, air-cooled Kohler® engine. The engine operates on clean-burning natural gas or propane (LP) vapor. Engine features include:

- Efficient overhead valve design and full pressure lubrication for maximum power, torque, and reliability under all operating conditions.
- Dependable, maintenance-free electronic ignition.
- Precision-formulated cast iron construction of parts subjected to the most wear and tear.
- Field-convertible multi-fuel systems that allow fuel changeover from natural gas to LP vapor (and vice-versa) while maintaining CARB emission certification.
- Digital spark-advance module (DSAM) optimizes ignition timing for the selected fuel.

1.4 Digital Control DC 2200

The generator set is equipped with the Kohler® Digital Control (DC 2200). Controller features include the following:

- Compact controller
- Integrally mounted to the generator set
- LED display:
 - Runtime hours
 - Crank cycle status
 - Diagnostics
- LED display communicates faults:
 - High engine temperature
 - Low battery voltage
 - · Low oil pressure
 - Overcrank safety
 - Overspeed
 - Overvoltage *
 - Underfrequency
 - Undervoltage *
- Master control switch: Run/Off-Reset/Auto
- Remote two-wire start/stop capability
- Digital voltage regulation: ±1.5% RMS no-load to full-load
- Automatic start for programmed cranking cycle
- * Controller software version 1.26 or higher.

TP-6398 4/07 Section 1 Features 11

1.5 Generator Set Components




Figure 1-1 Generator Set Components

12 Section 1 Features TP-6398 4/07

2.1 Prestart Checklist

To ensure continued satisfactory operation, perform the following checks or inspections before or at each startup, as designated, and at the intervals specified in the service schedule. In addition, some checks require verification after the unit starts.

Air Cleaner. Check for a clean and installed air cleaner element to prevent unfiltered air from entering the engine.

Air Inlets. Check for clean and unobstructed air inlets.

Battery. Check for tight battery connections. Consult the battery manufacturer's instructions regarding battery care and maintenance.

Exhaust System. Check for exhaust leaks and blockages. Check the muffler and piping condition and check for tight exhaust system connections.

Inspect the exhaust system components (exhaust manifold, exhaust line, flexible exhaust, clamps, silencer, and outlet pipe) for cracks, leaks, and corrosion.

- Check for corroded or broken metal parts and replace them as needed.
- Check that the exhaust outlet is unobstructed.
- Visually inspect for exhaust leaks (blowby). Check for carbon or soot residue on exhaust components.
 Carbon and soot residue indicates an exhaust leak.
 Seal leaks as needed.

Oil Level. Maintain the oil level at or near, not over, the full mark on the dipstick.

Operating Area. Check for obstructions that could block the flow of cooling air. Keep the air intake area clean. Do not leave rags, tools, or debris on or near the generator set.

2.2 Generator Set Operation

2.2.1 Controls and Indicators

Figure 2-1 illustrates the front panel of the Digital Control (DC 2200) generator set controller.

Figure 2-2 describes the controls and indicators located on the DC 2200. The LED display indicates generator set status as shown in Figure 2-2.

The LED display is activated:

- When the generator set master switch is moved to the RUN position.
- When a remote start command is received and the generator set master switch is in the AUTO position

The display turns off 48 hours after the generator set shuts down.




Figure 2-1 DC 2200 Front Panel

Control or Indicator	Item	Description
LED display	Runtime hours	Displays total generator set runtime hours while the generator set is running and when no other codes are displayed.
	Crank indication	Displays CC_1, CC_2, or CC_3 to indicate the first, second, or third attempt to start the engine. The last digit flashes during the crank cycle rest periods.
	Fault codes	Flashes a 2- or 3-letter fault code to indicate various fault conditions. See Section 2.4.
Generator set master switch	Three-position switch	Switch functions as the generator set operation and controller reset switch.

Figure 2-2 DC 2200 Controls and Indicators

TP-6398 4/07 Section 2 Operation 13

2.2.2 Starting Generator Set

The following procedures describe the actions required to start the generator set.

The controller attempts to start the generator set three times (three crank cycles, 15 seconds crank and 15 seconds off). If the generator set does not start in three attempts, the system shuts down on an overcrank fault.

Local Starting

Move the generator set master switch to the RUN position to immediately start the generator set.

Auto (Automatic) Starting

Move the generator set master switch to the AUTO position to allow startup by an automatic transfer switch (ATS) or remote start/stop switch, if equipped.

2.2.3 Stopping Generator Set

The following procedures describe the actions required to stop the generator set.

Local Stopping

- 1. Run the generator set with no load for at least 2 minutes to allow the engine to cool down.
- 2. Move the generator set master switch to the OFF/RESET position. The engine stops.

Automatic Stopping

With the generator set master switch in the AUTO position and an (ATS) or other automatic device connected to controller leads 3 and 4:

- 1. The ATS or other device disconnects the load from the generator set.
- If the ATS is equipped with an engine cooldown time delay, the generator set continues to run for a preset engine cooldown time.

Note: There is no engine cooldown time delay on the DC 2200 generator set controller.

The ATS or other device opens the remote start circuit between controller leads 3 and 4. The generator set shuts down.

2.3 Exercising Generator Set

Operate the generator set without load once each week for 20 minutes. If the generator set does not have a programmed exercise mode or an automatic transfer switch (ATS) with an exercise option, run the unit in the presence of an operator.

The operator should perform all of the prestart checks before starting the exercise procedure. Start the generator set according to the starting procedure in the controller section of this manual. While the generator set is operating, listen for a smooth-running engine and visually inspect the generator set for fluid or exhaust leaks. Check the air inlets and outlets and remove any items restricting the air flow.

14 Section 2 Operation TP-6398 4/07

2.4 Faults

The DC 2200 controller displays the fault warning and shutdown codes shown in Figure 2-3.

2.4.1 Shutdowns

If a shutdown code is displayed, the generator set has shut down automatically under the fault conditions listed in Figure 2-3. The generator set cannot be restarted until the fault condition is corrected and the controller is reset. See Section 2.4.3 to reset the controller after a fault shutdown. The controller resets automatically after a battery voltage fault condition is corrected.

The shutdown switches on the generator set automatically reset when the problem is corrected. The high engine temperature switch automatically resets when the generator set cools. However, the fault does not clear until the controller is reset.

2.4.2 Warning

The controller displays warning code LB but the generator set does not shut down when the engine starting battery voltage is low as described in Figure 2-3.

Code	Fault	Description	Check
HE	High engine temperature shutdown	Shutdown occurs if the engine coolant temperature exceeds the maximum temperature for more than 5 seconds. This protective becomes active after the engine reaches the crank disconnect speed.	Check for blocked air inlets and exhaust outlets.
LB	Low battery voltage warning	Fault code is displayed if the engine starting battery voltage falls below 8 VDC for a 12 VDC system or below 16 VDC for a 24 VDC system for more than 10 seconds when the engine is not running. This fault condition does not inhibit engine starting.	Check the battery rating and condition. Check the battery charger operation. Charge or replace the battery.
		The fault condition clears when the battery voltage returns to a voltage within the limits for more than 10 seconds.	
LOP	Low oil pressure shutdown	Shutdown occurs if a low oil pressure condition exists for more than 5 seconds. This protective becomes active 30 seconds after the engine has reached crank disconnect speed (30 second inhibit).	Check for leaks in the lubrication system. Check the oil level and add oil if the level is low.
		Note: The low oil pressure shutdown does not protect against low oil level. Check the oil level at the engine.	
OC Overcrank shutdown		Shutdown occurs after 3 unsuccessful starting attempts. The crank cycle is set for three starting attempts of 15 seconds cranking and 15 seconds rest.	Check the fuel supply, spark plug, and battery. Check for loose connections.
		The generator set also shuts down if no engine rotation is sensed during cranking. Shuts down 1 second after the fault is detected. *	Contact an authorized distributor/dealer for service if problem continues.
os	Overspeed shutdown	Shutdown occurs if the engine speed exceeds 115% of the normal running speed for more than 0.3 seconds.	Contact an authorized distributor/dealer for service if problem continues.
OU *	Overvoltage shutdown	Shutdown occurs if the voltage exceeds 120% of the system nominal voltage for more than 2 seconds.	Contact an authorized distributor/dealer for service.
UF	Underfrequency shutdown	Shutdown occurs when the governed frequency falls blow 90% of the nominal system frequency for more than 5 seconds. This protective becomes active 10 seconds after engine start. (10 second inhibit).	Reduce the load and restart the generator set. Contact an authorized distributor/dealer for service if problem continues.
UU *	Undervoltage shutdown	Shutdown occurs if the voltage falls below 80% of the nominal system voltage for more than 10 seconds.	Reduce the load and restart the generator set.
			Contact an authorized distributor/dealer for service if problem continues.
SCF0	Software Communication Fault 0	Indicates a software or communication problem within the ADC 2100	Replace the controller. Contact an authorized distributor/dealer for service.

Figure 2-3 DC 2200 Fault Codes

TP-6398 4/07 Section 2 Operation 15

2.4.3 Resetting Controller After Fault Shutdown

Always identify and correct the cause of a fault shutdown before resetting the controller. Use the following procedure to reset the generator set controller after a fault shutdown.

- Check the fault code displayed on the controller before resetting. See Figure 2-3 to identify the fault condition.
- 2. Move the generator set master switch to OFF/RESET.
- 3. Disconnect the generator set from the load using the line circuit breaker or ATS.

Note: See the safety precautions at the beginning of this section before proceeding.

- 4. Find and correct the cause of the fault shutdown. Refer to Section 4, Troubleshooting.
- 5. Test operate the generator set by moving the generator set master switch to RUN and verifying that the generator set starts and runs.
- 6. Move the generator set master switch to OFF/RESET. Verify that the generator set stops.
- 7. Reconnect the generator set to the load using the line circuit breaker or ATS.
- 8. Move the generator set master switch to the AUTO position for startup by remote transfer switch or remote start/stop switch.

Note: When the master switch is moved to AUTO, the controller's LED display remains off until a remote start command is received.

Controller software versions 1.26 and lower: Opening the remote start switch resets the controller.

Controller software versions 1.27 and higher: Faults must be reset with the master switch using the procedure shown above.

The controller software version number is displayed at controller powerup.

2.5 Battery Charger

The generator set is equipped with a 6-amp float/equalize battery charger to maintain the engine starting battery. The charger's power cord must be connected to a 120 VAC power source. Figure 2-4 illustrates the battery charger.

The battery charger uses an AGS 10 inline fuse. The fuse is located in the battery lead. See Figure 2-4.




Figure 2-4 6-Amp Float/Equalize Battery Charger

16 Section 2 Operation TP-6398 4/07

Figure 2-5 illustrates the three-stage charging method. Red and green LEDs indicate charger operation. The chart in Figure 2-6 describes the LED indicator operation during each stage of the charging process.




Figure 2-5 Charging Method

Display	Operating Condition
Red ON Green OFF	When the red LED is on, it indicates the battery is discharged and the battery charger is recharging at the BULK rate (stage 1). This charging rate is 6 amps. While the red LED is on, the voltage measured (with the battery charger on) will be 11.8-14 volts.
	If the red LED stays on for more than 24 hours, refer to Section 4.4 in this manual.
Red ON Green ON	When both the green and the red LEDs are on, the battery charger is charging at an ABSORPTION rate of between 1.5 and 5 amps (stage 2). This mode of charging gradually tops off your battery, and reduces harmful sulfating. While both LEDs are on, the voltage measured (with the battery charger on) should be approximately 14.0-14.5 VDC. If both LEDs stay on longer than 24 hours, refer to Section 4.4 in this manual.
Red OFF Green ON	When the green LED is on, the battery charger is charging at a FLOAT or MAINTENANCE rate of less than 1.5 amps (stage 3). Your battery is now 90% charged and ready for use. This float charging current will gradually decrease to as low as 0.1 amps as the battery reaches 100% charge. It will now be kept at full charge without overcharging.
	If the green LED stays on when your battery is known to be low, refer to Section 4.4 in this manual.

Figure 2-6 Battery Charger LED Indicator Functions

TP-6398 4/07 Section 2 Operation 17

Notes

18 Section 2 Operation TP-6398 4/07

WARNING



Accidental starting.
Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.



Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.



Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set

3.1 Routine Maintenance

Refer to the following service schedule and the runtime hours displayed on the DC 2200 display to schedule routine maintenance. Have an authorized distributor/dealer service the generator set at the designated intervals in the service schedule for the life of the generator set. Service units subject to extreme weather, long operating hours, or dusty or dirty conditions more frequently.

Contact an authorized distributor/dealer for parts.

3.2 Service Schedule

	Procedure						
System Component or Procedure	See Section	Visually Inspect	Check	Change	Clean	Test	Frequency
Fuel							
Flexible lines and connections		Х		R			Quarterly
Main tank supply level			Х				Weekly
Fuel piping		Х					Yearly
Lubrication	3.3						
Oil level		Х	Х				8 hours or before use
Crankcase breather hose		Х					Yearly or 500 hours
Change oil				Х			Yearly or 100 hours
Replace filter				Х			Yearly or 200 hours
Cooling	3.6						
Air ducts, louvers			Х		Х		Yearly
Exhaust Line	3.7						
Leakage		Х	Х				Weekly
Insulation, fire hazards		Х					Yearly
Obstructions or combustible materials near exhaust outlet		Х					Weekly
DC Electrical System	3.8						
Battery charger operation, charge rate (if equipped)		Х					Monthly
Remove corrosion, clean and dry battery and rack		Х			Х		Yearly
Clean and tighten battery terminals and inspect boots		Х	Х				Yearly
Battery electrolyte level and specific gravity *			Х				Yearly
AC Electrical System							
Tighten control and power wiring connections			Х				Yearly
Remote control system, if equipped						Х	Monthly
Visible wear or damage		Х					Quarterly
Wire abrasions where subject to motion		Х	Х				Six Months
Wire-cable insulation condition		Х					3 Years or 500 hours
Engine and Mounting							
Visible wear or damage		Х					Weekly
Air cleaner and precleaner service	3.5			R			Yearly or 100 hours
Spark plugs	3.4			Х			Yearly or 300 hours
Replace stepper motor coupling and bushing				D			500 hours
Generator							
Visible wear or damage	2.1	Х					Quarterly
Exercise generator set	2.3					Х	Weekly
Brushes and collector ring		D			D		Yearly
Measure and record resistance readings of windings with insulation tester (Megger®, with SCR assembly or rectifier and load leads disconnected)						D	3 Years
General Condition of Equipment							
Evidence of vibration, leakage, excessive noise, temperature, or deterioration		Х	X		Х		Weekly
Interior of sound enclosure		Х			X		Quarterly
* Not necessary for maintenance-free batteries.	ı	D Author X Action		outor/dealer ssary	1	1	,

Megger® is a registered trademark of Biddle Instruments.

3.3 Lubrication System

See Section 3.2, Service Schedule, for oil change and oil filter replacement intervals. See Section 1.5, Service Views, for the oil drain, oil check, oil fill, and oil filter locations. For extended operation, check the oil level every 8 hours. Maintain the oil level at or near, not over, the full mark on the dipstick.

3.3.1 Low Oil Pressure Shutdown

The low oil pressure shutdown feature protects the engine against internal damage if the oil pressure drops below 24.1 kPa ±13.8 kPa (3.5 psi ±1.5 psi) because of oil pump failure or other malfunction. The shutdown feature does not protect against damage caused by operating with the oil level below the safe range; it is not a low oil level shutdown. Check the oil level regularly, and add oil as needed.

Oil Check 3.3.2

The generator set is shipped with oil. Before operating a new generator set, check the engine oil in the crankcase. See Section 1.5, Generator Set Components. Verify that the oil level is at the F mark on the dipstick. Add oil that has a viscosity appropriate for See Section 3.3.3, Engine Oil the climate. Recommendation.

Do not check the oil level when the generator set is running. Shut down the generator set and wait several minutes before checking the oil level.

3.3.3 **Engine Oil Recommendation**

Use API (American Petroleum Institute) Service Class SG, SH, or SJ synthetic oil. Synthetic oil oxidizes and thickens less than other oils and leaves the engine intake valves and pistons cleaner. Select the viscosity based on the air temperature at the time of operation. See Figure 3-1.




Figure 3-1 Engine Oil Selection

3.3.4 Oil Change Procedure

Drain the oil while it is still warm.

1. Drain the oil.

- a. Place the generator set master switch in the OFF position.
- b. Disconnect the power to the battery charger.
- c. Disconnect the generator set engine starting battery, negative (-) lead first.
- d. Remove the housing side panel.
- e. Remove the oil drain hose from its retaining clip. Remove the cap from the oil drain hose and lower the hose into an oil collection container.
- f. Open the oil drain valve on the engine.
- g. Allow time for the engine oil to drain completely.
- h. Close the oil drain valve.
- i. Replace the cap on the oil drain hose. Replace the oil drain hose in its retaining clip.

2. Replace the oil filter.

- a. Remove the oil filter by rotating counterclockwise with an oil filter wrench.
- b. Clean the gasket sealing surface of the oil filter adapter.
- c. Apply a light coat of clean oil to the rubber seal of the new oil filter.
- d. Install the new oil filter following the instructions provided with the filter.

Note: Dispose of all waste materials (engine oil, fuel, filter, etc.) in an environmentally safe manner.

3. Fill with oil.

- a. Remove the oil fill cap and fill the engine to the F mark on the dipstick. The engine oil capacity is 1.9 L (2.0 gt.). See Section 3.3.3, Engine Oil Recommendation, for oil selection.
- b. Reinstall the dipstick and the oil fill cap.
- c. Check that the generator set master switch is in the OFF position.

- d. Reconnect the generator set engine starting battery, negative (-) lead last.
- e. Reconnect the power to the battery charger.
- f. Start and run the generator set for a minute to allow the oil pressure to reach the operating range.
- g. Stop the generator set, wait 1 minute, and then recheck the oil level. Add oil to bring the level up to the F mark on the dipstick.

4. Check for leaks.

- a. Check for oil leaks.
- b. Fix leaks and recheck the oil level.
- c. Reinstall the housing side panel.

3.4 Spark Plugs

Reset the spark plug gap or replace the plugs with new plugs as necessary.

- 1. Clean the area around the base of the spark plug to keep dirt and debris out of the engine.
- 2. Remove the spark plug and check its condition. Replace the spark plug if it is worn or if its reuse is questionable.
- 3. Check the spark plug gap using a wire feeler gauge. Adjust the gap to 0.76 mm (0.030 in.) by carefully bending the ground electrode. See Figure 3-2 and Figure 3-3.




Figure 3-2 Checking the Spark Plug Gap




Figure 3-3 Adjusting the Spark Plug Gap

3.5 Air Cleaner Element and Precleaner

The engine has a replaceable high-density paper air cleaner element with an oiled foam precleaner. See Figure 3-4.




Figure 3-4 Air Cleaner Components

Check for a buildup of dirt and debris around the air cleaner system. Keep this area clean.

Note: Operating the engine with loose or damaged air cleaner components could allow unfiltered air into the engine causing premature wear and failure.

3.5.1 Precleaner Service

Use the following procedure to wash and reoil the precleaner as indicated in the service schedule. Wash and reoil the precleaner more often under extremely dusty or dirty conditions.

- 1. Place the generator set master switch in the OFF/RESET position.
- 2. Disconnect the power to the battery charger.

- 3. Disconnect the battery, negative (-) lead first.
- 4. Loosen the cover retaining knob and remove the cover. Remove the precleaner from the paper element. Wash the precleaner in warm water with detergent. Rinse the precleaner thoroughly until all traces of detergent are eliminated. Squeeze out excess water (do not wring). Allow the precleaner to air dry.
- 5. Saturate the precleaner with new engine oil. Squeeze out all of the excess oil.
- 6. Reinstall the precleaner over the paper element.
- 7. Reinstall the air cleaner cover. Secure the cover with the cover retaining knob.
- 8. Reconnect the power to the battery charger.
- 9. Reconnect the generator set engine starting battery, negative (-) lead last.

3.5.2 **Paper Element Service**

Use the following procedure to replace the paper element at the intervals specified in the service schedule. Replace the paper element more often under extremely dusty or dirty conditions.

- 1. Place the generator set master switch in the OFF/ RESET position.
- 2. Disconnect the power to the battery charger.
- 3. Disconnect the generator set engine starting battery, negative (-) lead first.
- 4. Loosen the cover retaining knob and remove the cover.
- 5. Remove the element cover nut, element cover, and the paper element with precleaner.
- 6. Remove the precleaner from the paper element.

Note: Do not wash the paper element or clean it with pressurized air, as this will damage the element.

- 7. Replace the element if it is dirty, bent, or damaged.
- 8. Check the air cleaner base. Make sure it is secure and not bent or damaged. Also check the element cover for damage and fit. Replace all damaged air cleaner components. Remove any loose dirt or debris from the air cleaner base. Wipe the base carefully so that no dirt drops into the intake throat. Check the condition of the rubber seal on the air cleaner stud and replace the seal if necessary.

- 9. Reinstall the paper element, precleaner, element cover, element cover nut, and the air cleaner cover. Secure the cover with the cover retaining knob.
- 10. Reconnect the power to the battery charger.
- 11. Reconnect the generator set engine starting battery, negative (-) lead last.

3.6 Cooling System

The engine fan draws cooling air through the openings in the sides and end near the battery. The alternator fan draws cooling air through openings on the side walls of the enclosure. The cooling air mixes with the engine exhaust and is discharged at the exhaust outlet. See Figure 3-5. To prevent generator set damage caused by overheating, keep the housing cooling inlets and outlets clean and unobstructed at all times.

Note: Do not block the generator set cooling air inlets or other equipment above mount them. Overheating and severe generator damage may occur.




Figure 3-5 Cooling Air Intake and Exhaust

3.7 Exhaust System

Remove all combustible materials from the exhaust location. Combustible materials include building materials as well as natural surroundings. Keep dry field grass, foliage, and combustible landscaping material a minimum of 1.5 m (5 ft.) from the exhaust outlet.

Periodically inspect the exhaust system components (exhaust manifold, exhaust line, flexible exhaust, clamps, silencer, and outlet pipe) for cracks, leaks, and corrosion.

 Check for corroded or broken metal parts and replace them as needed.

- Check for loose, corroded, or missing clamps and hangers. Tighten or replace clamps and/or hangers as needed.
- Check for and remove loose insulation in the exhaust duct.
- Check that the exhaust outlet is clear.

3.8 Battery

▲ WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Refer to this section for general battery information and maintenance. Also consult the battery manufacturer's instructions for battery maintenance.

All generator set models use a negative ground with a 12-volt engine electrical system. Consult the generator set nameplate for the engine electrical system voltage. Consult the generator spec sheet for battery capacity recommendations for replacement purposes. Wiring diagrams provide battery connection information. See Figure 3-6 for typical battery connections.




Figure 3-6 12-Volt Engine Electrical System Single Starter Motor, Typical Battery Connection

Clean the battery and cables and tighten battery terminals using the service schedule recommendations. To prevent corrosion, maintain tight, dry electrical connections at the battery terminals. To remove corrosion from battery terminals, disconnect the cables from the battery and scrub the terminals with a wire brush. Clean the battery and cables with a solution of baking soda and water. After cleaning, flush the battery and cables with clean water and wipe them with a dry, lint-free cloth.

After reconnecting the battery cables, coat the battery terminals with petroleum jelly, silicone grease, or other nonconductive grease.

3.9 Battery Charger

The generator set is equipped with a 6-amp float/equalize battery charger to maintain the engine starting battery. The charger's DC leads are factorywired. Figure 3-7 illustrates the battery charger.

Periodically tighten all connections. maintenance on the battery charger is required.




Figure 3-7 6-Amp Float/Equalize Battery Charger

3.10 Circuit Protection

If the generator set circuit breaker trips or the fuses blow repeatedly, see Section 4, Troubleshooting, for possible causes.

3.10.1 Line Circuit Breaker

A line circuit breaker interrupts the generator output in the event of a fault in the wiring between the generator and the load. The line circuit breaker location is shown in Figure 1-1. See Figure 3-8 for the circuit breaker ratings. If the circuit breaker trips, reduce the load and switch the breaker back to the ON position. With the breaker in the OFF position the generator set runs but the generator output is disconnected from the load.

Model	Circuit Breaker Rating, Amps	
12RESM1/RE	SL 50	

Figure 3-8 Line Circuit Breakers

3.10.2 Fuses

Three fuses are located next to the generator set controller. The fuses are easily accessed from the service side of the generator set. See Figure 1-1 for the fuse location.

A 10-amp fuse in the battery charger DC lead protects the battery charger. See Section 2.5.

Always identify and correct the cause of a blown fuse before restarting the generator set. Refer to Section 4, Troubleshooting, for conditions that may indicate a blown fuse. Replace blown fuses with identical replacement parts. See Figure 3-9 for fuse ratings and part numbers.

Fuse	Label	Part Number	Location
Auxiliary winding	F1	292937	Lead 55
Relay interface board	F2	223316	Lead PF2
Controller	F3	223316	Lead PF1
Battery charger	_	AGS 10	Battery charger DC lead

Figure 3-9 Fuses

3.11 Storage Procedure

Perform the following storage procedure before removing the generator set from service for three months or longer. Follow the engine manufacturer's recommendations for storage, if available.

Note: Run the generator set monthly whenever possible.

3.11.1 Lubricating System

- 1. Operate the generator set until it reaches operating temperature, or about 15 minutes.
- 2. Stop the generator set.
- 3. While the engine is still warm, drain the engine lubrication oil from the engine crankcase.

- 4. Refill the engine crankcase with oil. See Section 3.3.3 for oil recommendations.
- 5. Run the generator set for a few minutes to distribute the clean oil.
- 6. Stop the generator set.

3.11.2 Fuel System

- 1. Start the generator set.
- 2. With the generator set running, shut off the gas supply.
- 3. Run the generator set until the engine stops.
- 4. Place the generator set master switch in the OFF/RESET position.

3.11.3 Cylinder Lubrication

- 1. Remove the spark plugs.
- 2. Pour one tablespoon of engine oil into each spark plug hole. Install the spark plugs and ground the spark plug leads. Do not connect the leads to the plugs.
- 3. Toggle the generator set master switch to crank the engine two or three revolutions to lubricate the cylinders.

3.11.4 Exterior Preparation

- 1. Clean the exterior surface of the generator set.
- 2. Seal all openings in the engine with nonabsorbent adhesive tape.
- 3. Mask all areas to be used for electrical contact.
- 4. Spread a light film of oil over unpainted metallic surfaces to prevent rust and corrosion.

3.11.5 Battery

Perform battery storage last.

- 1. Place the generator set master switch in the OFF/RESET position.
- 2. Disconnect the battery, negative (-) lead first.
- 3. Clean the battery. Refer to Section 3.8 for the cleaning procedure.
- 4. Place the battery in a warm, dry location.
- 5. Connect the battery to a float/equalize battery charger, or charge the battery monthly using a trickle charger. Follow the battery charger manufacturer's recommendations.

4.1 Introduction

Use the following charts to diagnose and correct common problems. First check for simple causes such as a dead engine starting battery, loose connections, or an open circuit breaker. The charts include a list of common problems, possible causes of the problem, and recommended corrective actions.

If the procedures in this manual do not explain how to correct the problem, contact an authorized distributor/ dealer for service. Maintain a record of repairs and adjustments performed on the equipment. Use the record to help describe the problem and repairs or adjustments made to the equipment.

4.2 Fault Codes

The Digital Control displays fault codes to aid in troubleshooting. Fault codes, descriptions, and recommended actions are listed in Figure 2-3.

Identify and correct the cause of the fault condition. Then reset the controller after a fault shutdown. See Section 2.4.3.

TP-6398 4/07 Section 4 Troubleshooting 27

4.3 Generator Set Troubleshooting

Figure 4-1 contains generator set troubleshooting, diagnostic, and repair information. Check for loose connections before replacing parts.

Problem	Possible Cause	Corrective Action		
The generator set does not crank.	Battery weak or dead	Check power to the battery charger. Recharge or replace the battery.		
	Battery charger fuse blown	Replace the fuse. Contact an authorized distributor/dealer for service if fuse blows repeatedly.		
	Battery connections reversed or poor	Check the connections.		
	Controller fuse (F3) blown	Replace the fuse. Contact an authorized distributor/dealer for service if fuse blows repeatedly.		
	Relay interface board fuse (F2) blown	Replace the fuse. Contact an authorized distributor/dealer for service if fuse blows repeatedly.		
	Generator set master switch in the OFF position	Move the master switch to the RUN position.		
The generator set	Air cleaner clogged	Clean and/or replace the air cleaner.		
cranks but does not start, starts hard, lacks power, or operates	Battery weak or dead	Check power to the battery charger. Recharge or replace the battery.		
erratically.	Battery connection poor	Clean and tighten the battery connections.		
-	Spark plug wire connection loose	Check the spark plug wires.		
	Low oil pressure shutdown	Check the oil level.		
	Fuel pressure insufficient	Check the fuel supply and valves.		
	Engine malfunction	Contact the distributor/dealer.		
No AC output.	AC circuit breaker in the OFF position	Place the circuit breaker in the ON position.		
	AC circuit breaker tripping because of overload	Reduce the load on the generator set.		
	AC circuit breaker tripping because of short circuit	Contact an authorized distributor/dealer for service.		
	Auxiliary winding fuse (F1) blown	Replace the fuse. Contact an authorized distributor/dealer for service if fuse blows repeatedly.		
Low output or excessive drop in voltage.	Generator set overloaded	Reduce the load.		
Generator set stops suddenly.	Fault shutdown, indicated by fault code on the controller display.	See Section 2.4.3.		
	No fuel to generator set	Check fuel supply and piping. Contact your fuel supplier.		
	Controller fuse (F3) blown	Replace the fuse. If the fuse blows again, contact the distributor/dealer.		
	Generator set master switch in the OFF/RESET position	Move the switch to the correct position (RUN or AUTO).		
	Remote stop command received from a remote switch or ATS	Check the remote switch position.		
	Engine malfunction	Contact the distributor/dealer.		
	Auxiliary winding fuse (F1) blown	Replace the fuse. Contact an authorized distributor/dealer for service if fuse blows repeatedly.		
Controller LED display	No power to the controller because:			
is off.	Controller fuse (F3) is blown.	Replace the fuse. If the fuse blows again, contact the distributor/dealer.		
	Battery voltage to controller is low or zero.	Check connections. Check generator set battery and battery charger. See Figure 4-2.		
	Generator set master switch is in the OFF/RESET position.	Move generator set master switch to the AUTO or RUN position.		
	Generator set master switch in AUTO but no start command has been received since last controller reset.	No action required (see Section 2.2.1). Controller display will activate when a remote start command is received or the generator set master switch is moved to the RUN position. Use the remote switch to start generator set and activate the controller display, if desired.		

Figure 4-1 General Troubleshooting Chart

28 Section 4 Troubleshooting TP-6398 4/07

4.4 Battery Charger Troubleshooting

Use the battery charger's LED indicators and the table in Figure 4-2 to troubleshoot battery charger operation problems.

Problem	Cause	Solution		
Red LED stays on for	One or more defective or damaged cells.	Load test the battery and replace, if necessary		
more than 24 hours.	Battery charger has reduced its output voltage below the normal level due to a DC overload or a DC short.	Remove the source of the overload or short. To test, disconnect the battery charger's black (NEGATIVE) ring terminal from the battery. Reapply AC power and the green LED only should now light.		
	Onboard DC systems are drawing more current than the battery charger can replace.	Turn off all DC equipment while charging.		
Red and green LEDs stay on for more than 24 hours.	Onboard DC systems are drawing between 1.5 and 5 amps.	Turn off all DC equipment while charging.		
	One or more defective or damaged battery cells.	Replace the battery.		
	Extremely low AC voltage at the battery charger.	Contact an authorized distributor/dealer.		
Green LED stays on	Open DC output fuse.	Replace AGS-10 fuse.		
when the battery is known to be low.	Faulty or contaminated terminal connections.	Clean and tighten or repair all terminal connections.		
	One or more defective or damaged battery cells.	Replace the battery.		
Neither of the LEDs turn on when the AC	No AC power available at the battery charger.	Connect AC power or reset the AC breaker on the main panel.		
power is applied.	Component failure.	Replace battery charger.		

Figure 4-2 Battery Charger Troubleshooting

TP-6398 4/07 Section 4 Troubleshooting 29

Notes

30 Section 4 Troubleshooting TP-6398 4/07

Appendix A Abbreviations

A, amp	ampere	cfh	cubic feet per hour	ES	engineering special,
ABDC	after bottom dead center	cfm	cubic feet per minute	E0D	engineered special
AC	alternating current	CG	center of gravity	ESD	electrostatic discharge
A/D	analog to digital	CID	cubic inch displacement	est.	estimated
ADC	advanced digital control;	CL	centerline	E-Stop	emergency stop
	analog to digital converter	cm	centimeter	etc.	et cetera (and so forth)
adj.	adjust, adjustment	CMOS	complementary metal oxide	exh.	exhaust
ADV	advertising dimensional		substrate (semiconductor)	ext.	external
۸h	drawing	cogen.	cogeneration	F	Fahrenheit, female
Ah	amp-hour	com	communications (port)	-	fiberglass
AHWT	anticipatory high water temperature	coml	commercial	FHM	flat head machine (screw)
AISI	American Iron and Steel		Commercial/Recreational	fl. oz.	fluid ounce
AIOI	Institute	conn.	connection	flex.	flexible
ALOP	anticipatory low oil pressure	cont.	continued	freq.	frequency
alt.	alternator	CPVC	chlorinated polyvinyl chloride	FS	full scale
AI	aluminum	crit.	critical	ft.	foot, feet
ANSI	American National Standards	CRT	cathode ray tube	ft. lb.	foot pounds (torque)
11101	Institute (formerly American	CSA	Canadian Standards	ft./min.	feet per minute
	Standards Association, ASA)	07	Association	ftp	file transfer protocol
AO	anticipatory only	CT	current transformer	g	gram
APDC	Air Pollution Control District	Cu	copper	ga.	gauge (meters, wire size)
API	American Petroleum Institute	cUL	Canadian Underwriter's	gal.	gallon
approx.	approximate, approximately	CUII	Laboratories	gen.	generator
AQMD	Air Quality Management District	CUL	Canadian Underwriter's Laboratories	genset	generator set
AR	as required, as requested	cu. in.	cubic inch	GFI	ground fault interrupter
AS	as supplied, as stated, as	CW.	clockwise	GND,	ground
	suggested ´	CW.		gov.	governor
ASE	American Society of Engineers		city water-cooled cylinder	gph	gallons per hour
ASME	American Society of	cyl.		gpm	gallons per minute
	Mechanical Engineers	D/A	digital to analog	gr.	grade, gross
assy.	assembly	DAC	digital to analog converter	GRD	equipment ground
ASTM	American Society for Testing	dB dB(A)	decibel	gr. wt.	gross weight
	Materials	dB(A)	decibel (A weighted)	•	height by width by depth
ATDC	after top dead center	DC	direct current	HC	hex cap
ATS	automatic transfer switch	DCR	direct current resistance	HCHT	high cylinder head temperature
auto.	automatic	deg., °	degree	HD	heavy duty
aux.	auxiliary	dept.	department	HET	high exhaust temp., high
avg.	average	DFMEA	Design Failure Mode and Effects Analysis	11-1	engine temp.
AVR	automatic voltage regulator	dia.	diameter	hex	hexagon
AWG	American Wire Gauge	DI/EO	dual inlet/end outlet	Hg	mercury (element)
AWM	appliance wiring material	DIN	Deutsches Institut fur Normung	НЙ	hex head
bat.	battery	DIN	e. V. (also Deutsche Industrie	HHC	hex head cap
BBDC	before bottom dead center		Normenausschuss)	HP	horsepower
ВС	battery charger, battery	DIP	dual inline package	hr.	hour
204	charging	DPDT	double-pole, double-throw	HS	heat shrink
BCA	battery charging alternator	DPST	double-pole, single-throw	hsg.	housing
BCI	Battery Council International	DS	disconnect switch	HVAC	heating, ventilation, and air
BDC	before dead center	DVR	digital voltage regulator	111710	conditioning
BHP	brake horsepower	E, emer.	emergency (power source)	HWT	high water temperature
blk.	black (paint color), block	ECM	electronic control module,	Hz	hertz (cycles per second)
hlle hte	(engine)	-	engine control module	IC	integrated circuit
blk. htr.	block heater	EDI	electronic data interchange	ID	inside diameter, identification
BMEP	brake mean effective pressure	EFR	emergency frequency relay	IEC	International Electrotechnical
bps	bits per second	e.g.	for example (exempli gratia)		Commission
br.	brass	EĞ	electronic governor	IEEE	Institute of Electrical and
BTDC	before top dead center	EGSA	Electrical Generating Systems		Electronics Engineers
Btu Dtu/main	British thermal unit		Association	IMS	improved motor starting
Btu/min.	British thermal units per minute	EIA	Electronic Industries	in.	inch
C	Celsius, centigrade		Association	in. H ₂ O	inches of water
cal.	calorie	EI/EO	end inlet/end outlet	in. Hg	inches of mercury
CAN	controller area network	EMI	electromagnetic interference	in. lb.	inch pounds
CARB	California Air Resources Board	emiss.	emission	Inc.	incorporated
	circuit breaker	eng.	engine	ind.	industrial
		ED.	Environmental Protection		
cc	cubic centimeter	EPA		int.	internal
cc CCA	cold cranking amps		Agency	int. int./ext.	internal internal/external
cc CCA ccw.	cold cranking amps counterclockwise	EPS	Agency emergency power system		
CB cc CCA ccw. CEC cert.	cold cranking amps		Agency	int./ext.	internal/external

TP-6398 4/07 Appendix 31

certificate, certification, certified

cert.

IP	iron pipe	ms	millisecond	RHM	round head machine (screw)
ISO	International Organization for	m/sec.	meters per second	rly.	relay
	Standardization	MTBF	mean time between failure	rms	root mean square
J	joule	MTBO	mean time between overhauls	rnd.	round
JIS	Japanese Industry Standard	mtg.	mounting	ROM	read only memory
k	kilo (1000)	MTU	Motoren-und Turbinen-Union	rot.	rotate, rotating
K	kelvin	MW	megawatt	rpm	revolutions per minute
kA	kiloampere	mW	milliwatt	RS	right side
KB	kilobyte (2 ¹⁰ bytes)	μF	microfarad	RTU	remote terminal unit
KBus	Kohler communication protocol	N, norm.	normal (power source)	RTV	room temperature vulcanization
kg	kilogram	NA	not available, not applicable	RW	read/write
kg/cm ²	kilograms per square	nat. gas	natural gas	SAE	Society of Automotive
	centimeter	NBS	National Bureau of Standards		Engineers
kgm	kilogram-meter	NC	normally closed	scfm	standard cubic feet per minute
kg/m ³	kilograms per cubic meter	NEC	National Electrical Code	SCR	silicon controlled rectifier
kHz	kilohertz	NEMA	National Electrical	s, sec.	second
kJ	kilojoule		Manufacturers Association	SI	Systeme international d'unites,
km	kilometer	NFPA	National Fire Protection		International System of Units
kOhm, kΩ	2 kilo-ohm		Association	SI/EO	side in/end out
kPa	kilopascal	Nm	newton meter	sil.	silencer
kph	kilometers per hour	NO	normally open	SN	serial number
kV	kilovolt	no., nos.	number, numbers	SNMP	simple network management
kVA	kilovolt ampere	NPS	National Pipe, Straight		protocol
kVAR	kilovolt ampere reactive	NPSC	National Pipe, Straight-coupling	SPDT	single-pole, double-throw
kW	kilowatt	NPT	National Standard taper pipe	SPST	single-pole, single-throw
kWh	kilowatt-hour		thread per general use	spec	specification
kWm	kilowatt mechanical	NPTF	National Pipe, Taper-Fine	specs	specification(s)
kWth	kilowatt-thermal	NR	not required, normal relay	sq.	square
L	liter	ns	nanosecond	sq. cm	square centimeter
LAN	local area network	OC	overcrank	sq. in.	square inch
		OD	outside diameter	SS	stainless steel
	l length by width by height	OEM	original equipment	std.	standard
lb.	pound, pounds	OLIVI	manufacturer	stl.	steel
lbm/ft ³	pounds mass per cubic feet	OF	overfrequency	tach.	tachometer
LCB	line circuit breaker	opt.	option, optional	TD	
LCD	liquid crystal display	OS	oversize, overspeed		time delay
ld. shd.	load shed	OSHA	Occupational Safety and Health	TDC	top dead center
LED	light emitting diode	OSHA	Administration	TDEC	time delay engine cooldown
Lph	liters per hour	OV	overvoltage	TDEN	time delay emergency to
Lpm	liters per minute	OZ.	ounce	TDEC	normal
LOP	low oil pressure			TDES	time delay engine start
LP	liquefied petroleum	p., pp. PC	page, pages personal computer	TDNE	time delay normal to
LPG	liquefied petroleum gas			TDOE	emergency
LS	left side	PCB	printed circuit board	TDOE	time delay off to emergency
L_{wa}	sound power level, A weighted	pF	picofarad	TDON	time delay off to normal
LWL	low water level	PF	power factor	temp.	temperature
LWT	low water temperature	ph., ∅	phase	term.	terminal
m	meter, milli (1/1000)	PHC	Phillips® head Crimptite®	THD	total harmonic distortion
M	mega (10 ⁶ when used with SI	D	(screw)	TIF	telephone influence factor
141	units), male	PHH	Phillips® hex head (screw)	TIR	total indicator reading
m ³	cubic meter	PHM	pan head machine (screw)	tol.	tolerance
m ³ /hr.	cubic meters per hour	PLC	programmable logic control	turbo.	turbocharger
m ³ /min.	cubic meters per minute	PMG	permanent magnet generator	typ.	typical (same in multiple
mA	milliampere	pot	potentiometer, potential		locations)
man.	manual	ppm	parts per million	UF	underfrequency
max.	maximum	PROM	programmable read-only	UHF	ultrahigh frequency
MB	megabyte (2 ²⁰ bytes)		memory	UL	Underwriter's Laboratories, Inc.
MCCB	molded-case circuit breaker	psi	pounds per square inch	UNC	unified coarse thread (was NC)
MCM		psig	pounds per square inch gauge	UNF	unified fine thread (was NF)
	one thousand circular mils	pt.	pint	univ.	universal
meggar	megohmmeter	PTC	positive temperature coefficient	US	undersize, underspeed
MHz	megahertz 	PTO	power takeoff	UV	ultraviolet, undervoltage
mi.	mile	PVC	polyvinyl chloride	V	volt
mil	one one-thousandth of an inch	qt.	quart, quarts	VAC	volts alternating current
min.	minimum, minute	qty.	quantity	VAR	voltampere reactive
misc.	miscellaneous	R	replacement (emergency)	VDC	volts direct current
MJ	megajoule		power source	VFD	vacuum fluorescent display
mJ	millijoule	rad.	radiator, radius	VGA	video graphics adapter
mm	millimeter	RAM	random access memory	VGA VHF	very high frequency
mOhm, m	Ωmilliohm	RDO	relay driver output	W	, , ,
MOlessa Mossa salassa		ref.	reference	w WCR	watt
MOV	metal oxide varistor	rem.	remote		withstand and closing rating
MPa	megapascal		Residential/Commercial	w/	with
mpg	miles per gallon	RFI	radio frequency interference	w/o	without
mph	miles per hour	RH	round head	wt.	weight
MS	military standard	1111	Todila Hoda	xfmr	transformer
-	•				

32 Appendix TP-6398 4/07

Notes

TP-6398 4/07 33

Notes

34 TP-6398 4/07

KOHLER POWER SYSTEMS

KOHLER CO. Kohler, Wisconsin 53044 Phone 920-565-3381, Fax 920-459-1646 For the nearest sales/service outlet in the US and Canada, phone 1-800-544-2444 KohlerPower.com

Kohler Power Systems Asia Pacific Headquarters 7 Jurong Pier Road Singapore 619159 Phone (65) 6264-6422, Fax (65) 6264-6455