

Operation

Software



OnCue™ Software

Models:

8.5/12RES equipped with the ADC-RES Controller
17/18RES equipped with the ADC-RES Controller
15/30RES equipped with the ADC 2100 Controller
15/30RYG equipped with the ADC 2100 Controller

KOHLER[®]
POWER SYSTEMS

9001
KOHLER
POWER SYSTEMS
NATIONALLY REGISTERED

TP-6616 7/09a

Table of Contents

Safety Precautions and Instructions	5
Introduction	7
Service Assistance	8
Section 1 System Requirements and Software Installation	9
1.1 OnCue Software	9
1.2 System Requirements	9
1.3 Network Bridge	9
1.4 Internet Configuration and Security	9
1.5 Software Installation	10
1.5.1 Microsoft .NET Framework	10
1.5.2 Device Installer	10
1.5.3 Kohler OnCue	10
Section 2 Software Configuration	13
2.1 Introduction	13
2.2 Start OnCue	13
2.3 Network Bridge Address or Domain Name and Password	15
2.3.1 Network Bridge Address or Domain Name	15
2.3.2 Network Bridge Passwords	17
2.3.3 Password Reset	17
2.4 Notification	18
2.4.1 Privacy Statement	18
2.4.2 Email Configuration	18
2.4.3 Disable Notification	20
2.4.4 Cellular Telephone SMS Text Message Configuration	20
2.5 Automatically Run OnCue	21
Section 3 Operation	23
3.1 Introduction	23
3.2 Program Description	23
3.2.1 OnCue Windows Service Module	23
3.2.2 OnCue User Interface	23
3.3 User Interface Screen	24
3.4 Operation Data	25
3.5 Fault Notification	25
3.5.1 Notification on the UI	25
3.5.2 Balloon Tip Messages	26
3.6 Remote Generator Set Control	26
3.6.1 Start/Stop Engine	26
3.6.2 Clear Faults	26
3.7 View History	27
3.8 Open/Close User Interface	27
Appendix A Abbreviations	29

Notes

Safety Precautions and Instructions

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. **SAVE THESE INSTRUCTIONS.**

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.

DANGER

Danger indicates the presence of a hazard that **will cause severe personal injury, death, or substantial property damage.**

WARNING

Warning indicates the presence of a hazard that **can cause severe personal injury, death, or substantial property damage.**

CAUTION

Caution indicates the presence of a hazard that **will or can cause minor personal injury or property damage.**

NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

Hazardous Voltage/ Moving Parts

DANGER



Hazardous voltage. Will cause severe injury or death.

Disconnect all power sources before opening the enclosure.

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), *not a direct short*, to ground.

Notes

This manual provides operation instructions for OnCue™ Software. OnCue software can be used with the following generator set models:

- 8.5RES with ADC-RES
- 12RES with ADC-RES
- 17RES with ADC-RES
- 18RES with ADC-RES
- 15RES with ADC 2100
- 30RES with ADC 2100
- 15RYG with ADC 2100
- 30RYG with ADC 2100

Note: OnCue™ software is designed for the generator set model and controller combinations shown above. OnCue™ software is not designed to work with other generator set models.

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual. Keep this manual with the equipment for future reference.

List of Related Literature

Figure 1 lists related literature.

Literature Type	Part Number
OnCue Specification Sheet	G6-98
OnCue Network Bridge Installation Instructions	TT-1486

Figure 1 Related Literature

Service Assistance

For professional advice on generator set power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KohlerPower.com.
- Look at the labels and stickers on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

Headquarters Europe, Middle East, Africa (EMEA)

Kohler Power Systems
3 rue de Brennus
93200 Saint Denis
France
Phone: (33) 1 49 178300
Fax: (33) 1 49 178301

Asia Pacific

Power Systems Asia Pacific Regional Office
Singapore, Republic of Singapore
Phone: (65) 6264-6422
Fax: (65) 6264-6455

China

North China Regional Office, Beijing
Phone: (86) 10 6518 7950
(86) 10 6518 7951
(86) 10 6518 7952
Fax: (86) 10 6518 7955

East China Regional Office, Shanghai
Phone: (86) 21 6288 0500
Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office
Bangalore, India
Phone: (91) 80 3366208
(91) 80 3366231
Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office
Tokyo, Japan
Phone: (813) 3440-4515
Fax: (813) 3440-2727

Latin America

Latin America Regional Office
Lakeland, Florida, USA
Phone: (863) 619-7568
Fax: (863) 701-7131

Section 1 System Requirements and Software Installation

1.1 OnCue Software

A personal computer (PC) running Kohler® OnCue™ software can communicate with the generator set models listed in the Introduction to monitor the generator set from any location with Internet access. With the correct password, you can also use the PC to signal the generator set controller to start or stop the engine or reset a fault.

The PC can be set up to automatically send email or text messages to notify selected recipients of generator set faults.

The generator set must be equipped with the OnCue™ network bridge, which allows connection of the generator set to the Internet through an Ethernet router and cable or DSL modem. See TT-1486 for network bridge installation, connection, and setup instructions.

1.2 System Requirements

OnCue™ software is designed to run on a personal computer (PC) connected to the Internet through a cable or DSL modem and an Ethernet router. The following items are the minimum requirements and recommendations for the computer system and related hardware.

- Personal computer (PC) with Microsoft® Windows Vista or Windows XP
- 512 MB RAM
- Up to 500 MB of available hard disk space may be required
- “Always-on” Internet service via DSL or cable modem
- Network bridge for generator set connection to the Ethernet. The network bridge is included with OnCue™ software kit.
- Ethernet router with a firewall for connection of the network bridge and one or more PCs to the modem. See router requirements, listed separately.
- An uninterruptible power supply (UPS) for the PC is strongly recommended.
- Network cable for connection of the network bridge to the Ethernet router (not included with the OnCue kit)

Microsoft®, Windows Vista®, and Windows XP® are registered trademarks of Microsoft Corporation.

Ethernet router requirements:

- Network Address Translation (NAT) is required to prevent Internet traffic from accessing the network bridge except as configured for OnCue.
- A wireless router (if used) should be encrypted to prevent untrusted devices from accessing your network bridge.

Requirements for remote access from a PC communicating over the Internet:

- The router must have port forwarding capability.
- One of two methods to identify the router is required:
 - The router should have dynamic DNS (domain name system) capability (check the router documentation), or
 - A static IP address for the Ethernet router may be obtained from the ISP (Internet service provider).
- When using OnCue from a remote location behind a firewall, it may be necessary to configure the firewall to open port 502. Contact your network administrator for assistance, if necessary.

1.3 Network Bridge

The network bridge is included in the OnCue™ software kit. See TT-1486, Installation Instructions, for instructions to install, connect, and configure the network bridge and other hardware. TT-1486 is included with the OnCue™ software kit.

1.4 Internet Configuration and Security

OnCue is designed to operate on a secure home network. Your network should have a router with a firewall that prevents unsolicited network traffic from accessing your network. If you have a wireless network, it should be encrypted to prevent unwanted access.

The network bridge does not secure the network connection used to configure its network address. The bridge does secure the network connection used to start, stop, and reset the generator and to change the bridge password. The bridge only encrypts the password (generator commands and status are not encrypted).

Internet router configuration

Your internet router must be configured to forward TCP port 502 to the network bridge attached to the genset. See TT-1486 and consult the documentation for your internet router for instructions to configure port forwarding.

PC configuration

If a firewall is running on your PC, the firewall may prompt you to allow OnCue to use port 502. You should allow the connection.

1.5 Software Installation

1.5.1 Microsoft .NET Framework

The OnCue software requires Microsoft® .NET framework 3.5. The .NET framework files are included on the OnCue CD-ROM. If the PC does not have the

required version of .NET Framework, the OnCue install program will install it and then prompt you to restart the PC.

1.5.2 Device Installer

Device Installer software is included on the OnCue CD-ROM. Device Installer is required for configuration of the J1939/Ethernet converter. See TT-1486.

1.5.3 Kohler OnCue

Note: You must have the Kohler J1939-Ethernet bridge configured with a valid IP address using Device Installer. See TT-1486 for instructions.

1. Insert the software CD-ROM into your PC's disk drive and allow it to start. The opening screen will appear. See Figure 1-1.
2. Click on OnCue™ Software.




Figure 1-1 CD Opening Screen

3. If the PC does not have the required version of .NET Framework, the OnCue install program will install it and then prompt you to restart the PC.
4. Read the license agreement, click the box to accept the terms in the license agreement, and click on the Install button. See Figure 1-2.

Note: See Section 2.4.1, Privacy Statement.

5. Wait for the program to install. A status screen shows the progress of the installation.
6. A new screen will appear when installation is complete. Click Finish.

Note: If a firewall is running on your PC, the firewall may prompt you to allow OnCue to use port 502. You should allow the connection.




Figure 1-2 Kohler OnCue Installation Screen with License Agreement

Notes

2.1 Introduction

This section contains instructions for configuration of communication settings on the PC and configuration of email and text messaging for fault notification.

Note: Before starting the OnCue™ software, use the Device Installer software provided with the OnCue kit to configure the network bridge. For instructions, refer to TT-1486, also provided with the kit.

2.2 Start OnCue

1. Start OnCue by clicking on Start > All Programs > Kohler OnCue. A new icon will appear in the lower right corner of the screen. See Figure 2-2.
2. Open OnCue by double-clicking on the OnCue icon in the lower right-hand corner of the screen.

The OnCue User Interface Window opens. See Figure 2-3.




Figure 2-1 Starting OnCue™






Figure 2-2 OnCue™ Icon



ADC 2100 User Interface



ADC-RES User Interface

tp6616

Figure 2-3 OnCue™ User Interface Window

2.3 Network Bridge Address or Domain Name and Password

OnCue™ may be installed on local and remote PCs. See Figure 2-5.

- A local PC is connected to the same Ethernet router as the network bridge. It communicates with the network bridge through the Ethernet router.
- A remote PC communicates with the network bridge and Ethernet router over the Internet. The remote PC must know the external IP address or domain name for the Ethernet router in order to establish a connection for communication.

2.3.1 Network Bridge Address or Domain Name

OnCue needs to know the IP address or domain name of the network bridge (for a local PC) or ethernet router (for a remote PC).

Note: Use Device Installer software to assign an IP address to the network bridge before running OnCue™. See instruction sheet TT-1486 provided with the OnCue™ kit.

1. Click on the top toolbar, Configure > Network Bridge Address and Password to open the Network Bridge and Password Setup window shown in Figure 2-4.




Figure 2-4 Configure Menu




Figure 2-5 Local and Remote PCs

2. Enter the IP address or domain name as shown in Figure 2-6.
 - a. If the PC and the network bridge are connected to the same Ethernet router, enter the IP address that was assigned to the network bridge using Device Installer software. See Figure 2-5 and TT-1486.
 - b. If the PC is a remote computer accessing the network bridge over the Internet, enter the external IP address or domain name of the ethernet router. See Figure 2-5 and TT-1486.

Note: For access by a remote PC, a static IP address OR a domain name with dynamic DNS is required for the Ethernet router. See TT-1486 and the router documentation for more information.




Figure 2-6 Network Bridge and Password Setup

3. Select one of the the password options. See Section 2.3.2 for more information.

Note: The default password does not allow remote control (start, stop, clear faults).

Selecting one of the options to change the password will reveal text boxes for the new password. See Figure 2-7.

Type the new password into the first box, then type it again in the second box for confirmation. Click on the Show Password box to see the password as you type, if desired.

Note: Passwords are case-sensitive. Check the Caps Lock key on your keyboard and be sure to note upper- and lower-case letters in your password.

Store your password in a secure location. OnCue™ cannot tell you the password.

4. Select the controller model: ADC 2100 or ADC-RES.
5. Click OK.




Figure 2-7 New Password Configuration

2.3.2 Network Bridge Passwords

A password is required for remote control of the generator set using OnCue. The password allows the PC to perform the following functions:

- Engine start
- Engine stop
- Clear faults (ADC 2100 controller only)

The password protects against the possibility of other computers equipped with OnCue software starting or stopping your generator set's engine or clearing faults from your generator set's controller.

Note: The factory default password will not allow remote control.

The network bridge is shipped from the factory with the factory default password. The PC operator must change the password on the network bridge and the PC to enable remote control of the generator set.

To change the password, click on Configure in the OnCue™ menu bar and select Network Bridge and Password Setup. Select from one of four options shown on the screen. See Figure 2-9.

Record the password and store it in a secure location.

Once the password has been set through the configuration screen, it does not need to be entered again unless it needs to be changed.

Password Selection	Description
Leave the password unchanged.	Select this option to connect to the network bridge without changing the password. Note: The factory default password will not allow remote control (start, stop, or clear faults from the PC).
Enter a new password for both the network bridge and PC.	Select this option to enter the password for the first time or after the password has been reset at the network bridge.
Change the password on both the network bridge and the PC.	Select this option to change an old password to something new. It is a good practice to periodically change your passwords for security purposes. This option is disabled if the password has not been changed from the default password.
Re-enter the current password on the PC only.	Changes the password on the PC but not on the network bridge. Select this option if you are connecting a new computer or a second computer, or if the password has somehow been deleted from the PC.

Figure 2-9 Password Choices

2.3.3 Password Reset

Use the password reset button on the network bridge if the password is lost or forgotten. See Figure 2-8 for the location of the password reset button.

To reset the network bridge password, use a bent paperclip or similar small tool to press and hold the password reset button for at least 10 seconds. The OnCue display will show Not Connected when the password resets. The password will be reset to the factory default password.

After resetting the password, follow the instructions in Section 2.3.1 to enter a new password to both the network bridge and the PC.




Figure 2-8 Network Bridge Password Reset Button

2.4 Notification

The OnCue™ program can be configured to send email or text messages alerting the recipient of generator set faults. Any local PC (connected to the router) or remote PC (connected over the Internet) running the OnCue program can be configured to send messages.

Email and text messages include:

- Date
- Time
- Location (user-defined)
- Engine runtime hours
- Description of the event (see below)

The following events will generate a message to all addresses in the recipients list:

- Auxiliary fault
- Battery voltage fault (high or low)
- High engine temperature fault
- Coolant fault (low coolant and loss of coolant, liquid-cooled engines only)
- Low oil pressure fault
- Overcrank fault
- Frequency fault (over or under)
- Overspeed fault
- Voltage fault (over or under)
- Communications fault
- Generator engine start
- Generator engine stop
- Fault cleared

There are two notification options:

- Email
- SMS Text Messaging

2.4.1 Privacy Statement

The OnCue™ system provides emails or electronic communications updating you on the status of your Kohler® generator and allowing you to monitor the unit remotely. These emails and text messages are routed through a Kohler-hosted server. In order to provide better service, Kohler may retain copies of these emails or electronic communications. These saved communications may include the sender's name, the sender's and recipients' email addresses, and generator information. Kohler Co. takes customer privacy very seriously and will take reasonable measures to keep the information secure.


Except in the limited circumstances described in this paragraph, Kohler Co. will not sell or share the collected information with unaffiliated third parties. We may disclose information if and when we believe it is necessary to comply with any law, rule, court order, or subpoena, or to enforce our legal rights, or to protect our business, property and operations.

Kohler Co. may update this policy at any time. The updated privacy policy will be posted on the Kohler Power Systems website, www.KohlerPower.com. If you have questions or concerns about this policy, please contact Kohler Co. by email at generatorfeedback@kohler.com, or call 1-800-544-2444.

By accepting the software licensing agreement, you are acknowledging your awareness of this privacy policy and granting Kohler Co. permission to save the information identified above.

2.4.2 Email Configuration

1. Configure notification options by opening the Notification Setup window:
Configure>Notification... See Figure 2-10.
2. Click on the Enable Notification checkbox to allow notification setup and to enable OnCue to send notifications to the addresses on the recipient list. A check mark appears in the box when enabled. No notifications will be sent if the checkbox is not checked.
3. Enter the information shown in Figure 2-11.
4. Enter the email address for new recipient to the Add field, and then click on the Add button.
5. To delete an Email address in the list, highlight the address to remove and click the Delete button.



6. After all recipients' email addresses have been added, send a test email to ensure that the notification settings have been configured properly.

- a. Click on Send Test E-mail to send a test message to all recipients on the list.
- b. Verify that all recipients received the test message from "OnCue Notification." See Figure 2-12 for a typical test message.
- c. If the test message was not received, check the email address entered into OnCue. Also instruct the recipient to check their spam email box or junk email box. It may be necessary for recipients to add the following email address to their email address book or "safe senders" list:

doNotReplyOnCueNotificationSystem@kohler.com

Figure 2-10 Notification Setup Window

Email Configuration Item	Description
Enable Notification	Check this box. Notification cannot be set up and notifications will not be sent if this box is not checked.
Sender Email Address	Enter the sender's email address (customer's email address). If a recipient replies to an OnCue notification message, the reply will be sent to this email address.
Sender Display Name	Enter a suitable display name (e.g. Kohler OnCue).
Location	Enter a name or address to identify the generator set location.
Recipient Address to Add	Enter recipient email addresses into the Email Address to Add field and click the Add button. Repeat this step for each email address to add. (This also applies for cell phone SMS text messaging. See additional information about SMS text messaging, below.)
Add button	Click Add after typing the recipient's address into the box to add it to the notification list.
Remove button	Select a name in the notification list and click Remove to delete it from the list.
Notification List	All recipients' addresses will appear here after they have been added using the Add button.

Figure 2-11 Email Configuration Information




Figure 2-12 Typical Test Message

2.4.3 Disable Notification

To stop sending messages, open the Notification Setup window and click on the Enable notification box so that the check mark disappears. Addresses in the notification list will appear greyed out but are not lost when notification is disabled.

2.4.4 Cellular Telephone SMS Text Message Configuration

SMS text messaging to a cellular telephone or other device is accomplished by sending an email to the cellular provider's email-to-SMS system. For example, if the customer is a subscriber of Verizon Wireless with the cellular telephone number 920-555-1212, a text message can be sent to their cell phone by sending an email to 9205551212@vtext.com.

Determine the customer's cellular telephone service provider and verify that their cell phone is equipped to receive SMS messages. Make sure that the customer is aware of any text messaging charges the cellular telephone provider may charge for received text messages.

The email address configuration for text messaging for several cellular telephone providers is shown in Figure 2-13. If the customer's provider is not shown below, please consult the provider or the provider's website for additional details.

As an example, the address for a text message to an Alltel cell phone with the number 212-555-1212 would be:

2125551212@message.alltel.com

Provider	Email Address Configuration for Text Messaging
Alltel	[10-digit phone number]@message.alltel.com
AT&T Wireless	[10-digit phone number]@mmode.com
Boost Mobile	[10-digit phone number]@myboostmobile.com
Cingular (now part of AT&T)	[10-digit phone number]@mobile.mycingular.com OR: [10-digit number]@cingularme.com
Nextel (now part of Sprint Nextel)	[10-digit phone number]@messaging.nextel.com
Sprint PCS (now Sprint Nextel)	[10-digit phone number]@messaging.sprintpcs.com
T-Mobile	[10-digit phone number]@tmomail.net
U.S. Cellular (http://www.uscellular.com)	[10-digit phone number]@email.uscc.net
Verizon (http://www.verizonwireless.com)	[10-digit phone number]@vtext.com
Virgin Mobile USA	[10-digit phone number]@vmobl.com

Figure 2-13 Email Address Configurations for Text Messaging

2.5 Automatically Run OnCue

Verify that the box next to Automatically Run OnCue When I Log Onto Windows is checked. This is the default setting. See Figure 2-14. When this feature is enabled, the OnCue™ icon will appear in your system tray whenever you are logged on to the PC, and balloon tip messages will appear on the screen if a fault condition is detected. Balloon tip fault messages appear only when the user interface screen is not displayed.




Figure 2-14 Automatically Run OnCue

If the Automatically Run feature is not selected, the user interface (UI) program will not start at login.

Note: The OnCue service runs, monitoring the generator set and sending notifications, even if the user interface program is not started.

If the user interface program does not run automatically at login, click Start>All Programs>Kohler OnCue to start the UI after logging onto the PC. See Figure 2-15.




Figure 2-15 Starting the UI from the Start menu

Notes

3.1 Introduction

The OnCue™ program automatically starts and runs immediately after installation on a personal computer (PC). The program monitors the generator set and generates messages even when the user interface is not displayed. After the program has been configured to send email and/or text messages, it will continue to send messages as long as the PC is turned on and connected to the Internet, even when you are not logged in.

Generator set engine start, engine stop, and fault messages are displayed on the user interface screen. If the user interface screen is closed or minimized, a balloon tip message will appear in the event of a generator set start, stop, or fault condition.

If the PC is turned off and then back on, the OnCue program starts automatically. However, if the Automatically Run OnCue feature in the Configure menu is not selected, the user interface portion of the program will not start automatically and balloon-tip notification at the PC will not be activated. See Section 2.5.

3.2 Program Description

The OnCue™ Generator Monitoring program is made up of two parts: the Windows service module and the user interface.

3.2.1 OnCue Windows Service Module

The OnCue Windows Service Module starts automatically when the program is installed and runs in the background. If the PC is turned off, the OnCue Windows Service Module starts automatically when the PC is turned back on. The Windows Service Module monitors the generator set operation and sends messages to the PC, email messages (if configured to send email messages), and text messages (if configured for text messaging) in the event of a generator set start, stop, or fault condition.

The windows service module continues to run as long as the computer is turned on, monitoring the generator set and sending email and text messages in the event of a generator set fault condition. Logging off does not stop the program. However, the PC must be on and connected to the Internet in order for the program to continue to monitor the generator set and send messages.

An uninterruptible power supply (UPS) for the PC, router, and modem is recommended to keep the PC

running and the program monitoring the generator set in the event of a power outage. When the utility power is lost, there may be a moment with no power before the generator set starts and provides emergency power. The PC could shut down during this time if not connected to a UPS.

3.2.2 OnCue User Interface

The OnCue User Interface (UI) is active only when the customer chooses to use it. The user interface allows the customer to view the generator set operation data, start or stop the engine, and clear faults. The user interface screen can be closed while the service module portion of the program continues to monitor the generator set status and send fault messages. In the event of a fault, a balloon tip message will be displayed on the PC even if the OnCue user interface screen is closed.

If the Automatically Run feature described in Section 2.5 is enabled, the user interface portion of the program starts at each login and displays an OnCue icon in the system tray. If the Automatically Run feature is not selected, the user interface program will not start at login. In that case, click Start>All Programs>Kohler OnCue to start the user interface program.




Figure 3-1 Starting the UI from the Start menu

3.3 User Interface Screen

The OnCue Windows Service Module runs in the background as long as the computer is running.

If the Automatically Run feature is enabled, the user interface portion of the program starts at each login and displays an OnCue icon in the system tray. If the OnCue user interface screen shown in Figure 3-2 is not displayed, open it by double-clicking on the OnCue icon

in the system tray at the lower right-hand corner of the screen.

Note: If automatic operation is turned off, the icon will not appear in the system tray after login. See Section 3.2.2.

In addition to the operation data display and operation buttons on the user interface screen, the menu bar at the top of the screen provides additional functions. See Sections 3.6.1 and 3.7.




Figure 3-2 OnCue™ User Interface Screen (ADC-RES interface shown with generator set running)

3.4 Operation Data

The user interface screen displays the generator set operation data on easy-to-read simulated gauges. See Figure 3-2. On all gauge displays, the green area marks the acceptable range of values when the generator set is running.

The following data are displayed. The generator set master switch must be in the AUTO or RUN position to communicate with OnCue so that data can be displayed.

- AC Voltage, in volts, is the output voltage of the generator set.
- Engine speed, in RPM, is indicated on the tachometer-style gauge.
- Engine hours, which is the total generator set run time, is displayed on the engine RPM gauge in the numerical display that resembles an automobile's odometer.
- Frequency, in Hz, is the frequency of the generator set output. The frequency will be 50 or 60 Hz when the generator set is running.
- Engine temperature is indicated on a display near the center of the user interface screen.

Note: Engine temperature data is displayed only for the ADC 2100 controller (ADC 2100 must be selected in the network bridge setup screen).

- Battery voltage, in volts DC, is the voltage of the engine starting battery.
- Fault active. A checkmark in a green circle near the lower left corner of the screen indicates no faults. A red circle indicates a fault shutdown. See Section 3.5 for fault descriptions.
- Engine is running/not running. A green symbol and Engine IS Running message indicate that the generator set is running. A yellow symbol and Engine IS NOT Running message indicate that the generator set is not running.
- Off. A red symbol and “Generator is Off” message indicate that the generator set has been turned off (the generator set master switch is in the OFF/RESET position). The gauges will all drop to zero when the master switch is off.
- Not connected. A red symbol and “Not Connected” message indicate that the PC is not successfully

communicating with the network bridge. Check network connections and battery power to the bridge (generator set engine starting battery).

3.5 Fault Notification

3.5.1 Notification on the UI

The user interface (UI) displays active faults. A checkmark in a green circle near the lower left corner of the screen indicates no faults. An X in a red circle indicates a fault shutdown. See Figure 3-3.

The type of fault is indicated using the descriptions below.

- Auxiliary Fault
- Battery Voltage Fault (high or low voltage)
- High Engine Temperature Fault
- Coolant Fault (low coolant level or loss of coolant)*
- Low Oil Pressure Fault
- Over Crank Fault
- Frequency Fault (over or under frequency)
- Over Speed Fault
- Voltage Fault (over or under voltage)
- Communications Fault

* Coolant Fault is not applicable to models with air-cooled engines, including the 8.5RES, 12RES, 17RES, and 18RES.




Figure 3-3 UI with Fault Message

3.5.2 Balloon Tip Messages

When the user interface (UI) is closed, OnCue™ continues to monitor the generator set. If a fault condition occurs when the UI is closed, a balloon tip message will describe the fault. See Figure 3-4.




Figure 3-4 Fault Message

3.6 Remote Generator Set Control

The Start Engine/Stop Engine button and Clear Faults button allow generator set control from a local or remote PC. The generator set master switch must be in AUTO position to allow remote control.

3.6.1 Start/Stop Engine

The Start Engine or Stop Engine button will appear depending on whether the generator set engine is running or not. See Figure 3-2. A message on the UI screen indicates *Engine IS Running* or *Engine IS NOT Running*. Press the Start Engine button to start the

generator set engine. Press the Stop Engine button to stop the generator set engine.

The start engine and stop engine commands are also accessible from the Operation menu at the top of the screen. See Figure 3-5. If the engine is not running, the Start Engine command is shown. When the engine is running, the Stop Engine command appears.




Figure 3-5 Operation Menu

3.6.2 Clear Faults

Click on the Clear Faults button to clear controller faults before attempting to restart the engine. The clear faults button is active only when a fault condition is detected.

The clear faults command is also accessible from the Operation menu at the top of the screen. See Figure 3-5.

Always identify and correct the cause of a fault shutdown before resetting the controller. See the generator set Operation Manual for more information about generator set faults and troubleshooting. Contact your local distributor/dealer for service.

3.7 View History

From the menu bar at the top of the user interface screen, click on View>History to see a list of time- and date-stamped events.

Click on View>Add History Comment to add notes to the history file, if desired.

To save the list to a file, click the Save button. The list will be saved to a text (.txt) file. A dialog box appears showing the filename and location where it will be saved. Change the file location and/or filename, if desired.

3.8 Open/Close User Interface

The user interface screen can be closed, if desired. Click on the Close button in the lower right corner of the user interface screen. The OnCue™ program continues to run in the background when the user interface screen is closed. The OnCue icon appears in the system tray as long as the program continues to run and monitor the generator set. Balloon tip messages will appear and messages will be sent if notification events occur when the user interface screen is closed.

To reopen the user interface screen, double-click on the OnCue icon in the system tray. See Figure 2-2. Another method is to right-click on the OnCue icon and then click on Open OnCue.

If it is necessary to stop the user interface program, rather than just closing the user interface screen, right-click on the OnCue icon in the system tray and click Exit. To restart the program after exiting this way, click Start>Programs>Kohler OnCue in the lower left corner of the screen.




Figure 3-6 Sample History

Notes

Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

A, amp	ampere	cfm	cubic feet per minute	exh.	exhaust
ABDC	after bottom dead center	CG	center of gravity	ext.	external
AC	alternating current	CID	cubic inch displacement	F	Fahrenheit, female
A/D	analog to digital	CL	centerline	FHM	flat head machine (screw)
ADC	advanced digital control; analog to digital converter	cm	centimeter	fl. oz.	fluid ounce
adj.	adjust, adjustment	CMOS	complementary metal oxide substrate (semiconductor)	flex.	flexible
ADV	advertising dimensional drawing	com	communications (port)	freq.	frequency
Ah	amp-hour	coml	commercial	FS	full scale
AHWT	anticipatory high water temperature	Coml/Rec	Commercial/Recreational connection	ft.	foot, feet
AISI	American Iron and Steel Institute	conn.	connection	ft. lb.	foot pounds (torque)
ALOP	anticipatory low oil pressure	cont.	continued	ft./min.	feet per minute
alt.	alternator	CPVC	chlorinated polyvinyl chloride	ftp	file transfer protocol
Al	aluminum	crit.	critical	g	gram
ANSI	American National Standards Institute (formerly American Standards Association, ASA)	CSA	Canadian Standards Association	ga.	gauge (meters, wire size)
AO	anticipatory only	CT	current transformer	gal.	gallon
APDC	Air Pollution Control District	Cu	copper	gen.	generator
API	American Petroleum Institute	cUL	Canadian Underwriter's Laboratories	genset	generator set
approx.	approximate, approximately	CUL	Canadian Underwriter's Laboratories	GFI	ground fault interrupter
APU	Auxiliary Power Unit	cu. in.	cubic inch	GND, ⊕	ground
AQMD	Air Quality Management District	cw.	clockwise	gov.	governor
AR	as required, as requested	CWC	city water-cooled	gph	gallons per hour
AS	as supplied, as stated, as suggested	cyl.	cylinder	gpm	gallons per minute
ASE	American Society of Engineers	D/A	digital to analog	gr.	grade, gross
ASME	American Society of Mechanical Engineers	DAC	digital to analog converter	GRD	equipment ground
assy.	assembly	dB	decibel	gr. wt.	gross weight
ASTM	American Society for Testing Materials	dB(A)	decibel (A weighted)	H x W x D	height by width by depth
ATDC	after top dead center	DC	direct current	HC	hex cap
ATS	automatic transfer switch	DCR	direct current resistance	HCHT	high cylinder head temperature
auto.	automatic	deg., °	degree	HD	heavy duty
aux.	auxiliary	dept.	department	HET	high exhaust temp., high engine temp.
avg.	average	dia.	diameter	hex	hexagon
AVR	automatic voltage regulator	DI/EO	dual inlet/end outlet	Hg	mercury (element)
AWG	American Wire Gauge	DIN	Deutsches Institut fur Normung e. V. (also Deutsche Industrie Normenausschuss)	HH	hex head
AWM	appliance wiring material	DIP	dual inline package	HHC	hex head cap
bat.	battery	DPDT	double-pole, double-throw	HP	horsepower
BBDC	before bottom dead center	DPST	double-pole, single-throw	hr.	hour
BC	battery charger, battery charging	DS	disconnect switch	HS	heat shrink
BCA	battery charging alternator	DVR	digital voltage regulator	hsg.	housing
BCI	Battery Council International	E ² PROM, EEPROM	electrically-erasable programmable read-only memory	HVAC	heating, ventilation, and air conditioning
BDC	before dead center	E, emer.	emergency (power source)	HWT	high water temperature
BHP	brake horsepower	ECM	electronic control module, engine control module	Hz	hertz (cycles per second)
blk.	black (paint color), block (engine)	EDI	electronic data interchange	IBC	International Building Code
blk. htr.	block heater	EFR	emergency frequency relay	IC	integrated circuit
BMEP	brake mean effective pressure	e.g.	for example (<i>exempli gratia</i>)	ID	inside diameter, identification
bps	bits per second	EG	electronic governor	IEC	International Electrotechnical Commission
br.	brass	EGSA	Electrical Generating Systems Association	IEEE	Institute of Electrical and Electronics Engineers
BTDC	before top dead center	EIA	Electronic Industries Association	IMS	improved motor starting
Btu	British thermal unit	EI/EO	end inlet/end outlet	in.	inch
Btu/min.	British thermal units per minute	EMI	electromagnetic interference	in. H ₂ O	inches of water
C	Celsius, centigrade	emiss.	emission	in. Hg	inches of mercury
cal.	calorie	eng.	engine	in. lb.	inch pounds
CAN	controller area network	EPA	Environmental Protection Agency	Inc.	incorporated
CARB	California Air Resources Board	EPS	emergency power system	ind.	industrial
CAT5	Category 5 (network cable)	ER	emergency relay	int.	internal
CB	circuit breaker	ES	engineering special, engineered special	int./ext.	internal/external
CC	crank cycle	ESD	electrostatic discharge	I/O	input/output
cc	cubic centimeter	est.	estimated	IP	internet protocol
CCA	cold cranking amps	E-Stop	emergency stop	ISO	International Organization for Standardization
ccw.	counterclockwise	etc.	et cetera (and so forth)	J	joule
CEC	Canadian Electrical Code			JIS	Japanese Industry Standard
cert.	certificate, certification, certified			k	kilo (1000)
cfh	cubic feet per hour			K	kelvin
				kA	kiloampere
				KB	kilobyte (2 ¹⁰ bytes)
				KBus	Kohler communication protocol
				kg	kilogram

kg/cm ²	kilograms per square centimeter	NBS	National Bureau of Standards	RTU	remote terminal unit
kgm	kilogram-meter	NC	normally closed	RTV	room temperature vulcanization
kg/m ³	kilograms per cubic meter	NEC	National Electrical Code	RW	read/write
kHz	kilohertz	NEMA	National Electrical Manufacturers Association	SAE	Society of Automotive Engineers
kJ	kilojoule	NFPA	National Fire Protection Association	scfm	standard cubic feet per minute
km	kilometer	Nm	newton meter	SCR	silicon controlled rectifier
kOhm, kΩ	kilo-ohm	NO	normally open	s, sec.	second
kPa	kilopascal	no., nos.	number, numbers	SI	<i>Systeme international d'unites</i> , International System of Units
kph	kilometers per hour	NPS	National Pipe, Straight	SI/EO	side in/end out
kV	kilovolt	NPSC	National Pipe, Straight-coupling	sil.	silencer
kVA	kilovolt ampere	NPT	National Standard taper pipe thread per general use	SMTP	simple mail transfer protocol
kVAR	kilovolt ampere reactive	NPTF	National Pipe, Taper-Fine	SN	serial number
kW	kilowatt	NR	not required, normal relay	SNMP	simple network management protocol
kWh	kilowatt-hour	ns	nanosecond	SPDT	single-pole, double-throw
kWm	kilowatt mechanical	OC	overcrank	SPST	single-pole, single-throw
kWth	kilowatt-thermal	OD	outside diameter	spec	specification
L	liter	OEM	original equipment manufacturer	specs	specification(s)
LAN	local area network	OF	overfrequency	sq.	square
L x W x H	length by width by height	opt.	option, optional	sq. cm	square centimeter
lb.	pound, pounds	OS	oversize, overspeed	sq. in.	square inch
lbm/ft ³	pounds mass per cubic feet	OSHA	Occupational Safety and Health Administration	SMS	short message service
LCB	line circuit breaker	OV	overvoltage	SS	stainless steel
LCD	liquid crystal display	oz.	ounce	std.	standard
LED	light emitting diode	p., pp.	page, pages	stl.	steel
Lph	liters per hour	PC	personal computer	tach.	tachometer
Lpm	liters per minute	PCB	printed circuit board	TB	terminal block
LOP	low oil pressure	pF	picofarad	TCP	transmission control protocol
LP	liquefied petroleum	PF	power factor	TD	time delay
LPG	liquefied petroleum gas	ph., ∅	phase	TDC	top dead center
LS	left side	PHC	Phillips® head Crimptite® (screw)	TDEC	time delay engine cooldown
L _{wa}	sound power level, A weighted	PHH	Phillips® hex head (screw)	TDEN	time delay emergency to normal
LWL	low water level	PHM	pan head machine (screw)	TDES	time delay engine start
LWT	low water temperature	PLC	programmable logic control	TDNE	time delay normal to emergency
m	meter, milli (1/1000)	PLC	programmable logic control	TDOE	time delay off to emergency
M	mega (10 ⁶ when used with SI units), male	PMG	permanent magnet generator	TDON	time delay off to normal
m ³	cubic meter	pot	potentiometer, potential	temp.	temperature
m ³ /hr.	cubic meters per hour	ppm	parts per million	term.	terminal
m ³ /min.	cubic meters per minute	PROM	programmable read-only memory	THD	total harmonic distortion
mA	milliampere	psi	pounds per square inch	TIF	telephone influence factor
man.	manual	psig	pounds per square inch gauge	tol.	tolerance
max.	maximum	pt.	pint	turbo.	turbocharger
MB	megabyte (2 ²⁰ bytes)	PTC	positive temperature coefficient	typ.	typical (same in multiple locations)
MCCB	molded-case circuit breaker	PTO	power takeoff	UF	underfrequency
MCM	one thousand circular mils	PVC	polyvinyl chloride	UHF	ultrahigh frequency
meggarr	megohmmeter	qt.	quart, quarts	UIF	user interface
MHz	megahertz	qty.	quantity	UL	Underwriter's Laboratories, Inc.
mi.	mile	R	replacement (emergency)	UNC	unified coarse thread (was NC)
mil	one one-thousandth of an inch	rad.	radiator, radius	UNF	unified fine thread (was NF)
min.	minimum, minute	RAM	random access memory	univ.	universal
misc.	miscellaneous	RDO	relay driver output	URL	uniform resource locator (web address)
MJ	megajoule	ref.	reference	US	undersize, underspeed
mJ	millijoule	rem.	remote	UV	ultraviolet, undervoltage
mm	millimeter	Res/Coml	Residential/Commercial	V	volt
mOhm, mΩ	milliohm	RFI	radio frequency interference	VAC	volts alternating current
MOhm, MΩ	megohm	RH	round head	VAR	voltampere reactive
MOV	metal oxide varistor	RHM	round head machine (screw)	VDC	volts direct current
MPa	megapascal	rly.	relay	VFD	vacuum fluorescent display
mpg	miles per gallon	rms	root mean square	VGA	video graphics adapter
mph	miles per hour	rnd.	round	VHF	very high frequency
MS	military standard	RO	read only	W	watt
ms	millisecond	ROM	read only memory	WCR	withstand and closing rating
m/sec.	meters per second	rot.	rotate, rotating	w/	with
mtg.	mounting	rpm	revolutions per minute	WO	write only
MTU	Motoren-und Turbinen-Union	RS	right side	w/o	without
MW	megawatt	RTDs	Resistance Temperature Detectors	wt.	weight
mW	milliwatt			xfrm	transformer
μF	microfarad				
N, norm.	normal (power source)				
NA	not available, not applicable				
nat. gas	natural gas				

TP-6616 7/09a

© 2009 by Kohler Co. All rights reserved.

KOHLER[®] POWER SYSTEMS

KOHLER CO. Kohler, Wisconsin 53044
Phone 920-565-3381, Fax 920-459-1646
For the nearest sales/service outlet in the
US and Canada, phone 1-800-544-2444
KohlerPower.com

Kohler Power Systems
Asia Pacific Headquarters
7 Jurong Pier Road
Singapore 619159
Phone (65) 6264-6422, Fax (65) 6264-6455