Service

Commercial Generator Sets



Models: COM7.5



KOHLER® POWER SYSTEMS_____

California Proposition 65



WARNING

Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Product Identification Information

Product identification numbers determine service parts. Record the product identification numbers in the spaces below immediately after unpacking the products so that the numbers are readily available for future reference. Record field-installed kit numbers after installing the kits.

Generator Set Identification Numbers

Record the product identification numbers from the generator set nameplate(s).

Model Designation _____

Specification Number _ Serial Number	
	Accessory Description
·	

Engine Identification

Record the product	identification	intormation	trom	tne
engine nameplate.				
Manufacturer				
Model Designation				
Serial Number				

Table of Contents

Product Identification	ion Inform	ation Inside front co	ver
Safety Precaution	s and Instr	uctions	- 1
Introduction			i
Maintenance and	Service Pa	rts	i
Service Assistance	e		ii
			1
-			
	-	m Description	1
-		ator Set Functional Description	1
1	•	ications	1
1	4 Servic	e Views	3
Section 2 Schedu	led Mainte	nance	5
2	1 Routin	e Maintenance	5
_		e Schedule	5
_		ation System	7
2	2.3.1	Oil Check	7
	2.3.1	Engine Oil Recommendation	7
	2.3.2	Oil Change Procedure	7
	2.3.4	Oil Cooler	8
	2.3.5	Low Oil Pressure Shutdown	8
		eaner Element and Precleaner	8
		y	9
2		n System	10
	2.6.1	Ignition System Description	10
	2.6.2	Spark Plug	10
2	7 Coolin	g System	10
2	8 Exhau	st System	10
2	9 Fuel S	System	10
	2.9.1	Gas Piping	10
2	10 Storag	ge Procedure	11
	2.10.1	Engine Oil	11
	2.10.2	Fuel	11
	2.10.3	Cylinder Lubrication	11
Section 3 General	Troublesh	nooting	13
		eshooting Chart	
3		ator Set/Controller System Troubleshooting Flowcharts	
_			
-		ng and Adjustment	23
	J	e Rectifier	23
4		onic Governor	24
	4.2.1	Governor Checks	24
	4.2.2	Stepper Motor Check	25
	-	r	26
4	Ū	n	26
4	5 Fuel S	system	26
	4.5.1	Fuel Regulators	27
	4.5.2	Fuel Solenoid Valve	27
	4.5.3	Fuel Conversion	27
	4.5.4	Fuel System Recalibration	28
4	6 Altern	ator	29
	4.6.1	Stator	29
	4.6.2	Rotor	30
4	7 Fault 9	Shutdown Switches	30

TP-6120 5/02 Table of Contents

Table of Contents, continued

Section 5	Controller (Operation	n and Test	31
	5.1	Controlle	er Operation	31
		5.1.1	Starting the Generator Set	31
		5.1.2	Stopping the Generator Set	31
		5.1.3	Remote Start/Stop Connections	32
		5.1.4	Control Connections	32
		5.1.5	Resetting the Controller	32
		5.1.6	Fault Shutdowns	33
	5.2	Fault Sh	utdown Tests	33
		5.2.1	Low Oil Pressure (LOP) Shutdown	34
		5.2.2	High Oil Temperature (HOT) Shutdown	34
		5.2.3	Overcrank Shutdown	34
		5.2.4	Overspeed Shutdown	34
	5.3	Control	Board Tests	35
		5.3.1	Fuel Control Circuit	35
		5.3.2	Speed Sensing and Governor (Throttle Control) Circuits	35
		5.3.3	Start Circuits	35
		5.3.4	Ignition Circuits	36
	5.4	Control	Board Replacement	36
Section 6	Disassemb	ly/Reass	embly	37
	6.1	COM7.5	Disassembly	37
		6.1.1	Generator Set Disconnection	37
		6.1.2	Alternator Disassembly	37
	6.2	COM7.5	Reassembly	39
		6.2.1	Alternator Reassembly	39
		6.2.2	Generator Set Connection	40
Section 7	Wiring Diag	ırams		41
Appendix A	A Abbrevia	tions		A-1
Appendix E	B Common	Hardwa	re Application Guidelines	A-3
Appendix (C General 7	Torque S	pecifications	A-4
Appendix [D Common	Hardwa	re Identification	Δ-5

Table of Contents TP-6120 5/02

Safety Precautions and Instructions

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. SAVE THESE INSTRUCTIONS.

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.



DANGER

Danger indicates the presence of a hazard that will cause severe personal injury, death, or substantial property damage.



WARNING

Warning indicates the presence of a hazard that *can cause severe personal injury, death,* or *substantial property damage*.



CAUTION

Caution indicates the presence of a hazard that *will* or *can cause minor personal injury* or *property damage*.

NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

generator Disabling the set. Accidental starting can cause severe injury or death. working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Place the generator set start/stop switch in the STOP (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

Battery

Α

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

A WARNING



Explosion.

Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. the battery before Disconnect generator installation Remove all jewelry maintenance. before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Engine Backfire/Flash Fire



Fire.
Can cause severe injury or death.

Do not smoke or permit flames or sparks near fuels or the fuel system.

Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner removed.

Combustible materials. A fire can cause severe injury or death. Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or for electrical fires or as recommended by the local fire code or an authorized agency. Train all fire extinguisher personnel on fire operation and prevention procedures.

Exhaust System



Carbon monoxide.

Can cause severe nausea, fainting, or death.

The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building unless the exhaust gas is piped safely outside. Never operate the generator set where exhaust gas could accumulate and seep back inside a potentially occupied building.

Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

Fuel System



Explosive fuel vapors.
Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

Gas fuel leaks. **Explosive fuel** vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LP vapor gas or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces per square (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

Hazardous Noise

A CAUTION



Hazardous noise. Can cause hearing loss.

Never operate the generator set without a muffler or with a faulty exhaust system.

Engine noise. Hazardous noise can cause hearing loss. Generator sets not equipped with sound enclosures can produce noise levels greater than 105 dBA. Prolonged exposure to noise levels greater than 85 dBA can cause permanent hearing loss. Wear hearing protection when near an operating generator set.

Hazardous Voltage/ Electrical Shock



Hazardous voltage. Can cause severe injury or death.

Only authorized personnel should open the enclosure.

(600 volts and under)



Operate the generator set only when all guards and electrical enclosures are in place.

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is Open the main circuit present. breakers of all power sources before servicing the equipment. Configure the installation to electrically ground the generator set and related equipment and electrical circuits to comply with applicable codes and standards. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

High voltage test. Hazardous voltage can cause severe injury or death. Follow the instructions of the test equipment manufacturer when performing high-voltage tests on the rotor or stator. An improper test procedure can damage equipment or lead to generator set failure.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Testing live electrical circuits. Hazardous voltage or current can cause severe injury or death. Have trained and qualified personnel take diagnostic measurements of live circuits. Use adequately rated test equipment with electrically insulated probes and follow the instructions of the test equipment manufacturer when performing voltage tests. Observe the following precautions when performing voltage tests: (1) Remove all jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Do not touch the enclosure or components inside the enclosure. (4) Be prepared for the system to operate automatically. (600 volts and under)

Hot Parts



Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

Servicing the generator. Hot parts can cause severe injury or death. Avoid touching the generator set field or exciter armature. When shorted, the generator set field and exciter armature become hot enough to cause severe burns.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Moving Parts



Rotating parts.
Can cause severe injury or death.

Operate the generator set only when all guards, screens, and covers are in place.

Tightening the hardware. Flying projectiles can cause severe injury or death. Loose hardware can cause the hardware or pulley to release from the generator set engine and can cause personal injury. Retorque all crankshaft and rotor hardware after servicing. Do not loosen the crankshaft hardware or rotor thrubolt when making adjustments or servicing the generator set. Rotate the crankshaft manually in a clockwise direction only. Turning the crankshaft bolt or rotor thrubolt counterclockwise can loosen the hardware.

Notice

NOTICE

Hardware damage. The engine and generator set may use both American Standard and metric hardware. Use the correct size tools to prevent rounding of the bolt heads and nuts.

NOTICE

When replacing hardware, do not substitute with inferior grade hardware. Screws and nuts are available in different hardness ratings. To indicate hardness, American Standard hardware uses a series of markings, and metric hardware uses a numeric system. Check the markings on the bolt heads and nuts for identification.

NOTICE

Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), not a direct short, to ground.

NOTICE

Fuse replacement. Replace fuses with fuses of the same ampere rating and type (for example: 3AB or 314, ceramic). Do not substitute clear glass-type fuses for ceramic fuses. Refer to the wiring diagram when the ampere rating is unknown or questionable.

This manual provides troubleshooting and repair instructions for model COM7.5 generator sets and controllers.

The generator set uses a Kohler® CH20 engine with a modified fuel system. Refer to the engine service manual for engine information not covered in this manual.

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual. Keep this manual with the equipment for future reference.

The equipment service requirements are very important to safe and efficient operation. Inspect the parts often and perform required service at the prescribed intervals. Maintenance and service must be performed by appropriately skilled and suitably trained maintenance personnel familiar with generator set operation and service.

Maintenance and Service Parts

Figure 1 lists some routine maintenance and service parts for your generator set. Parts Catalog TP-6091 provides a complete list of replacement parts.

Part Description	Part Number
Air Cleaner Foam Element	24 083 02
Air Cleaner Paper Element	24 083 08
Controller fuse	GM22466
Oil Filter	12 050 01
Spark Plug	12 132 02-S
Oxygen Sensor (service only)	A-345052

Figure 1 Maintenance and Service Parts

TP-6120 5/02 Introduction

Service Assistance

For professional advice on generator power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric
- Visit the Kohler Power Systems website at KohlerPowerSystems.com
- Look at the labels and stickers on your Kohler product or review the appropriate literature or documents included with the product
- Call toll free in the US and Canada 1-800-544-2444
- Outside the US and Canada, call the nearest regional office

Africa, Europe, Middle East

London Regional Office Langley, Slough, England Phone: (44) 1753-580-771 Fax: (44) 1753-580-036

Asia Pacific

Power Systems Asia Pacific Regional Office Singapore, Republic of Singapore

Phone: (65) 264-6422 Fax: (65) 264-6455

China

Fax:

North China Regional Office, Beijing

Phone: (86) 10 6518 7950 (86) 10 6518 7951

(86) 10 6518 7952 (86) 10 6518 7955

East China Regional Office, Shanghai

Phone: (86) 21 6288 0500 Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office Bangalore, India

Phone: (91) 80 3366208 (91) 80 3366231

Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office

Tokyo, Japan

Phone: (813) 3440-4515 Fax: (813) 3440-2727

Latin America

Latin America Regional Office Lakeland, Florida, USA Phone: (863) 619-7568 Fax: (863) 701-7131

X:in:008:001a

ii Service Assistance TP-6120 5/02

1.1 System Description

The COM7.5 generator set provides reliable backup DC power to cable TV systems or telecommunication sites in place of, or in addition to, batteries. The COM7.5 is available in 48 and 96 VDC models. The generator set nameplate indicates the unit's rated voltage.

The system batteries provide power at 48 or 96 volts. When power fails, the control system signals the generator set to start. The generator set provides DC power for continued or reserve operation of the system.

The COM7.5 generator set has both local and remote control capabilities. The unit runs on natural gas or LP vapor.

1.2 Generator Set Functional Description

The COM7.5 generator set system consists of the generator set (engine and generator) and the control system. The generator set provides regulated DC voltage to the telecommunications power system. The control system provides complete control of the engine and generator, accepts remote control commands, and delivers local and remote annunciation of unit status. Internal control functions include start and stop logic, fault monitoring, unit voltage control, engine speed (rpm) governing, and a local LED for fault annunciation.

Under very light loads, the generator set operates at low speed. As loads increase, the control system maintains constant generator output voltage by increasing the generator set engine speed.

The Kohler CH20 engine drives a direct-connected, variable-speed, 3-phase, voltage-specific generator to produce high-frequency AC power. A 3-phase, full-wave rectifier in the control system rectifies the output to produce low-ripple, unfiltered DC power.

1.3 Specifications

Figure 1-1, Figure 1-2, and Figure 1-3 contain generator set, alternator, and engine specifications. Refer to the scheduled maintenance section for service details.

Generator Set Specification	48 VDC	96V
Manufacturer	Koł	nler
Dimensions, L x W x H, mm (in.)	613 x 413 x 55 (24.1 x 16.3 x 21.8)	
Weight, dry, lb.	200	
Rated kW*	7.5	
Rated voltage (after rectifier)	52	104
Rated amps	144	72

^{*} Derate approximately 4% per 300 m (1000 ft.) over 153 m (500 ft.) above sea level. Derate 1% for each 5.5°C (10°F) increase in temperature above 25°C (77°F).

Figure 1-1 Generator Set Specifications

Alternator Specification	48 VDC 96 V		
Stator resistance, ohms	0.024	0.054	
Stator type	3-Phase, 3-Lead, Ungrounded		
Excitation method (rotor)	Permanent-Magnet, Brushless		
Coupling type	Direct-to-Engine		
Insulation (stator)	Class 155, Epoxy Varnish,		
	Vacuum-Impregnated		
Winding material	Copper		

Figure 1-2 Alternator Specifications

TP-6120 5/02 Section 1 Specifications

Engine Specification	Specification
Manufacturer	Kohler
Make/model	CH20
Cycle	4
Compression ratio	8.5:1
Displacement, cc (cu. in.)	398 (24.3)
Rated horsepower (using natural gas fuel)	13.1
Engine speed, rpm	2500-3650
Bore, mm (in.)	77 (3)
Stroke, mm (in.)	67 (2.64)
Valve train	Overhead Valve
Valve material:	
Intake	Steel
Exhaust	Stellite® Face
Number of cylinders	2
Cylinder block material	Aluminum w/Cast Iron Liners
Cylinder head material	Aluminum
Cylinder head tightening torque, Nm (ft. lb.)	41 (30)
Piston rings: quantity, type	2 Compression, 1 Oil
Crankshaft material	Heat Treated, Ductile Iron Casting
Bearings: quantity, type	2, Replaceable Sleeve
Governor	Electronic
Starter motor	Electric, Solenoid Shift
Lubrication system	Full Pressure
Oil capacity (with filter and cooler), L (qt.)	1.9 (2.0)
Oil type	Synthetic 5W-30
Oil filter tightening torque, Nm (in. lb.)	5.7-9.0 (50-80)
Oil pressure, kPa (psi)	172-241 (25-35)
Low oil pressure, kPa (psi)	24.1 ± 13.8 (3.5 ± 1.5)
Fuel type	Natural Gas or Propane
Fuel pressure, kPa (in. water column)	1.7 to 2.7 (7 to 11)
Fuel consumption at 7.5 kW:	
Natural gas, 1000 Btu/ft. ³	150 cfh
Propane, 2516 Btu/ft. ³	50 cfh
Battery voltage	12 VDC
Battery ground	Negative
Battery recommendation (minimum)	425 CCA at -18°C (0°F)
Spark plug type (Kohler Part No.)	24 132 03 (Champion RC12YC)
Spark plug gap, mm (in.)	0.75 (0.030)
Spark plug tightening torque, Nm (ft. lb.)	24.4-29.8 (18-22)
Ignition system	Capacitive Discharge
Cooling system	Air Cooled
High engine temperature, °C (°F)	152 (305)

Figure 1-3 Engine Specifications

2 Section 1 Specifications TP-6120 5/02

1.4 Service Views




Figure 1-4 COM7.5 Service Views

TP-6120 5/02 Section 1 Specifications 3

Notes

4 Section 1 Specifications TP-6120 5/02

WARNING



Accidental starting.
Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Place the generator set start/stop switch in the STOP position. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.



Hazardous voltage. Can cause severe injury or death.

Only authorized personnel should open the enclosure.

(600 volts and under)



Operate the generator set only when all guards and electrical enclosures are in place.

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Open the main circuit breakers of all power sources before servicing the equipment. Configure the installation to electrically ground the generator set and related equipment and electrical circuits to comply with applicable codes and standards. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.



Explosive fuel vapors.

Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

Gas fuel leaks. Explosive fuel vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LP vapor gas or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces per square inch (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

2.1 Routine Maintenance

Refer to the service schedule in the operation manual and the hourmeter located on the generator set to schedule routine maintenance. Perform maintenance on each item in the service schedule at the designated interval for the life of the generator set. Service units subject to extreme weather, long operating hours, or dusty or dirty conditions more frequently.

Refer to the operation manual for detailed maintenance information.

2.2 Service Schedule

Perform the service listed in Figure 2-1 at the designated intervals for the life of the generator set. Refer to the service views in Section 1.4 for system component locations.

TP-6120 5/02 Section 2 Scheduled Maintenance 5

		Procedure					
System Component or Procedure	See Section	Visually Inspect	Check	Change	Clean	Test	Frequency
Fuel	Coc Cocuon	шоросс		J			ricquency
Inspect flexible lines and connections. Replace cracked or spongy hoses. *	_	Х		R			Q
Check main LP tank supply level, if used.	_		Х				М
Inspect fuel piping for damage or corrosion.	_	Х					Υ
Lubrication							
Check oil level.	2.3.1	Х	Х				M or before use
Change oil.	2.3.2, 2.3.3			R			Y or 100 hr.
Replace oil filter.*	2.3.3, Intro Figure 1			R			Y or 200 hr.
Cooling							
Check that air ducts and louvers are clean and unobstructed.	2.7		Х		Х		Q
Exhaust System							
Check for leakage. Carbon or soot residue indicates a leak. Repair leaks.	2.8	Х	Х	R			Q
Check for fire hazards.	2.8	Х	Х		Х		Q
Check for loose or broken hangers and supports. Tighten or replace as needed.	_	Х	Х	R			S
Battery Connections							
Check battery charger operation and charge rate (if equipped).	Battery charger manual.	Х	Х				М
Clean and tighten battery terminals.		X	Х		Х		Υ
Remove corrosion, clean and dry battery and rack.		Х			Х		Y
Battery electrolyte level and specific gravity.†			Х				Q
Electrical System							
Inspect wiring and components for visible wear or damage.	_	Х					Q
Check for abrasions where wiring is subject to motion.	_	Х	Х				S
Check wiring for insulation breakdown.	_	Х	Х				Y
Tighten power and control wiring connections.	_		Х				Y
Engine And Mounting							
Inspect for visible wear or damage.	_	X					Q
Inspect air cleaner element; replace if necessary.*	2.4	Х		R			Y or 500
Inspect spark plugs; replace if necessary.* Control System	2.6.2	X		R			Y or 500
Check remote control operation.	Controller manufacturer's instructions.					Х	М
Generator Set							
Check items listed in the Prestart Checklist.	Operation Manual	Х					М
Exercise the generator set.	Operation Manual					Х	W
General Condition Of Equipment							
Check for signs of vibration, leakage, excessive noise, extreme temperature, or deterioration.	_	Х	х		Х		Q
Inspect and clean the enclosure interior.	_	Х			X		Q
* Consult your local distributor/dealer for parts or ser † Not necessary for maintenance-free batteries.	vice.	X Action R Repla	ce as neo	cessary			M=Monthly Q=Quarterly S=Six Months Y=Yearly No.=Hours of Running Time

Figure 2-1 Service Schedule

2.3 Lubrication System

See the service schedule in Section 2.2 for oil change and oil filter replacement intervals. See the Service Views in Section 1.4 for the oil drain, oil check, oil fill, and oil filter locations. The list of routine service parts in the Introduction of this manual shows the oil filter part number.




Figure 2-2 Lubrication System

2.3.1 Oil Check

Before operating a new generator set, check the engine oil in the crankcase. See Figure 2-2. Verify that the oil level is at the F mark on the dipstick. See Section 2.3.2 for engine oil recommendations.

Do not check the oil level when operating the generator set. To obtain the most accurate oil level reading, shut down the generator set and wait several minutes before checking the oil .

2.3.2 Engine Oil Recommendation

Kohler Co. recommends API (American Petroleum Institute) Service Class SF, SG, or SH 5W-30 synthetic oil. Synthetic oil oxidizes and thickens less than other oils and leaves fewer deposits on the engine intake valves and pistons.

2.3.3 Oil Change Procedure

Allow the oil to cool to a safe temperature before changing. See Figure 2-2.for the oil drain plug, filter, and fill tube locations.

- 1. Drain the oil.
 - a. Place an oil collection container below the oil drain and remove the oil drain plug.
 - b. Allow the engine oil to drain completely.
 - c. Replace the oil drain plug.
- 2. Replace the oil filter.
 - a. Place an oil collection container below the oil filter.
 - b. Remove the oil filter by rotating it counterclockwise with an oil filter wrench.
 - c. Clean the gasket sealing surface of the oil filter adapter.
 - d. Apply a light coat of clean oil to the rubber seal of the new oil filter.
 - e. Install the new oil filter following the instructions provided with the filter. Hand-tighten the filter.

Note: Dispose of all waste materials (engine oil, fuel, filter, etc.) in an environmentally safe manner.

- 3. Fill with oil.
 - a. Remove the oil fill cap and fill the engine to the F mark on the dipstick. The engine oil capacity is
 2.0 L (2.1 qt.). See Section 2.3.2 for oil selection.
 - b. Reinstall the dipstick and the oil fill cap.
- 4. Check for leaks.
 - a. Start and run the generator set to allow the oil pressure to reach the operating range.
 - b. Check for oil leaks around the oil filter and oil drain plug.
 - c. Stop the generator set and recheck the oil level. Tighten the oil filter to stop any leaks. Add oil to bring the level up to the F mark on the dipstick.
- Move the generator set master switch to the AUTO or center position to return the unit to standby service.

2.3.4 Oil Cooler

Use compressed air or a brush to clean the oil cooler fins after every 100 hours of operation (or more frequently if the generator set operates under dusty or dirty conditions). See Figure 2-2 for the oil cooler location.

2.3.5 Low Oil Pressure Shutdown

The low oil pressure shutdown feature protects the engine against internal damage if the oil pressure drops below a safe operating value because of oil pump failure or other malfunction. This shutdown feature does not protect against damage caused by operating with the oil level below the safe range—it is not a low oil level shutdown. Check the oil level regularly and add oil as needed.


2.4 Air Cleaner Element and Precleaner

The engine has a replaceable high-density paper air cleaner element with an oiled-foam precleaner. See Figure 2-3. Refer to the service views in Section 1.4 for the air cleaner's location. Follow the enclosure manufacturer's instructions to open the enclosure and gain access to the air cleaner.

Wash and oil the precleaner and replace the paper element at the intervals shown in the service schedule. Service the air cleaner more often if the generator set operates under dusty or dirty conditions. Refer to Maintenance and Service Parts in the Introduction section of this manual for replacement part numbers.

Keep the area around the air cleaner housing free of dirt and debris.

Note: Operating the engine with loose or damaged air cleaner components could allow unfiltered air into the engine, causing premature wear and failure.



Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner removed.




Figure 2-3 Air Cleaner Components

Air Cleaner Service Procedure

- 1. Disable the generator set.
 - a. Place the remote control switch in the OFF position.
 - b. Place the generator set master switch in the OFF/RESET position.
 - c. Disconnect the power to the battery charger, if equipped.
 - d. Disconnect the generator set engine starting battery, negative (-) lead first.
- 2. Remove the foam precleaner and paper element.
 - a. Loosen the air cleaner cover retaining knob and remove the cover.
 - b. Remove the element cover nut, element cover, and paper element with precleaner.
 - c. Remove the precleaner from the paper element.
- 3. Wash and oil the foam precleaner.
 - a. Wash the precleaner in warm soapy water.
 - Rinse the precleaner with warm water until the water runs clear.
 - c. Squeeze out excess water and allow the precleaner to air dry.

Note: Do not wring (twist) the precleaner or dry it with compressed air.

- d. Saturate the precleaner with new engine oil. Squeeze out the excess oil.
- 4. Replace the paper element if it is dirty, bent, or damaged.

Note: Do not wash the paper element or clean it with compressed air, as both will damage the element.

- 5. Reinstall the air cleaner.
 - a. Install the precleaner over the paper element.
 - b. Check the air cleaner base. Make sure it is secure and not bent or damaged. Remove any dirt or debris from the air cleaner base. Wipe the base carefully so that no dirt falls into the intake throat.

- c. Check the element cover for damage and fit. Replace all damaged air cleaner components. Check the condition of the rubber seal on the air cleaner stud and replace the seal if it is worn or damaged.
- d. Install the paper element, precleaner, element cover, element cover nut, and air cleaner cover.
 Secure the cover with the cover retaining knob (finger-tighten only).
- e. Check the element cover for damage and fit. Replace all damaged air cleaner components. Check the condition of the rubber seals and replace them if they are worn or damaged.
- f. Install the paper element, precleaner, and wing nut. Replace the short seal and the air cleaner cover. Secure the cover with the cover retaining knob (finger-tighten only).
- 6. Reconnect the generator set engine starting battery, negative (-) lead last.
- 7. Reconnect power to the battery charger, if equipped.

2.5 Battery

Use a starting battery that meets or exceeds the requirements shown in Section 1.3, Specifications. Follow the battery manufacturer's instructions for battery maintenance and service.

All generator set models use a negative ground with a 12-volt engine electrical system. See Figure 2-4 for the location of the ground connection.




Figure 2-4 Ground Connection

2.6 Ignition System

2.6.1 Ignition System Description

The COM7.5 engine uses a capacitive discharge ignition system. Refer to the CH20 Engine Service Manual for ignition service information.

Maintain the spark plugs using the instructions in Section 2.6.2.

2.6.2 Spark Plug

Reset the spark plug gap or replace the plug if necessary. Replace the plug at the intervals shown in the service schedule, Figure 2-1.

- 1. Clean the area around the base of the spark plug to keep dirt and debris out of the engine.
- Remove the spark plug and check its condition. Verify that the insulator is a light toast or gray color. Replace the spark plug if the insulator is discolored, the plug is coated with deposits, or the electrodes are pitted or worn.
- 3. Check the spark plug gap using a wire feeler gauge. Adjust the gap to 0.76 mm (0.030 in.) by carefully bending the ground electrode. See Figure 2-5 and Figure 2-6.




Figure 2-5 Checking the Spark Plug Gap




Figure 2-6 Adjusting the Spark Plug Gap

2.7 Cooling System

To prevent generator set damage caused by overheating, keep the housing cooling inlets and outlets clean and unobstructed at all times.

Note: Do not block the generator set cooling air inlet.

2.8 Exhaust System

Remove all combustible materials from the exhaust location. Combustible materials include building materials as well as natural surroundings. Keep dry field grass, foliage, and combustible landscaping material a safe distance from the exhaust outlet.

Periodically inspect the exhaust system components (exhaust manifold, exhaust line, flexible exhaust, clamps, silencer, and outlet pipe) for cracks and corrosion.

- Check for corroded or broken metal parts and replace as needed.
- Check for loose, corroded, or missing clamps and hangers. Tighten or replace clamps and/or hangers as needed.
- Check for and remove loose insulation in the exhaust duct.
- · Check that the exhaust outlet is clear.

2.9 Fuel System

2.9.1 Gas Piping

Ensure the gas pipe size meets size specifications in the chart. Measure the pipe length from the gas utility pressure regulator (7-11 in. water column output pressure) to the end of the pipe where it connects to the fuel inlet of the generator set. Compare the length with the chart in Figure 2-7. Replace piping longer than the listed maximum length with the specified pipe size.

Verify that the gas installer bleeds air from the gas lines at the time of installation.

Pipe Size	Maximum Pipe Length
1/2 in. NPT	3.0 m (10 ft.)
3/4 in. NPT	10.7 m (35 ft.)
1 in. NPT	30.5 m (100 ft.)

Figure 2-7 Maximum Gas Pipe Length

2.10 Storage Procedure

Perform the following steps if the generator set is out of service for three months or longer.

2.10.1 Engine Oil

- 1. Operate the generator set until it reaches operating temperature or about 15 minutes.
- 2. Stop the generator set.
- 3. While the engine is still warm, drain the engine lubrication oil from the engine crankcase.
- 4. Refill the engine crankcase with an oil having a viscosity appropriate for the particular climate.
- 5. Run the generator set for a few minutes to distribute the clean oil.
- 6. Stop the generator set.

2.10.2 Fuel

- 1. With the generator set running, shut off the gas
- 2. Run the generator set until the engine stops from lack of fuel.

2.10.3 Cylinder Lubrication

- 1. Remove the spark plugs.
- 2. Pour approximately one tablespoon of engine oil into each spark plug hole.
- 3. Crank the engine two or three revolutions to lubricate the cylinders.
- 4. Reinstall the spark plugs.

Notes

Section 3 General Troubleshooting

This section contains generator set troubleshooting and diagnostic information.

Use the following charts to diagnose and correct common problems. First check for simple causes such as a dead engine starting battery or loose connections.

Disconnect the generator set control board from the system controller and use the generator set master switch to operate the generator set. If the problem persists after the system controller is disconnected, use the troubleshooting procedures in this manual to diagnose the problem. If the generator set operates normally when the system controller is disconnected, the system controller may have sent a remote stop command or there may be a problem with the system controller. Instruct the customer to contact the system controller manufacturer for service information.

Note: Use an ohmmeter or continuity tester to check for shorts or open leads in the wiring harnesses before replacing the controller circuit board or other system components.

Follow the enclosure manufacturer's instructions to open or remove the enclosure, if necessary.

Maintain a record of repairs and adjustments performed on the equipment.



Accidental starting.
Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.


Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Place the generator set start/stop switch in the STOP position. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.




Hazardous voltage. Can cause severe injury or death.

Only authorized personnel should open the enclosure.

(600 volts and under)



Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Open the main circuit breakers of all power sources before servicing the equipment. Configure the installation to electrically ground the generator set and related equipment and electrical circuits to comply with applicable codes and standards. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.



Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

3.1 Troubleshooting Chart


The chart includes a list of common problems, possible causes, and recommended corrective actions.


Problem	Possible Cause	Corrective Action	Reference
Unit does not crank	Blown controller fuse	Check the fuse and replace if necessary.	Maintenance and Service Parts.
	Weak or dead battery	Recharge or replace the battery.	_
	Engine harness loose connection	Check and tighten connections.	_
	Start switch not in the AUTO position	Move the switch to AUTO.	_
	Controller interface harness disconnected	Reconnect the harness.	_
	Generator set controls are not receiving the remote start command	Check the controller interface harness connections and continuity. Troubleshoot the system controller.	System controller manufacturer's instructions
	Starter problem	Test the starter.	Section 4.3 and the Engine Service Manual, TP-2428-A
	Battery connections loose, dirty or incorrect	Correct, clean, or tighten battery connections.	_
	Fault shutdown	Identify and correct the cause of the fault. Reset the controller.	Section 5.1.6
	Controller board problem	Test the board as described in Section 5.3. Connect a spare control board to verify that the board needs to be replaced.	Sections 5.3 and 5.4.
Unit cranks but does	Air cleaner clogged	Clean or replace the air cleaner.	Section 2.4
not start	Fuel problem	Check the fuel supply and replenish if necessary.	_
		Verify that the fuel valve is open.	_
		Check that the fuel regulator opens.	Section 4.5.1
		Check that the throttle linkage moves freely and opens at start.	Section 4.2
		Check the fuel adjustment (oxygen sensor required for this test).	Section 4.5.4
		Check for the correct fuel and fuel block connection.	Section 4.5
	Faulty spark plug(s)	Replace or regap the spark plugs.	Section 2.6.2
	Loose spark plug wire connection	Reconnect and/or tighten spark plug wires.	_
	Ignition system problem	Test the ignition system.	Sections 5.3.4 and the Engine Service Manual
	Weak or dead battery	Recharge or replace the battery.	Section 2.5
Unit starts hard	Air cleaner clogged	Clean or replace the air cleaner element.	Section 2.4
	Faulty spark plug(s)	Replace or regap the spark plugs.	Section 2.6.2
	Ignition system problem	Test the ignition system and replace faulty components.	Engine Service Manual


Troubleshooting Chart (continued)


Problem	Possible Cause	Corrective Action	Reference
Unit stops suddenly	Air cleaner clogged	Clean or replace the air cleaner element.	Section 2.4
	Faulty spark plug(s)	Replace or regap the spark plugs.	Section 2.6.2
	Fuel starvation	Replenish fuel.	_
	Engine harness loose connection	Check and tighten connections.	_
	Fault shutdown	Check the controller LED. Correct the fault and reset controller. Test shutdown operation.	Sections 5.1.6 and 5.2
	Faulty shutdown switch	Test switches and replace if necessary.	Section 4.7
Unit lacks power or	Engine harness loose connection	Check and tighten connections.	_
operates erratically	Air cleaner clogged	Clean or replace the air cleaner element.	Section 2.4
	Insufficient cooling	Inspect and clean the cooling system.	Section 2.7
	Engine overload	Reduce the load on the generator set.	_
	Faulty spark plug	Replace or regap the spark plugs.	Section 2.6.2
	Fuel supply problem	Check the valves and fuel pressure.	Section 4.5
	Governor system problem	Check the governor and throttle linkage.	Section 4.2
Unit does not supply load	Fuel supply problem	Check for the correct fuel and fuel block connection.	Section 4.5
	Excessive load	Check that the load does not exceed the rating, 3.5 or 5 kW.	_
	Throttle linkage binding	Check that the throttle linkage is free to move and open while engine is running.	Section 4.2
	Undervoltage	Check that the voltage with no load matches the rating shown in Section 1.3, Specifications.	Section 1.3 and Section 4.1
Engine noise	Hydraulic lifter leakdown	Run the unit 5-10 minutes under load.	_
Unit overheats	Air openings clogged	Clean the intake and outlet openings.	Section 2.7
	Air cleaner clogged	Clean or replace the air cleaner element.	Section 2.4
	Overload	Verify that the load is within the specified range. Reduce load.	Section 1, Specifications


3.2 Generator Set/Controller System Troubleshooting Flowcharts











Unit Stops After Normal Operation Ε Possible intermittent wiring problem or control board malfunction. Check all wiring and components. Start the unit. Does it stop Done. after normal operation? Yes Is the controller Correct the fault and reset Yes fault LED lit? the controller. No Are alternator output leads Connect/repair/replace connected to AC terminals alternator output leads. on the rectifier? Yes Clean/replace Is air cleaner Yes air cleaner plugged? elements. Νo Are spark plug and Replace or regap spark No plugs. See Section 2.6.2. wires okay? Yes Are fuel solenoid Repair/replace No and wiring okay? fuel solenoid and/or wiring. Yes Is fuel adjustment Adjust the fuel No correct? See Section metering

valve.*

4.5.4.

Adjusting the fuel system may void the emissions certification. Only trained and authorized service technicians should adjust the fuel system. See Section 4.5.4.

Notes

Section 4 Component Testing and Adjustment

Use the troubleshooting procedures in Section 3 and the wiring diagrams in Section 7 to diagnose problems with the generator set operation. For controller operation and test, refer to Section 5 of this manual and to the system controller manual. Use the procedures in this section to check generator components for proper operation and adjust components when necessary. See the service views in Section 1.4 for component locations.



Hazardous voltage. Can cause severe injury or death.


Only authorized personnel should open the enclosure.


(600 volts and under)



Hazardous noise. Can cause hearing loss.

Never operate the generator set without a muffler or with a faulty exhaust system.





Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner removed.

4.1 **Voltage Rectifier**

The voltage rectifier converts AC voltage from the alternator into DC voltage. Figure 4-1 shows the rectifier schematic.

Refer to the wiring diagram in Section 7 for the rectifier Rectifier terminals 1-3 are the AC terminals. Leads AC1 and AC2 connect to the AC side of the rectifier and are used for speed sensing by the Terminal 4 is for the positive (+) DC connection and terminals 5 and 6 are for the negative (-) DC connections.

If there is no DC voltage at the output connector, check the output fuse. Test for output at the rectifier to check the output leads. Check for AC voltage into the rectifier. If there is AC voltage coming into the rectifier, but no DC output, replace the rectifier. The voltage rectifier has no adjustments.




Figure 4-1 Rectifier Schematic

The microprocessor controller monitors the DC output voltage. To verify accurate voltage control, increase and decrease loads while measuring DC output voltage at the output connector. The output voltage should remain fairly steady at the rated voltage as the engine speed increases or decreases in response to load changes.

If voltage falls below the rated value as load increases or decreases, check for the following problems:

- Inadequate fuel supply
- Fuel solenoid malfunction
- Fuel metering valve malfunction
- Stepper motor/throttle linkage binding

Electronic Governor 4.2

The system uses a variable-speed generator to maintain the rated output voltage with varying loads. The governor system regulates the engine speed with changing loads.

The governor system consists of an electronic governor control and an electromechanical actuator. Leads AC1 and AC2 provide a speed (frequency) signal from the AC side of the voltage rectifier to the control board. The control board signals the actuator, which controls the throttle and hence the engine speed, to maintain the generator nominal output voltage.

4.2.1 **Governor Checks**

The factory-set electronic governor does not normally require adjustment. If the engine operates erratically, check the following connections and conditions before adjusting the governor:

- Check the electrical connections and wire harnesses for clean, tight connections.
- Check the speed-sensing connections at rectifier AC terminals 2 and 3. Poor connections may cause an erratic signal, which could cause the unit to shut down.
- Check the electrical ground connections.

- Check the battery connections. Verify that the connections are clean and tight.
- Check for a good positive 12-volt DC supply.
- Check for stepper motor/throttle shaft linkage binding or wear. The linkage arm and lever arms must not bind or rub against other components while moving.
- Verify that the governor stepper motor operates with steady and smooth movement. If the movement of the stepper motor is erratic or large changes in movement occur, check for shaft misalignment, linkage binding, or loose or broken wiring or plug connections.
- Check the carburetor for dirt, grime, misadjustment. Check the idle-adjustment screw. The screw should not prevent the throttle plate from completely closing. Also, check the throttle linkage for any binding, dirt, damage, etc.

Note: Often hunting/surging problems thought to be caused by the governor are actually linked to carburetor adjustment. Check the carburetor adjustment before adjusting the governor.




Figure 4-2 Governor Location

The fuel shutoff solenoid deenergizes and the generator set shuts down with the following electronic governor faults:

- Loss of pickup while running (throttle moves to closed position)
- Engine overspeed
- Broken fuel shutoff solenoid lead
- Loss of DC power to governor assembly
- Broken stepper motor leads (erratic performance)
- Actuator linkage failure (erratic performance)

If none of the above conditions exist, proceed to Section 4.2.2, Stepper Motor Check.




Figure 4-3 Governor

4.2.2 **Stepper Motor Check**

Use the following procedure to test the operation of the governor stepper motor.

Stepper Motor Test Procedure

- 1. Stop the generator set and disconnect the battery.
- 2. Manually move the governor linkage fully counterclockwise (open throttle). See Figure 4-3.
- 3. Reconnect the battery. The stepper motor should move clockwise to the closed-throttle position with a noticeable clicking sound. If the stepper motor does not stay in the closed-throttle position, replace the stepper motor.

Only two stepper motor leads of each coil group are utilized (BLACK-YELLOW and RED-WHITE). The resistance per phase is 38.5 ohms. See Figure 4-4.




Figure 4-4 Actuator Coil Group

4.3 Starter

Check the starter if the generator set engine does not crank. Check the battery voltage and connections before proceeding. Check for a locked rotor or other fault condition that may have shut down the unit. Correct the fault condition and reset the controller to clear a fault shutdown.

Note: Always check the wiring and connections before replacing components.

The crank cycle attempts to start three times, cranking for 15 seconds and then resting for 15 seconds between attempts. The fault LED on the control board lights to indicate an overcrank shutdown; reset the controller if the LED lights during these tests.

Move the generator set master switch to Start and check for 12 VDC to the starter relay on lead 71 during the crank attempt. See Figure 4-5. If there is no voltage to the starter during the crank cycle, check the connections and the continuity of the wiring harness leads. Then check for voltage from the controller at P2-1 (see the wiring diagram, Section 7). If there is no voltage at P2-1 during cranking, replace the control board.




Figure 4-5 Starter Components

2. Starter relay (crank relay)


To test the starter relay, check for 12 VDC to the starter motor during the crank attempt. If there is voltage to the relay but not to the starter motor, check the connection between the relay and the starter motor. connection is good, replace the relay.

If there is voltage to the starter motor but the starter motor does not crank the engine, refer to the Kohler CH20 Engine Service Manual for starter service information. The generator set engine uses a solenoid shift electric starter.

Ignition 4.4

The COM7.5 engine uses a capacitive discharge ignition system. Refer to the Engine Service Manual for ignition service information. See Section 2.6 of this manual for spark plug information.

4.5 Fuel System



Explosive fuel vapors. Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.



Do not smoke or permit flames or sparks near fuels or the fuel system.

Combustible materials. A fire can cause severe injury or death. Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or BC for electrical fires or as recommended by the local fire code or an authorized agency. Train all personnel on fire extinguisher operation and fire prevention procedures.

4.5.1 **Fuel Regulators**

The typical gaseous fuel system uses two regulators. The primary regulator reduces the line pressure to an allowable inlet pressure for the secondary regulator. The fuel supplier provides and maintains the primary regulator. The secondary regulator is factory-installed on the generator set and is designed for a maximum inlet pressure of 2.7 kPa (6 oz./in.2) or 280 mm (11 in. water column).

Do not try to adjust the fuel pressure, fuel mixture, or engine speed using the fuel lock-off. See Figure 4-6 for the location of the fuel lock-off. The fuel lock-off prevents fuel flow when the engine is not operating.

Checking the Fuel Pressure

Use a gauge or manometer to check the fuel pressure at the secondary regulator inlet. See Figure 4-6. Measure the fuel pressure with the generator set running at full load. The fuel pressure should be 178-280 mm (7-11 in. water column) or 1.7-2.7 kPa (4-6 oz./in.2). Contact the fuel supplier if the inlet pressure is not within the specified range.

Note: Do not attempt to adjust the fuel mixture or engine speed by adjusting the regulators.




Figure 4-6 Secondary Regulator (with fuel block)

Fuel Solenoid Valve 4.5.2

The fuel solenoid valve is a 12 VDC valve energized by lead 70 when the generator set controller is in the crank or the run mode. The fuel solenoid valve is supplied by the enclosure manufacturer.

4.5.3 **Fuel Conversion**

A dual-fuel block with two fuel metering valves allows field conversion between natural gas and LP vapor. Have the fuel conversion procedure performed by trained and qualified personnel.

Note: The fuel metering valves are factory-sealed to comply with applicable emission standards and to provide the best possible hot and cold starting.

The manufacturer ships the generator set with the fuel system set for natural gas. To convert to LP gas, use the following procedure to move the fuel line from the natural gas outlet port to the LP outlet port in the dual-fuel block (or from the LP outlet to the natural gas outlet to convert from LP to natural gas). See Figure 4-7 for the LP and natural gas fuel connection and fuel block locations. Also see the service views in Section 1.4.




Figure 4-7 Fuel System (shown mounted on the shipping bracket)

Fuel Conversion Procedure

- 1. Move the remote start/stop switch to the STOP position.
- 2. Follow the enclosure manufacturer's instructions to open the enclosure to gain access to the fuel system.
- 3. Verify that the generator set master switch is in the STOP position.
- 4. Disconnect power to the battery charger, if equipped.
- 5. Disconnect the battery, negative (-) lead first.
- 6. Turn off the fuel supply.
- 7. Remove the hose clamp and fuel line hose from the fitting in the fuel block.
- 8. Remove the hose fitting from the natural gas (or LP) outlet in the fuel block.
- 9. Remove the plug from the LP (or natural gas) inlet. Clean the plug with a dry cloth or brush, apply fresh pipe sealant, and install the plug into the natural gas (or LP) outlet.
- 10. Clean the hose fitting with a dry cloth or brush, apply fresh pipe sealant, and install the fitting into the LP (or natural gas) inlet.
- 11. Slide the hose onto the hose fitting and secure the hose with the clamp.
- 12. Turn on the fuel supply and check for leaks using a gas leak detector.
- 13. Reconnect the battery cable and harness.
- 14. Follow the enclosure manufacturer's instructions to close the enclosure.

4.5.4 **Fuel System Recalibration**

The fuel metering valves are factory-set to meet emissions requirements and sealed to discourage field adjustments. If the fuel system requires recalibration, only trained, authorized service technicians may adjust the fuel metering valves. Always use an oxygen sensor, available from Kohler Co., when adjusting the fuel metering valves. See Maintenance and Service Parts in this manual for the sensor part number.

Note: Changing the fuel system adjustments may void the emissions certification.



Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Fuel System Recalibration Procedure

- 1. Remove the plug from the oxygen sensor port in the exhaust tube and install the oxygen sensor. See Figure 4-8.
- 2. Run the generator set at full load and check the oxygen sensor reading. At full load, the oxygen sensor output voltage should be between 0.45 and 0.55 VDC.
- 3. If adjustment is required, remove the seal on the fuel metering valve and adjust the valve to obtain an oxygen sensor reading between 0.45 and 0.55 VDC. See Figure 4-6 for the fuel metering valve location.
- 4. Reseal the valve after adjustment.
- 5. Allow the exhaust system to cool. Remove the oxygen sensor from the exhaust tube and reinstall the plug.




Figure 4-8 Oxygen Sensor Port Location

4.6 Alternator

The alternator is connected directly to the engine. The alternator uses a permanent-magnet rotor and a 3-lead, 3-phase stator. See Figure 4-9.

4.6.1 Stator

The stator contains coils of wire laid in a laminated steel frame. The three stator leads are connected together in a wye configuration. See Figure 4-10.

The stator leads supply voltage to the voltage rectifier and the speed-sensing circuit. Before testing, inspect the stator for heat discoloration, visible damage to housing lead wires, exposed coil windings, or exposed areas of frame laminations. Use an ohmmeter to check the continuity of the stator windings using the following procedure.




Figure 4-9 Alternator (end bracket removed)




Figure 4-10 Stator Windings

Stator Test Procedure

- 1. Disconnect the power to the battery charger, if equipped.
- 2. Disconnect the generator set engine starting battery, negative (-) lead first.
- 3. Disconnect the stator leads from the voltage rectifier.

Note: Disconnect all stator leads from the voltage rectifier before performing the test.

- 4. Set the ohmmeter on the R x 1 scale. Touch the ohmmeter leads together and adjust the ohmmeter to show zero ohms.
- 5. Check the cold resistance of the stator windings by connecting the meter leads to stator leads 1 and 2, 1 and 3, and 2 and 3. See Figure 4-11 for stator winding resistance values. Replace the stator if any of the resistance checks reveal an open winding.

Note: Most ohmmeters do not measure very small resistance values accurately. Check for continuity of the windings with no shorts to The stator is functional if the ground. resistance reading is low (indicating continuity) and there is no evidence (heat discoloration) of shorted windings.

Generator Set Voltage Rating, VDC	Stator Resistance, Ohms	
48	0.024	
96	0.054	

Figure 4-11 Stator Resistance

- 6. If the resistance test in the previous step is not conclusive, perform a megohmmeter test to determine whether the stator is shorted to ground.
 - a. Use a megohmmeter to apply 500 volts DC to any stator lead and the stator's frame. Follow the instructions of the megohmmeter's manufacturer when performing this test. A of approximately 500 kOhms reading (1/2 mOhm) or higher indicates that the stator is in good condition. A reading of less than approximately 500 kOhms (1/2 MOhm) indicates deterioration of the winding insulation and possible current flow to ground.
 - b. If the megohmmeter reading is less than 500 kOhms, replace the stator.

4.6.2 Rotor

The rotor uses permanent magnets. There are no tests or field adjustments for the rotor.

Fault Shutdown Switches 4.7

Check the continuity of the high oil temperature (HOT) and low oil pressure (LOP) switches. Check for loose connections and open or short circuits in the connecting wires before replacing the switches.

High Oil Temperature (HOT) Switch

The HOT switch is normally open. Shut down the generator set and allow the engine to cool. Use an ohmmeter to measure the resistance from pin P1-18 of the engine harness (lead 37) to ground. The ohmmeter should indicate an open circuit. Any other reading indicates a short; replace the HOT switch.




Figure 4-12 High Oil Temperature (HOT) Switch

Low Oil Pressure (LOP) Switch

The normally closed LOP switch opens when the engine oil pressure reaches the normal operating level and closes if the oil pressure drops below a preset minimum. Use an ohmmeter to check the continuity between pin P1-17 of the engine harness (lead 13) and ground. Verify that the switch is closed while the engine is stopped. Start the generator set and check that the switch opens approximately 5 seconds later. If the switch does not open after the engine reaches normal operating speed, check the oil level and test for leaks in the lubrication system before replacing the LOP switch.




Figure 4-13 Low Oil Pressure (LOP)Switch

Section 5 Controller Operation and Test

This section describes troubleshooting procedures for the generator set control board, shown in Figure 5-1. Refer to the operation manual for operating instructions. Refer to the remote controller manufacturer's instructions for troubleshooting and servicing remote controllers connected to the generator set.

Controller Operation 5.1

Microprocessor-based controls provide complete control of the engine and generator. The control system accepts remote control inputs for generator start and run and delivers remote annunciation of unit status and faults. Internal functions of the controls include start and stop logic, fault monitoring, generator voltage and engine speed governing, and fault annunciation through a common fault LED. See Figure 5-1 for the control board component locations.




Figure 5-1 Generator Set Controls

Generator set master switch. A three-position generator set master switch on the control board allows local or remote control of the generator set. Momentary RUN and STOP positions provide local control of the generator set. The STOP position also resets controller faults. The generator set master switch moves to the AUTO position when released, allowing a remote device to start and stop the generator set. See Section 5.1.3 for remote start/stop connection information.

5.1.1 Starting the Generator Set

The following procedures describe the actions required to start the generator set.

Reset the controller by moving the generator set master switch to the STOP position after applying battery voltage for the first time or after a voltage interruption.

Local Starting. Move the generator set master switch to the RUN position and release it to immediately start the generator set.

Remote Starting. With the generator set master switch in the AUTO position, close a contact between pins 5 (STT) and 6 (N) on the controller harness connector to start the generator set.

Note: The control board provides up to 75 seconds of cyclic cranking before overcrank shutdown After a fault shutdown, reset the controller by moving the generator set master switch to the STOP position.

At initial startup, the engine's hydraulic lifters may produce a metallic clicking sound. This is caused by the hydraulic lifter leakdown during storage. Run the generator for 5 minutes. The noise will normally cease in the first minute.

5.1.2 **Stopping the Generator Set**

The following procedures describe the actions required to stop the generator set.

Local Stopping. Move the generator set master switch to the STOP position and release it. The generator set stops immediately.

Note: When the generator set master switch is released, it returns to the AUTO position. A start command from a remote control board can restart the generator set when the switch is in AUTO.

Remote Stopping. With the generator set master switch in the AUTO position, close a remote contact between pins 6 (N) and 7 (STP) on the controller harness connector.

5.1.3 **Remote Start/Stop Connections**

Set the generator set master switch to the AUTO position for remote operation. For remote starting and stopping, use a three-wire start/stop switch connected to the controller harness. To start the generator set, open a contact between pins 6 (N) and 7 (STT) on the controller harness connector and close a contact between connector pins 5 (STP) and 6 (N) (see the wiring diagram in Section 7). Close the contact between pins 6 and 7 to stop the generator set.

5.1.4 **Control Connections**

Wiring harnesses connect the generator set control board to the remote controls and the engine. The generator set Operation Manual, TP-6119, shows the engine, sensing, and controller wiring harnesses. The wiring diagram in Section 7 shows the harness connections. Figure 5-2 defines the abbreviations used in the wiring diagram.

5.1.5 Resetting the Controller

Move the generator set master switch to the STOP position and then release it to reset the controller. Reset the controller after applying power for the first time or to clear a fault condition. See Section 5.1.6 for more information about faults.

Note: If the power to the controller has been disconnected and reconnected, the controller will require resetting.

Abbreviation	Definition
70	Run
71	Crank
AC1	Speed sensing
AC2	Speed sensing
BCA	Battery charging alternator
DCN	DC negative
DCP	DC positive
EBG	Engine block ground
GV	Gas valve
HOT	High oil temperature switch
HR	Hourmeter
LOP	Low oil pressure switch
M1	Throttle control
M2	Throttle control
M3	Throttle control
M4	Throttle control
N	Ground
N/C	Not connected
OVC	Overcrank
OVS	Overspeed
OVT	Overtemperature
Р	Positive
QCON	Quick connect terminal
RECT	Rectifier (voltage)
SM	Starter motor
SR	Starter relay
SS	Starter solenoid
Stat	Stator
STM	Stepper motor (governor)
STP	Stop
STT	Start

Figure 5-2 Wiring Diagram Abbreviations

Fault Shutdowns 5.1.6

The generator set shuts down automatically under the fault conditions listed in Figure 5-3 and cannot be restarted until the controls are reset. The LED on the control board illuminates to indicate a fault. See Figure 5-1.

Identify and correct the cause of the fault, then reset the controller by placing either the remote control switch or the generator set master switch in the STOP position.

Note: The high engine temperature fault automatically resets and the engine restarts when the generator set cools.

Fault	Description			
High engine temperature	Shuts down 5 seconds after the fault. When the engine cools, the fault clears and the controller resets automatically.			
	Note: The generator set engine restarts after the engine cools.			
	The high engine temperature shutdown does not function during the first 30 seconds after startup.			
Low oil pressure	Shuts down 5 seconds after the fault. The low oil pressure shutdown does not function during the first 30 seconds after startup.			
	NOTE: The low oil pressure shutdown does not protect against low oil level.			
Overcrank	Shuts down after three starting attempts: crank 15 sec., rest 15 sec., overcrank fault after three attempts to start.			
	Overcrank shutdown also occurs in the case of a locked rotor. Shuts down 1 second after the fault is detected.			
Overspeed	Shuts down immediately if the engine speed exceeds 3850 RPM.			

Figure 5-3 Fault Shutdowns


5.2 Fault Shutdown Tests

Verify operation of the controller overspeed, overcrank, low coolant level, low oil pressure, and high engine temperature shutdowns by performing the following tests with the generator set running. Observe the LED on the controller circuit board during the tests. Refer to the service views in Section 1.4 for component locations.


Follow the enclosure manufacturer's instructions to open or remove the enclosure to gain access to the generator set components in the following tests.

Check the continuity of the wiring harness leads before replacing the control board. Refer to the wiring diagrams in Section 7 for the lead codes and connecting terminals.

If these tests are inconclusive, test the individual shutdown circuit components as described in Section 5.3.



(600 volts and under)



Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Low Oil Pressure (LOP) Shutdown 5.2.1

The low oil pressure (LOP) switch closes 5 seconds after the oil pressure drops below 5 psi, shutting down the generator set and lighting the fault LED on the control board. The low oil pressure shutdown does not function during the first 30 seconds after startup.

To test the operation of the LOP shutdown, connect a jumper wire from pin J4-13 of the controller-to-engine wiring harness to the generator set ground. Start the generator set. After approximately 35 seconds the generator set shuts down and the fault lamp lights. If the generator set does not shut down, replace the control board.

Note: Always check wiring before replacing the control

High Oil Temperature (HOT) 5.2.2 **Shutdown**

The high oil temperature (HOT) switch closes 5 seconds after the generator set temperature reaches 305°F, shutting down the generator set and lighting the fault LED on the control board. The high engine temperature shutdown does not function during the first 30 seconds after startup.

To test the HOT shutdown, connect a jumper from the HOT switch (lead) to the generator set ground. Start the generator set. After approximately 35 seconds the generator set shuts down and the fault LED lights. Five seconds after the jumper is removed, the fault LED goes out and the generator set restarts. If the generator set does not shut down and restart as described, replace the control board.

Note: Always check wiring before replacing the control

5.2.3 Overcrank Shutdown

The generator set shuts down and the fault LED lights after approximately 75 seconds of cyclic cranking (three attempts to start). The manufacturer sets the circuit board for three cranking attempts: crank 15 seconds, rest 15 seconds, crank 15 seconds, rest 15 seconds, crank 15 seconds, shutdown. Use the following procedure to test the overcrank shutdown operation.

Overcrank Shutdown Test Procedure

- 1. Turn off the fuel supply to prevent flooding.
- 2. Move the generator set master switch to the RUN position.
- 3. Verify that the generator set stops cranking and the fault lamp lights after the third crank/rest cycle.

5.2.4 **Overspeed Shutdown**

The generator set shuts down and the fault LED on the control board lights when the engine speed exceeds 3850 rpm.

Use the following procedure to test the operation of the overspeed shutdown.

Overspeed Shutdown Test Procedure

Note: Do not increase the engine speed above 3950 rpm. Increasing the engine speed above 3950 rpm can raise the output voltage high enough to damage the generator and connected equipment.

- 1. Disconnect the load from the generator set.
- 2. Connect a tachometer to the engine spark plug lead to measure the engine speed during the test.

Note: If a tachometer is not available, connect a frequency meter across terminals 2 and 3 on the AC side of the voltage rectifier. Increase the engine speed as instructed in step 3. The generator set should shut down when the output frequency reaches 770 Hz. Do not exceed 790 Hz.

- 3. With the generator set running, carefully move the throttle linkage to increase the engine speed. Watch the tachometer and note the speed when the generator set shuts down.
- 4. Reset the controller by moving the master switch to the OFF position and then back to AUTO.

If the generator set does not shut down when the engine speed exceeds 3850 rpm, replace the control board.

5.3 Control Board Tests

Use the troubleshooting procedures in Section 3 to diagnose generator set and engine problems. If the troubleshooting procedures indicate a problem with the controller circuit board, use the tests in this section to check the board.

Refer to the wiring diagrams in Section 7 when troubleshooting the generator set control circuit board. Circuit board components cannot be repaired or replaced; if the troubleshooting process reveals a faulty component on the circuit board, replace the board.

Note: Use an ohmmeter or continuity tester to check for shorts or open leads in the wiring harnesses before replacing the controller circuit board or other system components.


Disconnect the generator system from the remote control system at controller interface harness GM14245 and use the generator set master switch to operate the generator set. If the generator set operates normally when the controller interface harness is disconnected, then the problem is with the remote control system. Refer to the manufacturer's instructions for the remote control system to troubleshoot the problem. If the problem persists after the controller interface harness is disconnected, use the troubleshooting procedures in this manual to diagnose the problem.



Hazardous voltage. Can cause severe injury or death.

Only authorized personnel should open the enclosure.

(600 volts and under)



Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

5.3.1 **Fuel Control Circuit**

Move the generator set master switch to the START position and check for 12 VDC to the fuel valve on lead 70. If the valve receives voltage but does not open, replace the valve.

If there is no voltage to the valve, check wiring harness. If the wiring harness is good but the fuel valve does not receive voltage, replace the controller circuit board.

5.3.2 Speed Sensing and Governor (Throttle Control) Circuits

The controller monitors the DC voltage from the voltage rectifier to sense and control the engine speed. If the engine speed varies erratically, test the governor operation as described in Section 4.2. If the tests show that the erratic operation is not caused by a faulty governor, replace the controller circuit board.

Start Circuits 5.3.3

Move the generator set master switch to the START or RUN position. If the engine does not crank, check the following components:

- 1. Check the battery voltage. Recharge or replace a weak or dead battery.
- 2. Check for 12 VDC to the starter motor. Also verify that the starter motor is grounded. See Section 7, Wiring Diagrams. If the starter motor is receiving voltage but not functioning, replace it. If there is no voltage to the starter motor, check the harness and connections and then proceed to step 3 to check the starter (crank) relay.
- 3. Check for 12 VDC to the crank relay. Section 7, Wiring Diagrams. If the crank relay is receiving voltage but not functioning, replace it. If there is no voltage to the crank relay, check the harness and connections.
- 4. Check for 12 VDC from the control board on pin P2-1 (lead 71). If there is no voltage, replace the controller circuit board.

5.3.4 Ignition Circuits

Move the generator set master switch to the START position. If the engine cranks but does not start, check for spark at the spark plugs. Refer to the Engine Service Manual for ignition system service information. The COM7.5 engine uses a capacitive discharge ignition system.

5.4 Control Board Replacement

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), *not a direct short*, to ground.

If the controller tests in this section or the troubleshooting procedures in Section 3 indicate that the control board needs to be replaced, follow these guidelines:

- Keep the new board in its protective wrapping until installation.
- Wear a grounding strap while handling the circuit board to prevent damage to the circuit board components.
- Check that all plug connections are secure.
- Calibrate the new control board after installation.

Control Board Replacement Procedure

- Move the system controller switch to the STOP or OFF position.
- 2. Move the generator set master switch to the STOP position. (The switch will return to the center position when released.)
- 3. Disconnect power to the battery charger, if equipped.
- 4. Disconnect the generator set engine starting battery, negative (-) lead first.
- 5. Disconnect the three (3) wiring harness connectors from the control board.
- 6. Carefully remove the board from its mounting.
- 7. Install the new control board.
- 8. Reconnect the three wiring harness connectors.

- 9. Reconnect power to the generator set engine starting battery, negative (-) lead last.
- 10. Reconnect power to the battery charger, if equipped.
- 11. Use the following procedure to calibrate the board.

Note: The new control board *must* be calibrated after installation.

Calibration Procedure

- Connect a voltmeter to the DC output terminals of the voltage rectifier. (See the wiring diagram in Section 7.)
- 2. Turn R32 on the circuit board fully clockwise. See Figure 5-4.
- 3. Start the generator set with no load.
- 4. Adjust R32 to obtain the voltage output shown in Figure 5-5.




Figure 5-4 Generator Set Controls

Generator Set Model	Measured Output Voltage, VDC
48 Volt	52
96 Volt	104

Figure 5-5 Output Voltages, VDC

6.1 COM7.5 Disassembly



Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

The following steps describe unit disassembly and reassembly and component removal and replacement.

6.1.1 **Generator Set Disconnection**

Perform the following steps to disconnect the generator set for any maintenance:

- 1. Move the remote control switch to the OFF or STOP position.
- 2. Follow the enclosure manufacturer's instructions to open or remove the enclosure.
- 3. Check that the generator set master switch (located on the generator set control board) is in the OFF position.
- 4. Disconnect the battery charger, if equipped.
- 5. Disconnect the battery, negative (-) lead first.
- 6. Disconnect the three alternator AC leads from the rectifier.
- 7. Remove ducting from around the generator set assembly as instructed by the enclosure manufacturer.

6.1.2 **Alternator Disassembly**

Perform the following steps to disassemble the alternator for maintenance.

- 1. Remove four screws from the bearing cover. See Figure 6-1.
- 2. Remove three screws from the exhaust bracket. See Figure 6-1, item 1.
- 3. Remove the four end bracket bolts.

Note: The exhaust bracket shown in Figure 6-1 is attached by the top two end bracket bolts and will come off when those bolts are removed. Set it aside for reinstallation later. (The silencer remains in place.)




Figure 6-1 Generator Set Alternator End

- 4. Use a puller or slide hammer to remove the end bracket. The end bracket has two 1/4 in. threaded holes, four inches apart, for use with an adapter bar. See Figure 6-2.
- 5. Remove the 4 socket head screws that secure the stator. See Figure 6-3.
- 6. Grasp the stator firmly. Pull straight out to prevent damage to the stator laminations. See Figure 6-4.
- 7. Loosen the thrubolt. See Figure 6-5.
- 8. Loosen the rotor/fan assembly by lightly tapping on alternate sides with a rubber mallet. Use only a rubber mallet to prevent damage to the bolt.
- 9. Remove the thrubolt and rotor.




Figure 6-2 Remove End Bracket




Figure 6-3 Remove Socket Head Screws




Figure 6-4 Remove Stator




Figure 6-5 Loosen Thrubolt

6.2 COM7.5 Reassembly

The following sections describe COM7.5 component reinstallation and unit reassembly.

6.2.1 **Alternator Reassembly**

Follow the step-by-step procedures listed on the following pages. See Figure 6-6 for a diagram on complete alternator reassembly.

Reassemble the Alternator

- 1. Apply antiseize thread compound to taper of engine crank shaft to ease future removals. See Figure 6-7.
- 2. Clean and reinstall the rotor and thrubolt. Remove any magnetically held debris.
- 3. With a strap wrench around the rotor, torque the thrubolt to 38 Nm (28 ft. lbs.). See Figure 6-8.




Figure 6-6 Alternator (exploded view)

4. Place guide pins or headless bolts in the stator mounting screw holes as a guide for reinstalling the stator. Stator damage can occur if it is not installed correctly.

Note: The magnets are very strong and cause the stator to quickly snap over the magnetized rotor.

5. Install the stator with the leads in the upper left position Slide the stator over the guide pins until it is fully installed on casting bosses. Be careful not to pinch your fingers between the stator and adapter when the stator snaps into place.




Figure 6-7 Apply Antiseize Compound




Figure 6-8 Torque Thrubolt

- 6. Remove the guides. Clean, install, and torque the socket head screws to 10.8 Nm (8 ft. lbs.). See Figure 6-9.
- 7. Route the stator leads through the port in the end bracket. Inspect leads for signs of wear. Repair or replace the stator as needed.
- 8. Align the end bracket on the stator assembly and rotor bearing. Use a rubber mallet to seat the end bracket casting if necessary.


Note: Do not install the end bracket by tightening the bolts. End bracket, engine, and/or generator adapter damage can result. Fully install and seat the end bracket casting against the mating casting before installing the bolts.

- 9. Clean and install the end bracket bolts. Tighten the bolts to 38.0 Nm (28 ft. lbs.) using the A, B, C, D tightening sequence shown in Figure 6-10.
- 10. Replace the bearing cover and install the screws.

6.2.2 **Generator Set Connection**

- 1. Check that the remote start/stop switch is in the STOP position.
- 2. Reconnect the three alternator AC output leads to the voltage rectifier.
- 3. Reconnect the generator set engine starting battery, negative (-) lead last.
- 4. Reconnect the battery charger, if equipped.

5. Follow the enclosure manufacturer's instructions to reinstall the exhaust ductwork and the enclosure.



Torque Socket Head Screws Figure 6-9




Figure 6-10 End Bracket: A, B, C, D Tightening Sequence

Section 7 Wiring Diagrams

Diagram or Drawing	Drawing Number	Reference
Schematic Diagrams Wiring Diagram	CM20551	Figuro 7 1
Schematic		




Figure 7-1 Wiring Diagram, GM20551




Figure 7-2 Schematic, ADV-6654

Notes

44 Section 7 Wiring Diagrams

The following list contains abbreviations that may appear in this publication.

THE IOII	owing list contains abbreviation	is that ma	y appear in this publication.		
A, amp	ampere	cfm	cubic feet per minute	exh.	exhaust
ABDC	after bottom dead center	CG	center of gravity	ext.	external
AC	alternating current	CID	cubic inch displacement	F	Fahrenheit, female
A/D	analog to digital	CL	centerline	fglass.	fiberglass
ADC	analog to digital converter	cm	centimeter	FHM	flat head machine (screw)
adj.	adjust, adjustment	CMOS	complementary metal oxide	fl. oz.	fluid ounce
AĎV	advertising dimensional		substrate (semiconductor)	flex.	flexible
	drawing	cogen.	cogeneration	freq.	frequency
AHWT	anticipatory high water	com	communications (port)	FS '	full scale
	temperature	coml	commercial	ft.	foot, feet
AISI	American Iron and Steel	Coml/Rec	Commercial/Recreational	ft. lbs.	foot pounds (torque)
	Institute	conn.	connection	ft./min.	feet per minute
ALOP	anticipatory low oil pressure	cont.	continued	g	gram
alt.	alternator	CPVC	chlorinated polyvinyl chloride	ga.	gauge (meters, wire size)
Al	aluminum	crit.	critical	gal.	gallon
ANSI	American National Standards	CRT	cathode ray tube	gen.	generator
	Institute (formerly American Standards	CSA	Canadian Standards	genset	generator set
	Association, ASA)		Association	GFI	ground fault interrupter
AO	anticipatory only	CT	current transformer	_	
API	American Petroleum Institute	Cu	copper	GND, ⊕	ground
approx.	approximate, approximately	cu. in.	cubic inch	gov.	governor
AR	as required, as requested	CW.	clockwise	gph	gallons per hour
AS	as supplied, as stated, as	CWC	city water-cooled	gpm	gallons per minute
70	suggested	cyl.	cylinder	gr.	grade, gross
ASE	American Society of Engineers	D/A	digital to analog	GRD	equipment ground
ASME	American Society of	DAC	digital to analog converter	gr. wt.	gross weight
, .o	Mechanical Engineers	dB	decibel	$H \times W \times D$	height by width by depth
assy.	assembly	dBA	decibel (A weighted)	HC	hex cap
ASTM	American Society for Testing	DC	direct current	HCHT	high cylinder head temperature
	Materials	DCR	direct current resistance	HD	heavy duty
ATDC	after top dead center	deg., °	degree	HET	high exhaust temperature,
ATS	automatic transfer switch	degt.	department		high engine temperature
auto.	automatic	dept. dia.	diameter	hex	hexagon
aux.	auxiliary	DI/EO	dual inlet/end outlet	Hg	mercury (element)
A/V	audiovisual	DI/LO		HH	hex head
avg.	average	DIN	Deutsches Institut fur Normung e. V.	HHC	hex head cap
AVR	automatic voltage regulator		(also Deutsche Industrie	HP	horsepower
AWG	American Wire Gauge		Normenausschuss)	hr.	hour
AWM	appliance wiring material	DIP	dual inline package	HS	heat shrink
bat.	battery	DPDT	double-pole, double-throw	hsg.	housing
BBDC	before bottom dead center	DPST	double-pole, single-throw	HVAC	heating, ventilation, and air
BC	battery charger, battery	DS	disconnect switch		conditioning
	charging	DVR	digital voltage regulator	HWT	high water temperature
BCA	battery charging alternator	E, emer.	emergency (power source)	Hz	hertz (cycles per second)
BCI	Battery Council International	EDI	electronic data interchange	IC	integrated circuit
BDC	before dead center	EFR	emergency frequency relay	ID	inside diameter, identification
BHP	brake horsepower	e.g.	for example (exempli gratia)	IEC	International Electrotechnical
blk.	black (paint color), block	EĞ	electronic governor		Commission
	(enginë)	EGSA	Electrical Generating Systems	IEEE	Institute of Electrical and
blk. htr.	block heater		Association		Electronics Engineers
BMEP	brake mean effective pressure	EIA	Electronic Industries	IMS	improved motor starting
bps	bits per second		Association	in.	inch
br.	brass	EI/EO	end inlet/end outlet	in. H ₂ O	inches of water
BTDC	before top dead center	EMI	electromagnetic interference	in. Hg	inches of mercury
Btu	British thermal unit	emiss.	emission	in. lbs.	inch pounds
Btu/min.	British thermal units per minute	eng.	engine	Inc.	incorporated
C	Celsius, centigrade	EPA	Environmental Protection	ind.	industrial
cal.	calorie		Agency	int.	internal
CARB	California Air Resources Board	EPS	emergency power system	int./ext.	internal/external
CARB	circuit breaker	ER	emergency relay	I/O	input/output
CC	cubic centimeter	ES	engineering special,	IP	iron pipe
CCA	cold cranking amps		engineered special	ISO	International Organization for
	counterclockwise	ESD	electrostatic discharge		Standardization
ccw. CEC	Canadian Electrical Code	est.	estimated	J	joule
		E-Stop	emergency stop	JIS	Japanese Industry Standard
cert.	certificate, certification, certified	etc.	et cetera (and so forth)		
cfh	cubic feet per hour				

TP-6120 5/02 Appendix A-1

k	kilo (1000)	MTBF	mean time between failure	RHM	round head machine (screw)
K	kelvin	MTBO	mean time between overhauls	rly.	relay
kA	kiloampere	mtg.	mounting	rms	root mean square
KB	kilobyte (2 ¹⁰ bytes)	MW	megawatt	rnd.	round
	kilogram	mW	milliwatt	ROM	read only memory
kg kg/om²					
kg/cm ²	kilograms per square centimeter	μF	microfarad	rot.	rotate, rotating
kgm	kilogram-meter	N, norm.	normal (power source)	rpm	revolutions per minute
kg/m ³	kilograms per cubic meter	NA	not available, not applicable	RS	right side
-	• .	nat. gas	natural gas	RTV	room temperature vulcanization
kHz	kilohertz	NBS	National Bureau of Standards	SAE	Society of Automotive
kJ	kilojoule	NC	normally closed		Engineers
km	kilometer	NEC	National Electrical Code	scfm	standard cubic feet per minute
kOhm, kΩ		NEMA	National Electrical	SCR	silicon controlled rectifier
kPa	kilopascal		Manufacturers Association	s, sec.	second
kph	kilometers per hour	NFPA	National Fire Protection	SI	Systeme international d'unites,
kV	kilovolt		Association	01/50	International System of Units
kVA	kilovolt ampere	Nm	newton meter	SI/EO	side in/end out
kVAR	kilovolt ampere reactive	NO	normally open	sil.	silencer
kW	kilowatt	no., nos.	number, numbers	SN	serial number
kWh	kilowatt-hour	NPS	National Pipe, Straight	SPDT	single-pole, double-throw
kWm	kilowatt mechanical	NPSC	National Pipe, Straight-coupling	SPST	single-pole, single-throw
L	liter	NPT	National Standard taper pipe	spec, spec	cs
LAN	local area network		thread per general use		specification(s)
		NPTF	National Pipe, Taper-Fine	sq.	square
lb.	pound, pounds	NR	not required, normal relay	sq. cm	square centimeter
lbm/ft ³	pounds mass per cubic feet	ns	nanosecond	sq. in.	square inch
LCB	line circuit breaker	OC	overcrank	SS	stainless steel
		OD	outside diameter	std.	standard
LCD	liquid crystal display	OEM	original equipment	stl.	steel
ld. shd.	load shed		manufacturer	tach.	tachometer
LED	light emitting diode	OF	overfrequency	TD	time delay
Lph	liters per hour	opt.	option, optional	TDC	top dead center
Lpm	liters per minute	OS	oversize, overspeed	TDEC	•
LOP	low oil pressure	OSHA	Occupational Safety and Health		time delay engine cooldown
LP	liquefied petroleum	OULA	Administration	TDEN	time delay emergency to normal
LPG	liquefied petroleum gas	OV	overvoltage	TDES	
LS	left side	OZ.	ounce		time delay engine start
L _{wa}	sound power level, A weighted	p., pp.	page, pages	TDNE	time delay normal to emergency
LWL	low water level	PC	personal computer	TDOE	time delay off to emergency
LWT	low water temperature	PCB	printed circuit board	TDOL	time delay off to enlergency
m	meter, milli (1/1000)		•		•
M	mega (10 ⁶ when used with SI	pF	picofarad	temp.	temperature
IVI	units), male	PF	power factor	term.	terminal
m ³	cubic meter	ph., \varnothing	phase	TIF	telephone influence factor
m ³ /min.	cubic meters per minute	PHC	Phillips head crimptite (screw)	TIR	total indicator reading
mA	milliampere	PHH	Phillips hex head (screw)	tol.	tolerance
		PHM	pan head machine (screw)	turbo.	turbocharger
man.	manual	PLC	programmable logic control	typ.	typical (same in multiple
max.	maximum	PMG	permanent-magnet generator		locations)
MB	megabyte (2 ²⁰ bytes)	pot	potentiometer, potential	UF	underfrequency
MCM	one thousand circular mils	ppm	parts per million	UHF	ultrahigh frequency
MCCB	molded-case circuit breaker	PROM	programmable read-only	UL	Underwriter's Laboratories, Inc.
meggar	megohmmeter		memory	UNC	unified coarse thread (was NC)
MHz	megahertz	psi	pounds per square inch	UNF	unified fine thread (was NF)
mi.	mile	pt.	pint	univ.	universal
mil	one one-thousandth of an inch	PTC	positive temperature coefficient	US	undersize, underspeed
min.	minimum, minute	PTO	power takeoff	UV	ultraviolet, undervoltage
misc.	miscellaneous	PVC	polyvinyl chloride	V	volt
MJ	megajoule	qt.	quart, quarts	VAC	volts alternating current
mJ	millijoule	qt. qty.	quantity	VAR	voltampere reactive
mm	millimeter	R	replacement (emergency)	VDC	volts direct current
mOhm, mg			power source	VFD	vacuum fluorescent display
	milliohm	rad.	radiator, radius		
MOhm, M		RAM	random access memory	VGA VHF	video graphics adapter
•	megohm	RDO	relay driver output		very high frequency
MOV	metal oxide varistor	ref.	reference	W	watt
MPa	megapascal			WCR	withstand and closing rating
mpg	miles per gallon	rem.	remote Posidential/Commercial	w/	with
mph	miles per hour		Residential/Commercial	w/o	without
MS	military standard	RFI	radio frequency interference	wt.	weight
m/sec.	meters per second	RH	round head	xfmr	transformer

A-2 Appendix TP-6120 5/02

Appendix B Common Hardware Application Guidelines

Use the information below and on the following pages to identify proper fastening techniques when no specific reference for reassembly is made.

Bolt/Screw Length: When bolt/screw length is not given, use Figure 1 as a guide. As a general rule, a minimum length of one thread beyond the nut and a maximum length of 1/2 the bolt/screw diameter beyond the nut is the preferred method.

Washers and Nuts: Use split lock washers as a bolt locking device where specified. Use SAE flat washers with whiz nuts, spiralock nuts, or standard nuts and preloading (torque) of the bolt in all other applications.

See Appendix C, General Torque Specifications, and other torque specifications in the service literature.




Figure 1 Acceptable Bolt Lengths

Steps for common hardware application:

- 1. Determine entry hole type: round or slotted.
- 2. Determine exit hole type: fixed female thread (weld nut), round, or slotted.

For round and slotted exit holes, determine if hardware is greater than 1/2 inch in diameter, or 1/2 inch in diameter or less. Hardware that is *greater than 1/2 inch* in diameter takes a standard nut and SAE washer. Hardware 1/2 inch or less in diameter can take a properly torqued whiz nut or spiralock nut. See Figure 2.

- 3. Follow these SAE washer rules after determining exit hole type:
 - a. Always use a washer between hardware and a slot.
 - b. Always use a washer under a nut (see 2 above for exception).
 - c. Use a washer under a bolt when the female thread is fixed (weld nut).
- 4. Refer to Figure 2, which depicts the preceding hardware configuration possibilities.




Figure 2 Acceptable Hardware Combinations

TP-6120 5/02 Appendix A-3

Appendix C General Torque Specifications

Use the following torque specifications when service literature instructions give no specific torque values. The charts list values for new plated, zinc phosphate, or

oiled threads. Increase values by 15% for nonplated threads. All torque values are +0%/-10%.

	American Standard Fasteners Torque Specifications						
	Torque Assembled into Cast Iron or Steel						
Size	Measurement	Grade 2	Grade 5	Grade 8	Aluminum Grade 2 or 5		
8-32	Nm (in. lb.)	1.8 (16)	2.3 (20)	_	1.8 (16)		
10-24	Nm (in. lb.)	2.9 (26)	3.6 (32)		2.9 (26)		
10-32	Nm (in. lb.)	2.9 (26)	3.6 (32)	_	2.9 (26)		
1/4-20	Nm (in. lb.)	6.8 (60)	10.8 (96)	14.9 (132)	6.8 (60)		
1/4-28	Nm (in. lb.)	8.1 (72)	12.2 (108)	16.3 (144)	8.1 (72)		
5/16-18	Nm (in. lb.)	13.6 (120)	21.7 (192)	29.8 (264)	13.6 (120)		
5/16-24	Nm (in. lb.)	14.9 (132)	23.1 (204)	32.5 (288)	14.9 (132)		
3/8-16	Nm (ft. lb.)	24.0 (18)	38.0 (28)	53.0 (39)	24.0 (18)		
3/8-24	Nm (ft. lb.)	27.0 (20)	42.0 (31)	60.0 (44)	27.0 (20)		
7/16-14	Nm (ft. lb.)	39.0 (29)	60.0 (44)	85.0 (63)	_		
7/16-20	Nm (ft. lb.)	43.0 (32)	68.0 (50)	95.0 (70)	_		
1/2-13	Nm (ft. lb.)	60.0 (44)	92.0 (68)	130.0 (96)	_		
1/2-20	Nm (ft. lb.)	66.0 (49)	103.0 (76)	146.0 (108)	_		
9/16-12	Nm (ft. lb.)	81.0 (60)	133.0 (98)	187.0 (138)			
9/16-18	Nm (ft. lb.)	91.0 (67)	148.0 (109)	209.0 (154)	_		
5/8-11	Nm (ft. lb.)	113.0 (83)	183.0 (135)	259.0 (191)	_		
5/8-18	Nm (ft. lb.)	128.0 (94)	208.0 (153)	293.0 (216)	_		
3/4-10	Nm (ft. lb.)	199.0 (147)	325.0 (240)	458.0 (338)			
3/4-16	Nm (ft. lb.)	222.0 (164)	363.0 (268)	513.0 (378)	_		
1-8	Nm (ft. lb.)	259.0 (191)	721.0 (532)	1109.0 (818)	_		
1-12	Nm (ft. lb.)	283.0 (209)	789.0 (582)	1214.0 (895)	_		

Metric Fasteners Torque Specifications, Measured in Nm (ft. lb.)						
	Assembled into					
Size (mm)	Grade 5.8	Grade 8.8	Grade 10.9	Aluminum Grade 5.8 or 8.8		
M6 x 1.00	5.6 (4)	9.9 (7)	14.0 (10)	5.6 (4)		
M8 x 1.25	13.6 (10)	25.0 (18)	35.0 (26)	13.6 (10)		
M8 x 1.00	21.0 (16)	25.0 (18)	35.0 (26)	21.0 (16)		
M10 x 1.50	27.0 (20)	49.0 (35)	68.0 (50)	27.0 (20)		
M10 x 1.25	39.0 (29)	49.0 (35)	68.0 (50)	39.0 (29)		
M12 x 1.75	47.0 (35)	83.0 (61)	117.0 (86)	_		
M12 x 1.50	65.0 (48)	88.0 (65)	125.0 (92)	_		
M14 x 2.00	74.0 (55)	132.0 (97)	185.0 (136)	_		
M14 x 1.50	100.0 (74)	140.0 (103)	192.0 (142)	_		
M16 x 2.00	115.0 (85)	200.0 (148)	285.0 (210)	_		
M16 x 1.50	141.0 (104)	210.0 (155)	295.0 (218)	_		
M18 x 2.50	155.0 (114)	275.0 (203)	390.0 (288)	_		
M18 x 1.50	196.0 (145)	305.0 (225)	425.0 (315)			

A-4 Appendix TP-6120 5/02

Appendix D Common Hardware Identification

Screw/Bolts/Studs					
Head Styles					
Hex Head or Machine Head					
Hex Head or Machine Head with Washer					
Flat Head (FHM)					
Round Head (RHM)					
Pan Head					
Hex Socket Head Cap or Allen™ Head Cap	Omin				
Hex Socket Head or Allen™ Head Shoulder Bolt	0				
Sheet Metal Screw					
Stud					
Drive Styles					
Hex					
Hex and Slotted					
Phillips®	4				
Slotted	0				
Hex Socket					


Nuts				
Nut Styles				
Hex Head				
Lock or Elastic				
Square				
Cap or Acorn				
Wing	Ø			
Washers				
Washer Styles				
Plain				
Split Lock or Spring	Q			
Spring or Wave				
External Tooth Lock	£0,3			
Internal Tooth Lock				
Internal-External Tooth Lock				

Hardness Grades				
American Standard				
Grade 2	$\bigcirc\bigcirc\bigcirc$			
Grade 5	←			
Grade 8				
Grade 8/9 (Hex Socket Head)	0			
Metric				
Number stamped on hardware; 5.8 shown	5.8			

Allen™ head screw is a trademark of Holo-Krome Co.

Phillips® screw is a registered trademark of Phillips Screw Company.

Sample Dimensions



TP-6120 5/02 Appendix A-5

KOHLERPOWER SYSTEMS

KOHLER CO. Kohler, Wisconsin 53044 Phone 920-565-3381, Fax 920-459-1646 For the nearest sales/service outlet in the US and Canada, phone 1-800-544-2444 KohlerPowerSystems.com

Kohler Power Systems Asia Pacific Headquarters 7 Jurong Pier Road Singapore 619159 Phone (65)264-6422, Fax (65)264-6455