Operation

Commercial Generator Sets



Models:

15REYG 30REYG

Controller: Advanced Digital Control (ADC 2100)



KOHLER®
POVER SYSTEMS _______TP-6728 10/11b

California Proposition 65



WARNING

Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Product Identification Information

Product identification numbers determine service parts. Record the product identification numbers in the spaces below immediately after unpacking the products so that the numbers are readily available for future reference. Record field-installed kit numbers after installing the kits.

Generator Set Identification Numbers Record the product identification numbers from the

enerator set nameplat	e(s).
Model Designation Specification Number _ Serial Number	
ccessory Number	Accessory Description

Controller Identification

Record the controller description from the generator se
operation manual, spec sheet, or sales invoice.

Controlle	r Description	
Jontrolle	r Description	

Engine Identification

engine nameplate.	•
Manufacturer	
Model Designation	
Serial Number	

Table of Contents

Product Identification Information 2			
Safety Precautions and Instructions			
Introduction		1	
Service Assista	nce		
Section 1 Servi	ce Vie	ws 1;	
Section 2 Opera	ation .		
-	2.1	Prestart Checklist	
	2.2	Exercising Generator Set	
	2.3	Advanced Digital Control Operation	
		2.3.1 Controls and Indicators	
		2.3.2 Starting Generator Set	
		2.3.3 Stopping Generator Set	
		2.3.4 Fault Warnings and Shutdowns	
		2.3.5 Resetting Controller after a Fault Shutdown	
		2.3.6 Controller Power Down	
Section 3 Sche	duled	Maintenance 2	
	3.1	General Maintenance	
	3.2	Service Schedule	
	3.3	Lubrication System	
		3.3.1 Oil Specifications	
		3.3.2 Oil Check	
		3.3.3 Optional Oil Makeup Kit	
		3.3.4 Oil Additions	
		3.3.5 Oil and Filter Change	
	3.4	Air Cleaner 24	
	3.5	Exhaust System	
	3.6	Cooling System	
		3.6.1 Checking and Filling Coolant	
		3.6.2 Draining Cooling System	
		3.6.3 Filling Cooling System	
		3.6.4 Flushing and Cleaning 26	
		3.6.5 Pressure Cap 26	
	3.7	Ignition System	
	3.8	Battery	
	3.9	Belt Check	
	3.10	Storage Procedure	
Section 4 Troub	olesho	oting 3	
	4.1	Introduction 3	
	4.2	Circuit Protection	
		4.2.1 Line Circuit Breaker	
		4.2.2 Fuses	
	4.3	Faults 3	
	-	4.3.1 Fault Codes	
		4.3.2 Fault History	
	4.4	Generator Set Troubleshooting	
	4.5	Controller Troubleshooting	
Annendix A Ahh	_	-	
		.ma	

4 Table of Contents TP-6728 10/11

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. SAVE THESE INSTRUCTIONS.

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.



DANGER

Danger indicates the presence of a hazard that will cause severe personal injury, death, or substantial property damage.



WARNING

Warning indicates the presence of a hazard that can cause severe personal injury, death, or substantial property damage.



CAUTION

Caution indicates the presence of a hazard that will or can cause minor personal injury or property damage.

NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

generator Disabling the set. Accidental starting can cause severe injury or death. working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

Battery

A

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

▲ WARNING



Explosion.

Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion. avoid touching the battery terminals with tools or other metal objects. Remove all iewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Engine Backfire/Flash Fire



Fire.
Can cause severe injury or death.

Do not smoke or permit flames or sparks near fuels or the fuel system.

Servicing the fuel system. A flash fire can cause severe injury or death.

Do not smoke or permit flames or sparks near the carburetor, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Catch fuels in an approved container when removing the fuel line or carburetor.

Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner removed.

Combustible materials. A fire can cause severe injury or death. Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or BC for electrical fires or as recommended by the local fire code or an authorized agency. Train all personnel on fire extinguisher operation and fire prevention procedures.

Exhaust System



Carbon monoxide.
Can cause severe nausea, fainting, or death.

The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building unless the exhaust gas is piped safely outside. Never operate the generator set where exhaust gas could accumulate and seep back inside a potentially occupied building.

Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

Carbon monoxide detectors. Carbon monoxide can cause severe nausea, fainting, or death. Install carbon monoxide detectors on each level of the building. Locate the detectors to adequately warn the building's occupants of the presence of carbon monoxide. Keep the detectors operational at all times. Periodically test and replace the carbon monoxide detectors according the manufacturer's instructions.

Fuel System



Explosive fuel vapors. Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

The fuel system. Explosive fuel vapors can cause severe injury or death. Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

Explosive fuel vapors can cause severe injury or death. additional precautions when using the following fuels:

Propane (LP)—Adequate ventilation is mandatory. Because propane is heavier than air, install propane gas detectors low in a room. Inspect the detectors per the manufacturer's instructions.

Natural Gas-Adequate ventilation is mandatory. Because natural gas rises, install natural gas detectors high in a room. Inspect the detectors per the manufacturer's instructions.

Gas fuel leaks. Explosive fuel vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LP vapor gas or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces per square (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

Hazardous Noise

CAUTION



Hazardous noise. Can cause hearing loss.

Never operate the generator set without a muffler or with a faulty exhaust system.

Engine noise. Hazardous noise can cause hearing loss. Generator sets not equipped with sound enclosures can produce noise levels greater than 105 dBA. Prolonged exposure to noise levels greater than 85 dBA can cause permanent hearing loss. Wear hearing protection when near an operating generator set.

Hazardous Voltage/ **Moving Parts**



Hazardous voltage. Will cause severe injury or death.

Disconnect all power sources before opening the enclosure.

WARNING





Hazardous voltage. Moving parts. Can cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

WARNING A



Hazardous voltage. Backfeed to the utility system can cause property damage, severe injury, or death.

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

CAUTION



Welding the generator set. Can cause severe electrical equipment damage.

Never weld components of the generator without set first disconnecting the battery, controller wiring harness, and engine electronic control module (ECM).

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Disconnecting the electrical load. Hazardous voltage can cause severe injury or death. Disconnect the generator set from the load by turning off the line circuit breaker or by disconnecting the generator set output leads from the transfer switch and heavily taping the ends of the leads. High voltage transferred to the load during testing may cause personal injury and equipment damage. Do not use the safeguard circuit breaker in place of the line circuit breaker. The safeguard circuit breaker does not disconnect the generator set from the load.

Welding on the generator set. Can cause severe electrical equipment damage. Before welding on the generator set perform the following steps: (1) Remove the battery cables, negative (-) lead first. (2) Disconnect all engine electronic control module (ECM) connectors. (3) Disconnect all generator set controller and voltage regulator circuit board connectors. (4) Disconnect the engine battery-charging alternator connections. (5) Attach the weld ground connection close to the weld location.

Installing the battery charger. Hazardous voltage can cause severe injury or death. ungrounded battery charger may cause electrical shock. Connect the battery charger enclosure to the ground of a permanent wiring system. As an alternative, install an equipment grounding conductor with circuit conductors and connect it to the equipment grounding terminal or the lead on the battery charger. Install the battery charger as prescribed in the equipment manual. Install the battery charger in compliance with local codes and ordinances.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Engine block heater. Hazardous voltage can cause severe injury or death. The engine block heater can cause electrical shock. Remove the engine block heater plug from the electrical outlet before working on the block heater electrical connections.

Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death. Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.

▲ WARNING



Airborne particles.

Can cause severe injury or blindness.

Wear protective goggles and clothing when using power tools, hand tools, or compressed air.

Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator set.

Heavy Equipment



Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.

Do not use lifting eyes. Lift the generator set using lifting bars inserted through the lifting holes on the skid.

Hot Parts



Hot coolant and steam.
Can cause severe injury or death.

Before removing the pressure cap, stop the generator set and allow it to cool. Then loosen the pressure cap to relieve pressure.




Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

Servicing the alternator. Hot parts can cause severe injury or death. Avoid touching the alternator field or exciter armature. When shorted, the alternator field and exciter armature become hot enough to cause severe burns.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Notice



NOTICE

Voltage reconnection. Affix a notice to the generator set after reconnecting the set to a voltage different from the voltage on the nameplate. Order voltage reconnection decal 246242 authorized from service an distributor/dealer.

NOTICE

Canadian installations only. For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code, Part 1.

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), not a direct short, to ground.

This manual provides operation instructions for 15 and 30 kW commercial generator set models listed on the front cover.

Refer to the engine operation manual for generator set engine scheduled maintenance information.

This generator set is approved for use in stationary applications in locations served by a reliable utility power source. Have the generator set installed by an authorized distributor/dealer or service technician. Refer to the Installation Manual for installation instructions. See the List of Related Literature, below.

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual. Keep this manual with the equipment for future reference.

The equipment service requirements are very important to safe and efficient operation. Inspect the parts often and perform required service at the prescribed intervals. Obtain service from an authorized service distributor/ dealer to keep equipment in top condition.

List of Related Literature

Figure 1 identifies related literature available for the generator sets covered in this manual. Only trained and qualified personnel should install or service the generator set.

Literature Type	Part Number	
Installation Manual, 15/30REYG	TP-6727	
Wiring Diagram Manual	TP-6719	
Parts Catalog*	TP-6729	
Service Manual (Engine)	TP-6724	
Service Manual (Generator Set) TP-6198		
* One Parts Catalog combines generator and engine information.		

Figure 1 Generator Set Literature

TP-6728 10/11 Introduction 11

Service Assistance

For professional advice on generator set power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KohlerPower.com.
- Look at the labels and stickers on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

Headquarters Europe, Middle East, Africa (EMEA)

Kohler Power Systems 3 rue de Brennus 93200 Saint Denis

France

Phone: (33) 1 49 178300 Fax: (33) 1 49 178301

Asia Pacific

Power Systems Asia Pacific Regional Office Singapore, Republic of Singapore

Phone: (65) 6264-6422 Fax: (65) 6264-6455

China

North China Regional Office, Beijing

Phone: (86) 10 6518 7950 (86) 10 6518 7951

(86) 10 6518 7952 Fax: (86) 10 6518 7955

East China Regional Office, Shanghai

Phone: (86) 21 6288 0500 Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office Bangalore, India

Phone: (91) 80 3366208

(91) 80 3366231

Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office

Tokyo, Japan

Phone: (813) 3440-4515

Fax: (813) 3440-2727

Latin America

Latin America Regional Office

Lakeland, Florida, USA Phone: (863) 619-7568 Fax: (863) 701-7131

12 Introduction TP-6728 10/11

Section 1 Service Views




Figure 1-1 Service Views

TP-6728 10/11 Service Views 13

14 Section 1 Service Views TP-6728 10/11

2.1 Prestart Checklist

To ensure continued satisfactory operation perform the following checks or inspections before or at each startup, as designated, and at the intervals specified in the service schedule. In addition, some checks require verification after the unit starts

Air Cleaner. Check for a clean and installed air cleaner element to prevent unfiltered air from entering the engine.

Air Inlets. Check for clean and unobstructed air inlets.

Battery. Check for tight battery connections. Consult the battery manufacturer's instructions regarding battery care and maintenance.

Coolant Level. Check the coolant level according to the cooling system maintenance information.

Note: Block heater damage. The block heater will fail if the energized heater element is not immersed in coolant. Fill the cooling system before turning on the block heater. Run the engine until it is warm, and refill the radiator to purge the air from the system before energizing the block heater.

Drive Belt(s). Check the belt condition of the water pump and battery charging alternator belt(s).

Check for exhaust leaks and Exhaust System. blockages. Check the silencer and piping condition and check for tight exhaust system connections.

Inspect the exhaust system components for cracks and corrosion (exhaust manifold, exhaust line, exhaust clamps, and silencer).

- Check for corroded or broken metal parts and replace them as needed.
- Check for loose, corroded, or missing clamps and hangers. Tighten or replace the exhaust clamps and/or hangers as needed.
- Check that the exhaust outlet is unobstructed.
- Visually inspect for exhaust leaks (blowby). Check for carbon or soot residue on exhaust components. Carbon and soot residue indicates an exhaust leak. Seal leaks as needed.

Carbon Monoxide Detectors. Check the installation and operation of carbon monoxide (CO) detectors.

Oil Level. Maintain the oil level at or near, not over, the full mark on the dipstick.

Operating Area. Check for obstructions that could block the flow of cooling air. Keep the air intake area clean. Do not leave rags, tools, or debris on or near the generator set.

2.2 Exercising Generator Set

Operate the generator set under load once each week for 20 minutes.

The operator should perform all of the prestart checks before starting the exercise procedure. Start the generator set according to the starting procedure in the controller section of this manual. While the generator set is operating, listen for a smooth-running engine and visually inspect the generator set for fluid or exhaust leaks.

2.3 Advanced Digital Control Operation

Figure 2-1 illustrates the user interface on the Advanced Digital Control (ADC 2100).

Note: Have setup and adjustments of the ADC 2100 performed only by an authorized Kohler distributor/dealer. The setup and adjustments are password protected.




Figure 2-1 ADC 2100 Control

2.3.1 Controls and Indicators

Figure 2-2 describes the controls and indicators located on the controller. The LED display indicates generator set status as shown in Figure 2-2. The display is active when the master switch is in the RUN or AUTO position and remains active until the generator set master switch is moved to the OFF/RESET position or the power to the controller is removed. If the factory-installed continuous power mode jumper has been disconnected, the LED display turns off 48 hours after the generator set shutdown. See Section 2.3.6.

The buttons on the controller keypad are used only for system configuration and adjustment. The ADC 2100 is factory-set and should not require configuration or adjustment under normal operating conditions. If the generator set is reconnected to a different voltage and/or frequency, refer to an authorized Kohler distributor/dealer for system configuration and adjustment instructions.

Control or Indicator	Item	Description
LED display	Runtime hours	Displays total generator set runtime hours.
	Crank indication	Displays CC_1, CC_2, or CC_3 to indicate the first, second or third attempt to start the engine. The last digit flashes during the crank cycle rest periods.
	Fault codes	Flashes a 2- or 3-letter fault code to indicate various fault conditions. See Section 2.3.4.
	Software version	See the Generator Set Installation Manual.
Keypad	Select and arrow buttons	The keypad is used for controller setup and adjustment only. Have setup and adjustments performed only by an authorized distributor/dealer. The setup and adjustment functions are password-protected.
Generator set master switch	Three-position switch	Switch functions as the generator set operation and controller reset switch.

Figure 2-2 ADC 2100 Controls and Indicators

2.3.2 Starting Generator Set

The following procedures describe the actions required to start the generator set.

Local Starting.

Move the generator set master switch to the RUN position. The ADC 2100 attempts to start the generator set in three crank cycles (crank cycle time is pre-programmed). If the generator set does not start in three attempts, the system shuts down on an overcrank fault.

Auto (Automatic) Starting.

Move the generator set master switch to the AUTO position to allow startup by an automatic transfer switch (ATS), remote start/stop switch or remote digital gauge. A remote start/stop switch or digital gauge can be connected to the customer interface connection (P21 connector, leads 3 and 4). The generator set crank cycle starts when the remote switch or engine start contacts on the ATS contacts close.

The ADC 2100 attempts to start the generator set in three crank cycles (crank cycle time is preprogrammed). If the generator set does not start in three attempts, the system shuts down on an overcrank fault.

2.3.3 Stopping Generator Set

The following procedures describe the actions required to stop the generator set.

Local Stopping

- 1. Run the generator set with no load for at least 2 minutes to allow the engine to cool down.
- 2. Move the generator set master switch to the OFF/RESET position. The engine stops.

Auto (Automatic) Stopping

With the generator set master switch in the AUTO position, open the remote start/stop switch contacts or engine start contacts on the ATS to signal the generator set to stop.

16 Section 2 Operation TP-6728 10/11

2.3.4 Fault Warnings and Shutdowns

Warnings. The controller displays a fault code but the generator set does not shut down under the high battery voltage (HB) and low battery voltage (LB) warning conditions shown in Figure 2-3. The controller resets automatically after a battery voltage fault condition is corrected.

Shutdowns. The generator set shuts down automatically under the conditions listed in Figure 2-4 and the controller displays a fault code. Correct the fault condition and then reset the controller before restarting the generator set. See Section 2.3.5 to reset the controller after a fault shutdown.

Shutdown switches on the generator set automatically reset when the problem is corrected. For example, the high engine temperature switch automatically resets when the generator set cools. However, the fault does not clear until the controller is reset.

LOP Shutdown. The oil pressure switch shuts down the generator set if the oil pressure drops below a preset level, providing some protection from major engine damage due to insufficient oil pressure. However, the low oil pressure switch is not a low oil level indicator. Check the oil regularly as described in the service schedule and add oil as required to keep the oil level at or near the full mark on the dipstick or optional gauge.

Code	Fault	Description	Check
НВ	High battery voltage warning	Fault code is displayed if the engine starting battery voltage rises above 16 VDC for a 12 VDC system or above 30 VDC for a 24 VDC system for more than 10 seconds when the engine is not running. This fault condition does not inhibit engine starting.	Check the battery rating and condition.
		The fault condition clears when the battery voltage returns to a voltage within the limits for more than 10 seconds.	
LB	Low battery voltage warning	Fault code is displayed if the engine starting battery voltage falls below 9.5 VDC for a 12 VDC system or below 16 VDC for a 24 VDC system for more than 10 seconds when the engine is not running. This fault condition does not inhibit engine starting.	Check the battery rating and condition. Charge or replace the battery.
		The fault condition clears when the battery voltage returns to a voltage within the limits for more than 10 seconds.	

Figure 2-3 ADC 2100 Fault Warning Codes

TP-6728 10/11 Section 2 Operation 17

Code	Fault	Description	Check
AF	Auxiliary fault input shutdown	Input from a customer-supplied switch that closes when the fault is active. The generator set shuts down 0.3 seconds after the fault is detected and will not start when the fault is active (input is grounded). This protection becomes active 3 seconds after crank disconnect.	Check the cause of the auxiliary fault.
HE	High engine temperature shutdown	Shutdown occurs if the engine coolant temperature exceeds the maximum temperature for more than 5 seconds. This protective becomes active after the engine reaches the crank disconnect speed.	Check for blocked air inlets and exhaust outlets.
LCL	Low coolant level	Not used.	_
LOC	Loss of coolant	Not used.	_
LOP	Low oil pressure shutdown	Shutdown occurs if a low oil pressure condition exists for more than 5 seconds. This protective becomes active 30 seconds after the engine has reached crank disconnect speed (30 second inhibit).	Check for leaks in the lubrication system. Check the oil level and add oil if the level is low.
ОС	Overcrank	Shutdown occurs after 3 unsuccessful starting	Check the fuel supply, spark plug, and battery.
	shutdown attempts. The crank cycle is set for three starting attempts of 15 seconds cranking and 15		Check for loose connections.
		seconds rest. The generator set also shuts down if no engine	Contact an authorized distributor/dealer for service if problem continues.
		rotation is sensed during cranking. Shuts down 1 second after the fault is detected.	
OF	Overfrequency shutdown	Shutdown occurs when the governed frequency exceeds 110% of the system's frequency setpoint for more than 5 seconds. This protective becomes active 10 seconds after engine start (10 second inhibit).	Contact an authorized distributor/dealer for service if problem continues.
os	Overspeed shutdown	Shutdown occurs if the engine speed exceeds 115% of the normal running speed for more than 0.3 seconds.	Contact an authorized distributor/dealer for service if problem continues.
OU	Overvoltage shutdown	Shutdown occurs if the voltage exceeds 120% of the system nominal voltage for more than 2 seconds.	Contact an authorized distributor/dealer for service if problem continues.
UF	Underfrequency shutdown	Shutdown occurs when the governed frequency falls below 90% of the nominal system frequency for more than 5 seconds or below 59 Hz for more than 60 seconds. This protective becomes active 10 seconds after engine start. (10 second inhibit).	Reduce the load and restart the generator set. Contact an authorized distributor/dealer for service if problem continues.
UU	Undervoltage shutdown	Shutdown occurs if the voltage falls below 80% of the nominal system voltage for more than 10 seconds.	Reduce the load and restart the generator set. Contact an authorized distributor/dealer for service if problem continues.
SCF0	Software Communication Fault 0	Indicates a software or communication problem within the ADC 2100	Replace the controller.

Figure 2-4 ADC 2100 Fault Shutdown Codes

18 Section 2 Operation TP-6728 10/11

2.3.5 Resetting Controller after a Fault Shutdown

Always identify and correct the cause of a fault shutdown before resetting the controller. Use the following procedure to reset the generator set controller after a fault shutdown.

- 1. Move the generator set master switch to the OFF/RESET position.
- Disconnect the generator set from the load using the line circuit breaker or ATS. See the safety precautions at the beginning of this manual before proceeding.
- Identify and correct the cause of the fault shutdown. See the safety precautions at the beginning of this manual before proceeding. Refer to Section 4, Troubleshooting.
- Start the generator set by moving the generator set master switch to RUN. Test operate the generator set to verify that the cause of the shutdown has been corrected.
- 5. Shut the generator off by moving the generator set master switch to the OFF/RESET position.
- 6. Reconnect the generator set to the load using the line circuit breaker or ATS.
- 7. Move the generator set master switch to the AUTO position for startup by remote transfer switch, remote start/stop switch, or remote digital gauge.

Note: Opening and closing the remote start/stop contact also resets the controller. Always identify and correct the cause of the fault shutdown before restarting the generator set.

2.3.6 Controller Power Down

The ADC 2100 is powered by the generator set engine starting battery.

When the generator set master switch is in the AUTO position, the controller may power down after a period of inactivity. The controller's communication parameter (Cn) setting determines the power down mode. See the generator set installation manual for controller configuration information.

48-hour power down (default setting). If the ADC 2100 communication parameter is set to Cn00, the controller automatically powers down after 48 hours of inactivity. A remote start signal (from a transfer switch or a remote start/stop switch connected to P21 connector, leads 3 and 4) or moving the generator set master switch to the RUN position turns the controller back on.

Continuous power mode. If the ADC 2100 communication parameter is set to Cn01, the controller will not power down. The controller remains powered at all times to maintain CANbus communication and to allow remote start commands from a remote CAN gauge. A battery charger is recommended to maintain the engine starting battery.

Note: The ADC 2100 draws 250 mA when the master switch is in the AUTO position and the unit is configured for CAN communication.

1-hour power down. Setting the communications parameter to Cn06 will cause the controller to power down after 1 hour of inactivity. In this mode, a remote digital gauge using CAN communication will not be able to activate the controller after power down. A remote start signal (from a transfer switch or a remote start/stop switch connected to P21 connector, leads 3 and 4) or moving the generator set master switch to the RUN position turns the controller back on. Controller application code version 1.21 or higher is required for the 1-hour power down option.

TP-6728 10/11 Section 2 Operation 19

20 Section 2 Operation TP-6728 10/11

General Maintenance 3.1

WARNING

Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.



Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Servicing the generator set when it is operating. Exposed moving parts can cause severe injury or death. Keep hands, feet, hair, clothing, and test leads away from the belts and pulleys when the generator set is running. Replace guards, screens, and covers before operating the generator

The engine and generator set may use both American Standard and metric hardware. Use the correct size tools to prevent rounding of the bolt heads and nuts.

See the Safety Precautions and Instructions at the beginning of this manual before attempting to service, repair, or operate the generator set. Have an authorized distributor/dealer perform generator set service.

Engine Service. Perform generator set engine service at the intervals specified by the engine operation manual.

Generator Set Service. Perform generator set service at the intervals specified by the generator set operation manual.

If the generator set operates under dusty or dirty conditions, use dry compressed air to blow dust out of the alternator. With the generator set running, direct the stream of air in through the cooling slots at the alternator

Routine Maintenance. Refer to the following generator set service schedule, the engine service schedule, and the runtime hours shown on the ADC2100 to determine when to schedule routine maintenance. Service generator sets that are subject to extreme weather or dusty or dirty conditions more frequently.

Maintenance and Service Parts. Obtain maintenance and service parts from an authorized Kohler distributor/dealer.

3.2 Service Schedule

Perform maintenance on each item in the service schedule at the designated intervals for the life of the generator set.

Perform Service at Intervals Indicated (X)	Reference Section	Before Starting	Weekly	100 Hr. (3 Mo.)	300 Hr. (6 Mo.)	400 Hr. (Yearly)
Fuel System			_			
Check the fuel level and fill as necessary (LP)	2.1	X				
Check the solenoid valve operation *			X			
Check the fuel lines and replace as necessary *					X	
Lubrication System						
Check the crankcase oil level and add oil as necessary	3.3.2	X 24 hr.				
Replace the oil in the crankcase	3.3.5			X 150 hr.		
Replace the lube oil filter element	3.3.5			X 150 hr.		
Cooling System	'		'	1	II.	
Check the coolant level and fill as necessary	3.6.1	X				
Inspect the radiator and hoses		Х				
Check the belt tension and condition *	3.9			X		
Check the coolant protection and tighten hose clamps *	3.6.1					Х
Flush the cooling system *	3.6.4					X 1000 h
Ignition System	"	11		1.	II.	
Clean and regap the spark plugs	3.7				Х	
Replace the spark plugs	3.7					X 1000 h
Intake/Exhaust System						
Inspect the exhaust system components *	3.5	X				
Check the installation and operation of CO detectors	3.5	Х				
Check the exhaust gas condition during operation	3.5	Х				
Inspect and clean the air cleaner element	3.4			Х		
Replace the air cleaner element	3.4					Х
Inspect the complete exhaust system ‡	3.5					Х
Electrical System		II.	"	1.	l .	
Keep the battery charged and in good condition §	3.8	Х				
Check and tighten electrical connections			Х			
Clean the battery cables as required *		Х				
Engine and Mounting			'	I		
Check for fuel, coolant, and oil leakage *†		Х				
Retighten all nuts and bolts as required		Х				
Check tightness of mounting bolts/vibromounts				Х		
Remote Control System	1	L	<u> </u>	1	1	· ·
Check the remote control operation			Х			X
Generator			<u>l</u>	1	<u></u>	•
Test run the generator set	2.2		Х			
Blow dust out of the generator *	3.1					Х
Clean collector ring and inspect brushes *						X 1000 h

[†] Read WARNING found at the beginning of manual regarding moving parts

 $[\]S$ Consult battery manufacturer's instructions.

3.3 Lubrication System

3.3.1 Oil Specifications

Use oil that displays the American Petroleum Institute (API) Starburst certification mark FOR GASOLINE ENGINES on the container. Do not use oils that are specifically formulated for diesel engines. CC or CD classification oils, even when labeled Heavy Duty or For Natural Gas Engines are not acceptable.

Multi-viscosity oils are recommended. Figure 3-1 shows the recommended Society of Automotive Engineers (SAE) viscosity designation for a given operating temperature.

Ambient Temperature	SAE Viscosity Grade		
-18°C (0°F) or above	10W-30		
Below -18°C (0°F)	5W-30		

Figure 3-1 Engine Oil Selection

3.3.2 Oil Check

Check the oil level in the crankcase every 24 hours of operation or before each startup to ensure that the level is in the safe range. Do not check the oil level while operating the unit. Stop the generator set and keep the generator set level to get an accurate reading. To check the oil level, remove the dipstick and wipe the end clean. reinsert and remove. Maintain the oil level between the Full and Add marks on the dipstick, as shown in Figure 3-2. See Section 1, Service Views for the dipstick location.

Note: Do not operate the set if the oil level is below the Add mark or above the Full mark on the dipstick.




Figure 3-2 Oil Level Check

3.3.3 **Optional Oil Makeup Kit**

On 30 kW generator sets equipped with the optional oil makeup kit, check the oil level in the oil reservoir and at the sight gauge. Refer to the instructions provided with the oil makeup kit for more information.

Oil Additions 3.3.4

Adding some oil between oil changes is normal. The amount varies with generator set usage. Open the oil fill cap and pour in a small amount of oil using a funnel or other suitable pouring device. See Section 1, Service Views, for the oil check and oil fill locations.

3.3.5 Oil and Filter Change

Change the oil according to the service schedule or before generator set storage. Change the oil more frequently if the generator set operates under dirty. dusty conditions. Change the oil while the engine is still warm. See Figure 3-3 for oil capacity. See Section 1, Service Views, for oil fill, oil check, and oil filter locations.

Oil Change Procedure

Whenever possible, drain the oil while it is still warm.

1. Drain the oil.

- a. Place the generator set master switch in the OFF position.
- b. Disconnect the power to the battery charger, if equipped.
- c. Disconnect the generator set engine starting battery, negative (-) lead first.
- d. Remove the housing side panel.
- e. Place an oil collection container below the oil drain and remove the oil drain plug.
- f. Open the oil drain valve on the engine.
- g. Allow time for the engine oil to drain completely.
- h. Close the oil drain valve.
- i. Replace the oil drain plug. Replace the cap on the oil drain hose. Replace the oil drain hose in its retaining clip.

2. Replace the oil filter.

- a. Remove the oil filter by rotating counterclockwise with an oil filter wrench.
- b. Clean the contact surface of the oil filter adapter.
- c. Apply a light coat of clean oil to the rubber seal of the new oil filter.
- d. Install the new oil filter following the instructions provided with the filter.

Note: Dispose of all waste materials (engine oil, fuel, filter, etc.) in an environmentally safe manner.

3. **Fill with oil.** See Figure 3-1 for oil selection and Figure 3-3 for oil capacity.

Model	Oil Capacity, L (qt.)		
15/30 kW	3.5 (3.7)		
30 kW with oil makeup kit	5.4 (5.7)		

Figure 3-3 Oil Capacity (with Filter)

4. Check for leaks.

- a. Check that the generator set master switch is in the OFF position.
- b. Reconnect the generator set engine starting battery, negative (-) lead last.
- c. Reconnect the power to the battery charger, if equipped.
- d. Start the generator set and check for leaks around the oil filter.
- e. Stop the generator set and tighten the oil filter to stop any leaks.
- f. Reinstall the housing side panel.
- 5. Stop the generator set. Check the oil level. Add oil, as necessary, to bring the level up to the Full mark.

Note: Too high an oil level causes high oil consumption and engine carbonizing. Too low a level damages the engine.

3.4 Air Cleaner

At the interval specified in the service schedule, inspect, clean, *or replace* the air cleaner element. Clean the element more frequently in dirty, dusty conditions. Check the element for accumulated oil or dirt that could cause poor performance. Replace a damaged air cleaner element. Follow the procedure described below.

Air Cleaner Service Procedure

A dry-type air cleaner silences and filters the intake air. The air intake silencer assembly connects to the intake manifold via a flexible hose. Refer to Figure 3-4 during this procedure.

- Release the spring clips to open the housing and remove the air silencer element.
- Tap the element lightly against a flat surface to dislodge loose surface dirt. Do not clean the element in any liquid or use compressed air as these will damage the filter element.
- 3. Examine the element and housing for damage. Replace the element or housing if necessary.
- Wipe the cover and housing with a clean rag to remove dirt. Make sure the sealing surfaces fit correctly and reattach the spring clips.




Figure 3-4 Air Cleaner

3.5 Exhaust System



Carbon monoxide. Can cause severe nausea. fainting, or death.

The exhaust system must be leakproof and routinely inspected.

Carbon monoxide detectors. Carbon monoxide can cause severe nausea, fainting, or death. Install carbon monoxide detectors on each level of the building. Locate the detectors to adequately warn the building's occupants of the presence of carbon monoxide. Keep the detectors operational at all times. Periodically test and replace the carbon monoxide detectors according to the manufacturer's instructions.

At the interval specified in the service schedule, inspect the exhaust system components (exhaust manifold, exhaust outlet, exhaust line, exhaust clamps, and muffler) for cracks, leaks, and corrosion.

Exhaust System Inspection Points

- Check for corroded or broken metal parts and replace them as needed.
- Check for loose, corroded, or missing clamps and hangers. Tighten or replace the exhaust clamps and/or hangers as needed.
- Check that the exhaust outlet is unobstructed.
- Check the exhaust gas color. If the exhaust is blue or black, contact your local distributor/dealer.
- Visually inspect for exhaust leaks (blowby). Check for carbon or soot residue on exhaust components. Carbon and soot residue indicates an exhaust leak. Seal leaks as needed.
- Check the installation and operation of carbon monoxide (CO) detectors.

3.6 Cooling System



Hot coolant and steam. Can cause severe injury or death.

Before removing the pressure cap, stop the generator set and allow it to cool. Then loosen the pressure cap to relieve pressure.

Allow the engine to cool. Release pressure from the cooling system before removing the pressure cap. To release pressure, cover the pressure cap with a thick cloth and then slowly turn the cap counterclockwise to the first stop. Remove the cap after pressure has been completely released and the engine has cooled. Check the coolant level at the tank if the generator set has a coolant recovery tank.

3.6.1 **Checking and Filling Coolant**

Maintain the coolant level in the coolant overflow bottle between the High and Low markings. See Section 1, Service Views, for the coolant overflow bottle location.

Note: Periodically check the coolant level by removing the radiator's pressure cap. Do not rely solely on the level in the coolant overflow bottle. Add fresh coolant until the level is just below the overflow tube opening.

When checking the coolant level, also check the rubber seal of the radiator's pressure cap and replace a cracked or deteriorated cap. The pressure cap raises the boiling point of the coolant, enabling higher operating temperatures. If the cap leaks, replace it with the same rating type of cap. Find the pressure cap rating in Figure 3-6. Remove dirt and other debris from the pressure cap and filler neck.

To prevent generator shutdown or damage because of overheating, keep the cooling air inlets clean and unobstructed at all times. Inspect the radiator's exterior for obstructions and remove dirt and foreign material with a soft brush or cloth to avoid damaging the radiator fins. Check the hoses and connections for leaks and replace any cracked, frayed, or spongy hoses.

3.6.2 **Draining Cooling System**

The radiator contains a coolant drain valve to drain the cooling system. When draining the coolant, remove the radiator's pressure cap: this will allow the entire system to drain and will prevent air pockets from forming and restricting coolant passage to the block.

Note: Pay special attention to the coolant level. After the coolant drains, allow time for complete refill of the engine water jacket. Check the coolant level as described earlier.

3.6.3 Filling Cooling System

1. Close the radiator's coolant drain valve and tighten the hose clamps.

Note: Do not add coolant to a hot engine. Adding coolant to a hot engine can cause the cylinder block or cylinder head to crack. Wait until engine has cooled.

2. Fill the radiator with the recommended coolant mixture of 50% ethylene glycol and 50% clean, softened water to inhibit rust/corrosion and prevent freezing. See Figure 3-5 for coolant capacity

Note: A coolant solution of 50% ethylene glycol provides freezing protection to -37°C (-34°F) and overheating protection to 129°C (265°F). A coolant solution with less than 50% ethylene glycol may not provide adequate freezing and overheating protection. A coolant solution with more than 50% ethylene glycol can cause engine or component damage. Do not use alcohol or methanol antifreeze or mix them with the specified coolant. Consult the engine manufacturer's operation manual for engine coolant specifications.

- 3. Operate the engine with the radiator cap removed until the thermostat opens and the radiator upper hose becomes hot.
- 4. Stop the engine and allow it to cool.

Model	Coolant Capacity L (gal.)			
All models	11.5 L (3.0 gal.)			

Figure 3-5 Coolant Capacity

- 5. Add coolant to the radiator to just below the overflow tube on the filler neck. See Section 1, Service Views, for the overflow tube location.
- 6. Replace the radiator's pressure cap.
- 7. Maintain the coolant level in the coolant overflow bottle between the High and Low markings. See Section 1, Service Views, for the coolant overflow bottle location.

Note: Periodically check the coolant level by removing the radiator's pressure cap. Do not rely solely on the level in the coolant overflow bottle. Add fresh coolant until the level is just below the overflow tube opening.

3.6.4 Flushing and Cleaning

For optimum protection, drain, flush, and refill the cooling system at the interval listed in the service schedule.

Flushing and Cleaning Procedure

- 1. Remove the pressure cap and open the radiator's coolant drain valve and let the system drain completely. Remove the pressure cap to simplify draining.
- 2. Drain, clean, and flush the coolant overflow bottle.
- 3. Flush the system with clean water.
- 4. Close the radiator's coolant drain valve.
- 5. Fill the system with the recommended coolant.
- 6. Replace the pressure cap.

3.6.5 **Pressure Cap**

The cooling system utilizes a pressure cap to raise the boiling point of the coolant, enabling higher operating temperatures. If the cap leaks, replace it with a cap of the same rating. Find the pressure cap rating in Figure 3-6.

Item	Rating
Pressure Cap	97 kPa (14 psi)
Thermostat	91°C (195°F)

Figure 3-6 Pressure Cap and Thermostat Rating

3.7 Ignition System

Service the spark plugs at the interval specified in the service schedule using the following procedure.

- 1. Remove spark plug wires by grasping the spark plug boot and turning slightly while pulling. Do not pull the wire. Pulling on the wire rather than the boot may damage the wire or terminal.
- 2. Loosen the spark plug with a ratchet and 5/8-in. spark plug socket with a rubber insert to prevent spark plug damage.
- 3. Use compressed air to remove dirt from around each spark plug to prevent dirt particles from falling into the combustion chamber.
- 4. Remove spark plugs, one at a time, and examine. Identify a normal spark plug in good operating condition by observing a light tan or gray deposit on the firing tip. See Figure 3-9 to evaluate engine condition by color/condition of a problem spark
- 5. Clean spark plugs by wiping them with a rag. File the center electrode to keep it parallel to the side electrode.

Note: Do not sandblast, wire brush, scrape, or otherwise service spark plug in poor condition. Obtain a new plug for best results.

6. Check the spark plug gap before installing any spark plug. See Figure 3-7 and Figure 3-8. Attain a correct gap when the feeler (or wire) passes between the spark plug electrode. It should pass easily but with some resistance or drag; otherwise adjust as necessary.

Model	Spark plug gap		
15/30 kW	0.9 mm (0.035 in.)		

Figure 3-7 Recommended Spark Plug Gap




Figure 3-8 Spark Plug Gap Inspection

Problem/Condition	Means of Identification	Possible Cause/Solution
Gap-bridged spark plug	Built-up deposits and gap between electrodes closing.	Oil or carbon fouling. Clean and regap the spark plug.
Oil-fouled spark plug	Wet, black deposits on the insulator shell, bore, and electrodes.	Excessive oil entering combustion chamber through worn rings and pistons, excessive clearance between valve guides and stems, or worn or loose bearings. Replace the spark plug.
Carbon-fouled spark plug	Black, dry, fluffy carbon deposits on insulator tips, exposed shell surfaces and electrodes.	Incorrect spark plug, weak ignition, clogged air intake, overrich fuel mixture, or excessive no-load operation. Clean and regap the spark plug.
Lead-fouled spark plug	Dark gray, black, yellow, or tan deposits; or a glazed coating on the insulator tip.	Caused by highly leaded fuel. Replace the spark plug.
Preignition damaged spark plug	Melted electrodes and possibly blistered insulator. Metallic deposits on insulator suggest internal engine damage.	Wrong type of fuel, incorrect timing or advance, too hot a plug, burned valves, or engine overheating. Replace the spark plug.
Overheated spark plug	White or light gray insulator with small black or gray/brown spots with bluish (burned) appearance on electrodes.	Engine overheating, wrong type of fuel, loose spark plugs, too hot a plug, low fuel pressure or incorrect ignition timing. Replace the spark plug.
Worn spark plug	Severely eroded or worn electrodes.	Caused by normal wear and failure to replace spark plug at prescribed interval. Replace the spark plug.

Figure 3-9 Engine Evaluation Using Spark Plug Condition

7. Use a gapping tool to gently bend side electrode closer to or farther from the center electrode to set the correct gap. See Figure 3-10. Position the side electrode directly over the center electrode.




Figure 3-10 Spark Plug Gap Adjustment

- 8. Reinstall the spark plug. Do not bump the electrode against the cylinder head. Rotate the spark plug clockwise until you feel resistance.
- 9. Use a torque wrench to torque each spark plug to 25 Nm (18 ft. lbs.). Otherwise, hand-tighten the spark plug until you feel resistance.
- 10. Use a ratchet wrench to final tighten an additional 1/4 turn. Do not overtighten, as doing so may strip the threads or alter the electrode gap setting.
- Check the spark plug wire connector in the boot for accumulated dirt, grease, and other debris, and clean as necessary.
- 12. Firmly push spark plug boot onto the spark plug.

3.8 Battery

Consult the battery manufacturer's instructions regarding battery care and maintenance.

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

3.9 Belt Check

Check the belt tension at the intervals specified in the service schedule. If the tension is not within specification, adjust as necessary using the following procedure.

Adjust the tension of the alternator/fan belt so that the belt can be depressed about 7-10 mm (0.3-0.4 in.) when applying finger pressure. Use the following procedure to adjust the belt.




Figure 3-11 Belt Tension

Belt Tensioning Procedure

- 1. Disconnect the battery, negative lead first.
- 2. Loosen the pivot and adjusting screws.
- 3. While prying the battery charging alternator outward, tighten the adjusting screw.

- 4. Tighten the pivot screw.
- 5. Recheck and adjust as necessary.
- 6. Reconnect the battery, negative lead last.

Note: Also check the fan belt for cracks or tears and replace the belt if necessary.

3.10 Storage Procedure

Follow the procedure below when storing your generator set for a long period (3 months or more).

- 1. Start and run the generator set until it reaches operating temperature or about 15 minutes.
- 2. Stop the generator set.
- 3. Change the oil and oil filter; see Section 3.3.5, Oil and Filter Change.
- 4. Drain the fuel completely from the fuel tank to prevent accumulated moisture from mixing with the fuel.
- 5. Check the engine coolant protection; see Section 3.6.

Note: Use antifreeze capable of withstanding the lowest possible temperatures.

- 6. Keep spark plugs in their holes or seal spark plug holes with suitable threaded metal plugs.
- 7. Clean the exterior of the generator set and spread a light film of oil or silicon spray over any exposed surfaces that may be subject to rust or corrosion.
- 8. Seal the air inlet, exhaust pipe, and fuel tank cap with tape.
- 9. Disconnect and remove the battery. Place the battery in a warm, dry location for the storage period. Recharge the battery once a month to maintain a full charge.
- 10. Select a well-ventilated (not humid or dusty) location to store the generator.
- 11. Cover the entire unit with a dust cover.

Note: Run the generator set once a month whenever possible.

4.1 Introduction

Use the following charts to diagnose and correct common problems. First check for simple causes such as a dead engine starting battery, loose connections, or an open circuit breaker. The charts include a list of common problems, possible causes of the problem, and recommended corrective actions.

If the procedures in this manual do not explain how to correct the problem, contact an authorized distributor/ dealer. Maintain a record of repairs and adjustments performed on the equipment. Use the record to help describe the problem and repairs or adjustments made to the equipment.

Circuit Protection 4.2

If the generator set circuit breaker trips or the fuses blow repeatedly, see Section 4, Troubleshooting, for possible causes.

4.2.1 Line Circuit Breaker

A line circuit breaker interrupts the generator output in the event of a fault in the wiring between the generator and the load. The line circuit breaker location is shown in Figure 1-1. If the circuit breaker trips, reduce the load and switch the breaker back to the ON position.

4.2.2 **Fuses**

The engine harness contains three 10-amp inline fuses. Four additional fuses are located inside the engine fuse box. See the service views in Section 1 for the fuse locations.

Always identify and correct the cause of a blown fuse before restarting the generator set. Refer to section 4, Troubleshooting, for conditions that may indicate a blown fuse. Obtain service from an authorized distributor/dealer.

F1 Auxiliary Winding Fuse. A replaceable 10-amp fuse protects the alternator.

F2 Relay Fuse. A replaceable 10-amp fuse protects the engine relays. If the generator set does not crank, check the battery and battery connections and then check the relay fuse.

F3 Controller Fuse. A replaceable 10-amp fuse protects the controller circuitry. If the controller display is

dark, check the battery and battery connections and then check the controller fuse.

Engine Fuses. Four engine fuses are located in the engine fuse box. Contact your distributor or dealer for replacement fuses.

Fuse	Description	Part Number
F1	10 Amp Auxiliary Winding	358337
F2	10 Amp Relay Interface Board	223316
F3	10 Amp Controller	223316

Figure 4-1 Generator Set Fuses

4.3 Faults

4.3.1 **Fault Codes**

The Advanced Digital Control displays fault codes to aid in troubleshooting. Fault codes, descriptions, and recommended checks are listed in Figure 2-4.

Identify and correct the cause of the fault condition. Then reset the controller after a fault shutdown. See Section 2.3.5.

4.3.2 **Fault History**

Use the following procedure to view the last 20 fault codes on the ADC 2100 controller.

Procedure to View Fault History

- 1. Press and HOLD the Select button on the controller. Move the generator set master switch to the RUN position. (The generator set engine will not start.)
 - Continue to hold the select button until the software version number (vX.XX) is displayed on the controller.
- 2. Release the Select button.
- 3. Press and HOLD both arrow buttons until F 1 is displayed, indicating the most recent fault.
- 4. Press the UP arrow button to the view the fault code.
- 5. Press UP again to view the generator run time hours at the time of the fault.
- 6. Press UP to step to the next fault.

- 7. Repeat steps 4 through 6 to step through the last 20 faults. Press the Select button to return to the most recent fault, if desired.
- 8. To exit, move the generator set master switch to the OFF/RESET position.

4.4 Generator Set Troubleshooting

Figure 4-2 contains generator set troubleshooting, diagnostic, and repair information. Check for loose connections before replacing parts.

Problem	Possible Cause	Corrective Action	
The generator set	Battery weak or dead	Recharge or replace the battery.	
does not crank	Battery connections reversed or poor	Check the connections.	
	Controller fuse (F3) blown	Replace the fuse. Contact an authorized	
	Relay interface board fuse (F2) blown	distributor/dealer for service if fuse blows	
	Engine fuse blown.	repeatedly.	
	Generator set master switch in the OFF position	Move the master switch to the RUN position.	
The generator set	Air cleaner clogged	Clean and/or replace the air cleaner.	
cranks but does not	Battery weak or dead	Recharge or replace the battery.	
start, starts hard, lacks power, or	Battery connection poor	Clean and tighten the battery connections.	
operates erratically	Spark plug wire connection loose	Check the spark plug wires.	
operates stratisting	Low oil pressure shutdown	Check the oil level.	
	Fuel pressure insufficient	Check the fuel supply and valves.	
	Engine fuse blown.	Replace the fuse. Contact an authorized distributor/dealer for service if fuse blows repeatedly.	
	Engine malfunction	Contact the distributor/dealer.	
No AC output	AC circuit breaker in the OFF position	Place the circuit breaker in the ON position.	
	AC circuit breaker tripping because of overload	Reduce the load on the generator set.	
	AC circuit breaker tripping because of short circuit	Contact an authorized distributor/dealer for service.	
	Auxiliary winding fuse (F1) blown	Replace the fuse. Contact an authorized distributor/dealer for service if fuse blows	
	Engine fuse blown.	repeatedly.	
Low output or excessive drop in voltage	Generator set overloaded	Reduce the load.	
Generator set stops	Low oil pressure shutdown	Check the oil level.	
suddenly	Out of fuel	Check fuel supply.	
	Overcrank shutdown	Reset the controller. If the overcrank fault occurs again, contact the distributor/dealer.	
	Controller fuse (F3) blown	Replace the fuse. If the fuse blows again, contact the distributor/dealer.	
	Overspeed shutdown	Reset the controller. If the overspeed fault occurs again, contact the distributor/dealer.	
	Generator set master switch in the OFF/RESET position	Move the switch to the correct position (RUN or AUTO).	
	Remote stop command received from a remote switch, remote digital gauge, or ATS	Check the remote switch position.	
	Engine malfunction	Contact the distributor/dealer.	
	Engine fuse blown.	Replace the fuse. Contact an authorized distributor/dealer for service if fuse blows repeatedly.	
	Auxiliary winding fuse (F1) blown	Replace the fuse. Contact an authorized distributor/ dealer for service if fuse blows repeatedly.	

Figure 4-2 General Troubleshooting Chart

32 Section 4 Troubleshooting TP-6728 10/11

4.5 Controller Troubleshooting

Figure 4-3 contains troubleshooting, diagnostic, and repair information for the Advanced Digital Control.

Problem	Possible Cause	Corrective Action	
Controller LED display is off	Controller may power down if the generator set has not run in the last hour of 48 hours, depending on the controller's Cn parameter setting. See Section 2.3.6, Controller Power Down.	Controller display will automatically activate when a remote start command is received or the generator set master switch is moved to the RUN position.	
Controller fuse (F3) is blown.		Replace the fuse. If the fuse blows again, contact the distributor/dealer.	
	Low or no battery voltage.	Check connections. Check generator set battery. See Figure 4-2.	
	Generator set master switch is in the OFF/RESET position.	Move generator set master switch to the AUTO or RUN position.	

Figure 4-3 ADC 2100 Troubleshooting Chart

TP-6728 10/11 Section 4 Troubleshooting 33

34 Section 4 Troubleshooting TP-6728 10/11

Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

	• · · · · · · · · · · · · · · · · · · ·				
A, amp	ampere	cfm	cubic feet per minute	exh.	exhaust
ABDC	after bottom dead center	CG	center of gravity	ext.	external
AC	alternating current	CID	cubic inch displacement	F	Fahrenheit, female
A/D	analog to digital	CL	centerline	FHM	flat head machine (screw)
ADC	advanced digital control;	cm	centimeter	fl. oz.	fluid ounce
od:	analog to digital converter	CMOS	complementary metal oxide	flex.	flexible
adj.	adjust, adjustment		substrate (semiconductor)	freq.	frequency
ADV	advertising dimensional	com	communications (port)	FS	full scale
۸h	drawing	coml	commercial	ft.	foot, feet
Ah AHWT	amp-hour anticipatory high water		Commercial/Recreational	ft. lb.	foot pounds (torque)
ALIVVI	temperature	conn.	connection	ft./min.	feet per minute
AISI	American Iron and Steel	cont.	continued	ftp	file transfer protocol
71101	Institute	CPVC	chlorinated polyvinyl chloride	g	gram
ALOP	anticipatory low oil pressure	crit.	critical	ga.	gauge (meters, wire size)
alt.	alternator	CSA	Canadian Standards Association	gal.	gallon
Al	aluminum	СТ	current transformer	gen.	generator
ANSI	American National Standards	Cu	copper	genset	generator set
	Institute (formerly American	cUL	Canadian Underwriter's	GFI	ground fault interrupter
	Standards Association, ASA)	COL	Laboratories	GND, 🕌	ground
AO	anticipatory only	CUL	Canadian Underwriter's	gov.	governor
APDC	Air Pollution Control District	OOL	Laboratories	gph	gallons per hour
API	American Petroleum Institute	cu. in.	cubic inch	gpm	gallons per minute
approx.	approximate, approximately	CW.	clockwise	gr.	grade, gross
APU	Auxiliary Power Unit	CWC	city water-cooled	ĞRD	equipment ground
AQMD	Air Quality Management District	cyl.	cylinder	gr. wt.	gross weight
AR	as required, as requested	D/A	digital to analog		height by width by depth
AS	as supplied, as stated, as	DAC	digital to analog converter	HC	hex cap
	suggested	dB	decibel	HCHT	high cylinder head temperature
ASE	American Society of Engineers	dB(A)	decibel (A weighted)	HD	heavy duty
ASME	American Society of	DC DC	direct current	HET	high exhaust temp., high
	Mechanical Engineers	DCR	direct current resistance		engine temp.
assy.	assembly	deg., °	degree	hex	hexagon
ASTM	American Society for Testing	degt.	department	Hg	mercury (element)
	Materials	dept. dia.	diameter	ΗŇ	hex head
ATDC	after top dead center	DI/EO	dual inlet/end outlet	HHC	hex head cap
ATS	automatic transfer switch	DIN	Deutsches Institut fur Normung	HP	horsepower
auto.	automatic	DIN	e. V. (also Deutsche Industrie	hr.	hour
aux.	auxiliary		Normenausschuss)	HS	heat shrink
avg.	average	DIP	dual inline package	hsg.	housing
AVR	automatic voltage regulator	DPDT	double-pole, double-throw	HVAC	heating, ventilation, and air
AWG	American Wire Gauge	DPST	double-pole, single-throw		conditioning
AWM	appliance wiring material	DS	disconnect switch	HWT	high water temperature
bat.	battery	DVR	digital voltage regulator	Hz	hertz (cycles per second)
BBDC	before bottom dead center	E ² PROM,	FERROM	IBC	International Building Code
BC	battery charger, battery	,	electrically-erasable	IC	integrated circuit
	charging		programmable read-only	ID	inside diameter, identification
BCA	battery charging alternator		memory	IEC	International Electrotechnical
BCI	Battery Council International	E, emer.	emergency (power source)		Commission
BDC	before dead center	ECM	electronic control module,	IEEE	Institute of Electrical and
BHP	brake horsepower		engine control module		Electronics Engineers
blk.	black (paint color), block	EDI	electronic data interchange	IMS	improved motor starting
	(engine)	EFR	emergency frequency relay	in.	inch
blk. htr.	block heater	e.g.	for example (exempli gratia)	in. H ₂ O	inches of water
BMEP	brake mean effective pressure	EG	electronic governor	in. Hg	inches of mercury
bps	bits per second	EGSA	Electrical Generating Systems	in. lb.	inch pounds
br.	brass		Association	Inc.	incorporated
BTDC	before top dead center	EIA	Electronic Industries	ind.	industrial
Btu	British thermal unit	FUEO	Association	int.	internal
Btu/min.	British thermal units per minute	EI/EO	end inlet/end outlet	int./ext.	internal/external
C.	Celsius, centigrade	EMI	electromagnetic interference	I/O	input/output
cal.	calorie	emiss.	emission	IP	internet protocol
CAN	controller area network	eng.	engine	ISO	International Organization for
CARB	California Air Resources Board	EPA	Environmental Protection		Standardization
CAT5	Category 5 (network cable)	EDC	Agency	J	joule
CB	circuit breaker	EPS	emergency power system	JIS	Japanese Industry Standard
CC	crank cycle	ER	emergency relay	k	kilo (1000)
CC	cubic centimeter	ES	engineering special,	K	kelvin
CCA	cold cranking amps	ESD	engineered special electrostatic discharge	kA	kiloampere
CCW.	counterclockwise	est.	estimated	KB	kilobyte (2 ¹⁰ bytes)
CEC	Canadian Electrical Code	E-Stop	emergency stop	KBus	Kohler communication protocol
cert.	certificate, certification, certified	etc.	et cetera (and so forth)	kg	kilogram
cfh	cubic feet per hour	010.	S. Soloia (and So ioili)		

TP-6728 10/11 Appendix 35

kg/cm ²	kilograms per square	NBS	National Bureau of Standards	RTU	remote terminal unit
kg/ciii	centimeter	NC	normally closed	RTV	room temperature vulcanization
kgm	kilogram-meter	NEC	National Electrical Code	RW	read/write
kg/m ³	kilograms per cubic meter	NEMA	National Electrical	SAE	Society of Automotive
kHz	kilohertz	INCIVIA	Manufacturers Association	SAL	Engineers
kJ		NFPA	National Fire Protection	scfm	•
	kilojoule	INFFA	Association	SCR	standard cubic feet per minute
km	kilometer	Nm	newton meter		silicon controlled rectifier
	2 kilo-ohm	NO	normally open	s, sec.	second
kPa	kilopascal		number, numbers	SI	Systeme international d'unites, International System of Units
kph	kilometers per hour	no., nos. NPS	National Pipe, Straight	SI/EO	side in/end out
kV	kilovolt	NPSC	National Pipe, Straight coupling	sil.	silencer
kVA	kilovolt ampere		National Pipe, Straight-coupling	SII. SMTP	
kVAR	kilovolt ampere reactive	NPT	National Standard taper pipe thread per general use		simple mail transfer protocol
kW	kilowatt	NPTF	National Pipe, Taper-Fine	SN	serial number
kWh	kilowatt-hour	NR	not required, normal relay	SNMP	simple network management protocol
kWm	kilowatt mechanical		nanosecond	SPDT	•
kWth	kilowatt-thermal	ns OC	overcrank	SPST	single-pole, double-throw
L	liter	OD			single-pole, single-throw
LAN	local area network		outside diameter	spec	specification
	I length by width by height	OEM	original equipment manufacturer	specs	specification(s)
lb.	pound, pounds	OF	overfrequency	sq.	square
lbm/ft ³	pounds mass per cubic feet	opt.	option, optional	sq. cm	square centimeter
LCB	line circuit breaker	OS	oversize, overspeed	sq. in.	square inch
LCD	liquid crystal display	OSHA	Occupational Safety and Health	SMS	short message service
LED	light emitting diode	USHA	Administration	SS	stainless steel
Lph	liters per hour	OV		std.	standard
Lpm	liters per minute		overvoltage	stl.	steel
LOP	low oil pressure	OZ.	ounce	tach.	tachometer
LP	liquefied petroleum	p., pp.	page, pages	TB	terminal block
LPG	liquefied petroleum gas	PC	personal computer	TCP	transmission control protocol
LS	left side	PCB	printed circuit board	TD	time delay
L _{wa}	sound power level, A weighted	pF	picofarad	TDC	top dead center
LWL	low water level	PF	power factor	TDEC	time delay engine cooldown
LWT	low water temperature	ph., ∅	phase	TDEN	time delay emergency to
m	meter, milli (1/1000)	PHC	Phillips® head Crimptite®		normal
M	mega (10 ⁶ when used with SI	DUIL	(screw)	TDES	time delay engine start
	units), male	PHH	Phillips® hex head (screw)	TDNE	time delay normal to
m ³	cubic meter	PHM	pan head machine (screw)		emergency
m ³ /hr.	cubic meters per hour	PLC	programmable logic control	TDOE	time delay off to emergency
m ^{3′} /min.	cubic meters per minute	PMG	permanent magnet generator	TDON	time delay off to normal
mÁ	milliampere '	pot	potentiometer, potential	temp.	temperature
man.	manual	ppm	parts per million	term.	terminal
max.	maximum	PROM	programmable read-only	THD	total harmonic distortion
MB	megabyte (2 ²⁰ bytes)		memory	TIF	telephone influence factor
MCCB	molded-case circuit breaker	psi	pounds per square inch	tol.	tolerance
MCM	one thousand circular mils	psig	pounds per square inch gauge	turbo.	turbocharger
meggar	megohmmeter	pt.	pint	typ.	typical (same in multiple
MHz	megahertz	PTC	positive temperature coefficient		locations)
mi.	mile	PTO	power takeoff	UF	underfrequency
	one one-thousandth of an inch	PVC	polyvinyl chloride	UHF	ultrahigh frequency
mil min.	minimum, minute	qt.	quart, quarts	UIF	user interface
misc.	miscellaneous	qty.	quantity	UL	Underwriter's Laboratories, Inc.
MJ		R	replacement (emergency)	UNC	unified coarse thread (was NC)
mJ	megajoule millijoule		power source	UNF	unified fine thread (was NF)
mm	millimeter	rad.	radiator, radius	univ.	universal
	Ωmilliohm	RAM	random access memory	URL	uniform resource locator
	sziriiiioriiri IΩmegohm	RDO	relay driver output		(web address)
,	0	ref.	reference	US	undersize, underspeed
MOV	metal oxide varistor	rem.	remote	UV	ultraviolet, undervoltage
MPa	megapascal	Res/Coml	Residential/Commercial	V	volt
mpg	miles per gallon	RFI	radio frequency interference	VAC	volts alternating current
mph	miles per hour	RH	round head	VAR	voltampere reactive
MS	military standard	RHM	round head machine (screw)	VDC	volts direct current
ms	millisecond	rly.	relay	VFD	vacuum fluorescent display
m/sec.	meters per second	rms	root mean square	VGA	video graphics adapter
mtg.	mounting	rnd.	round	VHF	very high frequency
MTU	Motoren-und Turbinen-Union	RO	read only	W	watt
MW	megawatt	ROM	read only memory	WCR	withstand and closing rating
mW_	milliwatt	rot.	rotate, rotating	w/	with
μF	microfarad	rpm	revolutions per minute	WO	write only
N, norm.	normal (power source)	ŔS	right side	w/o	without
NA	not available, not applicable	RTDs	Resistance Temperature	wt.	weight
nat. gas	natural gas		Detectors	xfmr	transformer

36 Appendix TP-6728 10/11

TP-6728 10/11 37

38 TP-6728 10/11

KOHLER POWER SYSTEMS

KOHLER CO. Kohler, Wisconsin 53044 Phone 920-457-4441, Fax 920-459-1646 For the nearest sales/service outlet in the US and Canada, phone 1-800-544-2444 KohlerPower.com

Kohler Power Systems Asia Pacific Headquarters 7 Jurong Pier Road Singapore 619159 Phone (65) 6264-6422, Fax (65) 6264-6455