Operation

Residential/Commercial Generator Sets



Models: 14/20RES 14/20RESL

Controller:
RDC Residential Digital Control
DC Digital Control
Version 2.08 or higher



KOHLER®
POVER SYSTEMS______ TP-6734 1/11b

California Proposition 65



WARNING

Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Product Identification Information

Product identification numbers determine service parts. Record the product identification numbers in the spaces below immediately after unpacking the products so that the numbers are readily available for future reference. Record field-installed kit numbers after installing the kits.

Generator Set Identification Numbers Record the product identification numbers from the

generator set nameplat	e(s).
Model Designation	
Specification Number _	
Serial Number	
Accessory Number	Accessory Description

Controller Identification

Record the controller description from the generator set operation manual, spec sheet, or sales invoice.
Controller Description
Engine Identification
Record the product identification information from the engine nameplate.
Manufacturer
Model Designation
Serial Number

Table of Contents

Product Identifica	ation	Information 2
Safety Precaution	ns an	d Instructions 5
Introduction		9
Service Assistan	се	
Section 1 Descri	ption	ns and Service Views
	1.1	Introduction
	1.2	Engine
	1.3	Alternator
	1.4	Transfer Switch
	1. 4 1.5	
	-	-
	1.6	Accessories
		1.6.1 Carburetor heater
		1.6.2 OnCuet Home Generator Management System
	1.7	Service Views for Maintenance
Section 2 Operat	tion .	17
:	2.1	Prestart Checklist
2	2.2	Exercising the Generator Set
2	2.3	RDC and DC Generator Set/ Transfer Switch Controllers
:	2.4	Controller Power
:	2.5	Controller Firmware Version
2	2.6	Controls and Indicators
		2.6.1 Controller Keypad
		2.6.2 LED Display
		2.6.3 LED Indicators
:	2.7	Generator Set Operation
		2.7.1 Local Starting and Stopping 20
		2.7.2 Engine Start Crank Cycle
		2.7.3 Engine Cooldown
		2.7.4 Automatic Operation with Model RRT Transfer Switch
		2.7.5 Automatic Operation with Model RDT or RSB Transfer Switches 20
2	2.8	Exercise
		2.8.1 Unloaded Variable-Speed Exercise with Complete System Diagnostics 21
		2.8.2 System Diagnostics
		2.8.3 Loaded Exercise (with RRT only)
		2.8.4 Power Failure During Exercise Cycle
		2.8.5 Exerciser Reset
		2.8.6 Exercise Disable
2	2.9	Test
		2.9.1 Unloaded Test
		2.9.2 Loaded Test (with RRT only)
		2.9.3 Power Failure During Test Cycle
2	2.10	Faults 24
		2.10.1 Warnings 24
		2.10.2 Shutdowns
		2.10.3 ATS Communication Errors
		2.10.4 Resetting the Controller after a Fault Shutdown
		2.10.5 Event History
2	2.11	Model RRT Transfer Switch Operation
		2.11.1 Source Availability
		2.11.2 ATS Control Sequence of Operation
		2.11.3 Time Delays
		2.11.4 Load Control Time Delay

TP-6734 1/11 Table of Contents

Table of Contents, continued

Section 3 Scheduled	Maintenance	29
3.1	Scheduled Maintenance	29
	3.1.1 Service Schedule, 14RES/RESL Models	30
	3.1.2 Service Schedule, 20RES/RESL Models	31
3.2	Lubrication System	32
	3.2.1 Low Oil Pressure Shutdown	32
	3.2.2 Oil Check	32
	3.2.3 Engine Oil Recommendation	32
	3.2.4 Oil Change Procedure	32
	3.2.5 Oil Cooler 20RES/RESL	33
3.3	Spark Plugs	34
3.4	Air Cleaner Service	34
	3.4.1 Air Cleaner, 14RES/RESL Models	34
	3.4.2 Air Cleaner, 20RES/RESL Models	35
3.5	Cooling System	36
3.6	Exhaust System	36
3.7	Battery	37
3.8	Battery Charger	38
	3.8.1 RES Battery Charger	38
3.9	Circuit Protection	39
	3.9.1 Line Circuit Breaker	39
	3.9.2 Fuses	39
3.10	Storage Procedure	40
	3.10.1 Lubricating System	40
	3.10.2 Fuel System	40
	3.10.3 Cylinder Lubrication	40
	· · · · · · · · · · · · · · · · ·	40
	3.10.5 Battery	40
Section 4 Troublesh	poting	41
4.1	Introduction	41
4.2	Controller Service Access	41
4.3	Generator Set Troubleshooting	41
4.4	_	43
Annendix A Ahhreviat		45

Table of Contents TP-6734 1/11

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. SAVE THESE INSTRUCTIONS.

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.



DANGER

Danger indicates the presence of a hazard that will cause severe personal injury, death, or substantial property damage.



WARNING

Warning indicates the presence of a hazard that *can cause severe* personal injury, death, or substantial property damage.



CAUTION

Caution indicates the presence of a hazard that *will* or *can cause minor personal injury* or *property damage*.

NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator Accidental starting can cause severe injury or death. working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

Battery

A

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

▲ WARNING



Explosion.

Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eves or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the batterv charger off disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Engine Backfire/Flash Fire



Fire.
Can cause severe injury or death.

Do not smoke or permit flames or sparks near fuels or the fuel system.

Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner removed.

Servicing the fuel system. A flash fire can cause severe injury or death. Do not smoke or permit flames or sparks near the carburetor, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Catch fuels in an approved container when removing the fuel line or carburetor.

Combustible materials. A fire can cause severe injury or death. Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or BC for electrical fires or recommended by the local fire code or an authorized agency. Train all personnel on fire extinguisher operation and fire prevention procedures.

Exhaust System



Carbon monoxide. Can cause severe nausea, fainting, or death.

The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

monoxide Carbon detectors. Carbon monoxide can cause severe nausea, fainting, or death. Install carbon monoxide detectors on each level of any building adjacent to the generator set. Locate the detectors to adequately warn the building's occupants of the presence of carbon monoxide. Keep the detectors operational at all times. Periodically test and replace the carbon monoxide detectors according to manufacturer's instructions.

Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

Fuel System



Explosive fuel vapors.
Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

The fuel system. Explosive fuel vapors can cause severe injury or death. Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

Gas fuel leaks. **Explosive fuel** vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LP vapor gas or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces per square (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. successful test depends on the ability of the solution to bubble.

Hazardous Noise

▲ CAUTION



Hazardous noise. Can cause hearing loss.

Never operate the generator set without a muffler or with a faulty exhaust system.

Engine noise. Hazardous noise can cause hearing loss. Generator sets not equipped with sound enclosures can produce noise levels greater than 105 dBA. Prolonged exposure to noise levels greater than 85 dBA can cause permanent hearing loss. Wear hearing protection when near an operating generator set.

Hazardous Voltage/ Moving Parts

▲ WARNING





Hazardous voltage. Moving parts. Can cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

▲ WARNING



Hazardous voltage. Backfeed to the utility system can cause property damage, severe injury, or death.

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

CAUTION



Welding the generator set.

Can cause severe electrical equipment damage.

Never weld components of the generator set without first disconnecting the battery, controller wiring harness, and engine electronic control module (ECM).

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power before servicing sources equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Welding on the generator set. Can cause severe electrical equipment Before welding on the damage. generator set perform the following steps: (1) Remove the battery cables, negative (-) lead first. (2) Disconnect all engine electronic control module (ECM) connectors. (3) Disconnect all generator set controller and voltage regulator circuit board connectors. (4) Disconnect the engine batterycharging alternator connections. (5) Attach the weld ground connection close to the weld location.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death. Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.

Heavy Equipment



Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.

Do not use lifting eyes.

Lift the generator set using lifting bars inserted through the lifting holes on the skid.

Hot Parts



Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Servicing the engine heater. Hot parts can cause minor personal injury or property damage. Install the heater before connecting it to power. Operating the heater before installation can cause burns and component damage. Disconnect power to the heater and allow it to cool before servicing the heater or nearby parts.

Notice

NOTICE

Canadian installations only. For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code, Part 1.

This manual provides operation and maintenance instructions for residential/commercial model 14/20RES and RESL generator sets equipped with Residential Digital Control (RDC) or Digital Control (DC) generator set/transfer switch controllers. The RDC and DC controllers control the generator set and the optional Model RRT transfer switch. See Figure 1.

This generator set is approved for use in stationary applications in locations served by a reliable utility power source. Have the generator set installed by an authorized distributor/dealer or service technician. Refer to TP-6733, Installation Manual, for installation instructions.

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual. Keep this manual with the equipment for future reference.

The equipment service requirements are very important to safe and efficient operation. Inspect the parts often and perform required service at the prescribed intervals. Obtain service from an authorized service distributor/ dealer to keep equipment in top condition.



Figure 1 RES/RESL Generator Set and Optional Model RRT Transfer Switch

List of Related Literature


Figure 2 identifies related literature available for the generator sets covered in this manual. Only trained and qualified personnel should install or service the generator set.

Literature Type	Part Number
14/20RES/RESL Generator Set Installation Manual	TP-6733
14/20RES/RESL Generator Set Service Manual	TP-6735

Figure 2 Related Literature

Nameplate

The following illustration shows a typical generator set nameplate. Copy the model, serial, and specification numbers from the nameplate into the spaces provided in the product information section on the inside front cover of this manual. See Section 1.7 for the nameplate location.



TP-6734 1/11 Introduction 9

Emission Information

The Kohler® Model CH740 engine used on the 14RES/RESL generator set is certified to operate using natural gas or propane fuel.

The Kohler Model CH1000 engine used on the 20RES/RESL generator set is certified to operate using propane fuel. The CH1000 engine used on the 20RES/RESL may be operated on natural gas fuel because it is excluded from the requirements of 40 CFR 1048 as a stationary engine.

The engine used in the Model 20RES/RESL generator set is certified for emergency standby use only.

The Emission Compliance Period referred to on the Emission Control or Air Index label indicates the number of operating hours for which the engine has been shown to meet CARB or EPA emission requirements. Figure 3 provides the engine compliance period (in hours) associated with the category descriptor, which may be found on the certification label.

Emission Compliance Period			
EPA	Category C	Category B	Category A
	250 hours	500 hours	1000 hours
CARB	Moderate	Intermediate	Extended
	125 hours	250 hours	500 hours

Figure 3 Emission Compliance Period

Refer to the certification label for engine displacement.

The exhaust emission control system for the CH740 engines (14RES/RESL) is EM for U.S. EPA, California, and Europe.

The exhaust emission control system for the CH1000 engine (20RES/RESL) is EM for U.S. EPA, California, and Europe.

10 Introduction TP-6734 1/11

For professional advice on generator set power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KohlerPower.com.
- Look at the labels and stickers on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

Headquarters Europe, Middle East, Africa (EMEA)

Kohler Power Systems 3 rue de Brennus 93200 Saint Denis

France

Phone: (33) 1 49 178300 Fax: (33) 1 49 178301

Asia Pacific

Power Systems Asia Pacific Regional Office Singapore, Republic of Singapore

Phone: (65) 6264-6422 Fax: (65) 6264-6455

China

North China Regional Office, Beijing

Phone: (86) 10 6518 7950 (86) 10 6518 7951

(86) 10 6518 7952 Fax: (86) 10 6518 7955

East China Regional Office, Shanghai

Phone: (86) 21 6288 0500 Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office Bangalore, India

Phone: (91) 80 3366208

(91) 80 3366231

Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office

Tokyo, Japan

Phone: (813) 3440-4515 Fax: (813) 3440-2727

Latin America

Latin America Regional Office

Lakeland, Florida, USA Phone: (863) 619-7568 Fax: (863) 701-7131

TP-6734 1/11 Service Assistance 11

Notes

12 Service Assistance TP-6734 1/11

Section 1 Descriptions and Service Views

1.1 Introduction

The generator set specification sheets provide specific generator and engine information. Refer to the spec sheet for data not supplied in this manual. Consult the generator set service manual, engine operation manual, and engine service manual for additional specifications. Obtain copies of the latest spec sheets, manuals, diagrams, and drawings from your local distributor/ dealer.

1.2 Engine

The generator set has a four-cycle, twin cylinder, aircooled Kohler® engine. The engine operates on cleanburning natural gas or propane (LP) vapor. Engine features include:

- Efficient overhead valve design and full pressure lubrication for maximum power, torque, and reliability under all operating conditions.
- Dependable, maintenance-free electronic ignition.
- Precision-formulated cast iron construction of parts subjected to the most wear and tear.
- Field-convertible multi-fuel systems that allow fuel changeover from natural gas to LP vapor (and viceversa) while maintaining CARB emission certification.
- Digital spark advance optimizes ignition timing for the selected fuel.

1.3 Alternator

The generator uses Kohler's unique PowerBoost™ voltage regulation system, which provides instant response to load changes.

PowerBoost™ ensures reliable motor starting and consistent voltage levels. PowerBoost™ utilizes a voltage excitation system that employs a winding independent of the main output windings to provide excitation voltage.

Transfer Switch

The RDC and DC controllers are designed to interface with and control the Kohler Model RRT Automatic Transfer Switch (ATS).

If the power system uses a transfer switch other than the Kohler® Model RRT ATS, the RDC controller functions as a generator set controller only. An ATS other than the Model RRT must provide engine start contacts that connect to the remote engine start leads on the generator set.

1.5 Controllers




Figure 1-1 Controllers

RES models are equipped with the Residential Digital Control (RDC). RESL models use the Digital Control (DC). See Figure 1-1.

Controller Features

- Integrated control for the generator set and Kohler® Model RRT transfer switch
- Automatic start with programmed cranking cycle
- Digital isochronous governor to maintain steady-state speed at all loads
- Digital voltage regulation: ±1.5% RMS no-load to full-load
- Smart engine cooldown senses engine temperature
- Master switch pushbuttons (Off, Auto, Run, Exercise/down arrow)
- Off, Auto, and Run LED indicators
- LED display:
 - Crank cycle status
 - Setup information (RDC only)
 - Firmware version
 - Faults
 - Event history
- Scrolling system status display when generator set is running includes:
 - Engine runtime hours
 - Battery voltage
 - Generator voltage
 - Engine temperature
 - Utility voltage*
- Membrane keypad for configuration and adjustment (RDC only)
 - Password-protected access to system configuration and adjustment menus
 - System voltage/frequency selection and engine configuration
 - Voltage, gain, and engine speed adjustment
- Selectable exercise and test modes:
 - Weekly unloaded variable-speed exercise with complete system diagnostics
 - Weekly loaded full-speed exercise *
 - Unloaded full-speed test
 - Loaded full-speed test *

- Faults displayed:
 - ATS communication error
 - Auxiliary fault
 - High battery voltage
 - High engine temperature
 - Internal faults
 - Locked rotor
 - Loss of AC sensing
 - Low battery voltage
 - Low cranking battery voltage
 - Low oil pressure
 - Overcrank
 - Overfrequency
 - Overspeed
 - Overvoltage
 - Speed sensor fault
 - Underfrequency
 - Underspeed
 - Undervoltage
- Front-access mini USB connector for controller firmware upgrade †
- Front access fuses and mini-breaker
- Remote two-wire start/stop capability for optional connection of Model RDT or RSB transfer switches
- Load control output allows delayed start of large motor loads *
- Generator output voltage and frequency sensing with adjustable voltage pickup and dropout settings [†]
- Engine start and load transfer time delays*
 (adjustable using Kohler® SiteTech™ software †)
- Provides utility voltage sensing data and transfer signals with the Model RRT transfer switch *

^{*} Model RRT transfer switch required

[†] Requires Kohler® SiteTech™ software, available only to Kohler authorized distributors and dealers

1.6 Accessories

The following optional accessories are offered for the RES and RESL generator sets.

1.6.1 **Carburetor heater**

An optional carburetor heater is recommended for improved cold starting in locations where the ambient temperature drops below 0°C (32°F). The carburetor heater prevents condensation and carburetor icing. The heater requires a continuous source of 120 VAC power.

See the generator set Installation manual for more information.

OnCue™ Home Generator 1.6.2 **Management System**

The Kohler® OnCue™ Home Generator Management System allows monitoring and control of your RES or RESL generator set from a personal computer located in your home or at other remote locations. OnCue™ can also be configured to send email or text message notifications in the event of a generator set fault.

Note: Be sure to obtain the correct version of the OnCue™ kit for the RDC/DC controller.

OnCue™ version 3.0 with the Ethernet option board is required for RES/RESL generator sets equipped with the RDC/DC controller. Earlier versions of the OnCue™ kit are not compatible with the RDC/DC controller.

1.7 Service Views for Maintenance




Figure 1-2 Generator Set Components

2.1 Prestart Checklist

To ensure continued satisfactory operation, perform the following checks or inspections before or at each startup, as designated, and at the intervals specified in the service schedule. In addition, some checks require verification after the unit starts.

Air Cleaner. Check for a clean and installed air cleaner element to prevent unfiltered air from entering the engine.

Air Inlets. Check for clean and unobstructed air inlets.

Battery. Check for tight battery connections. Consult the battery manufacturer's instructions regarding battery care and maintenance.

Exhaust System. Check for exhaust leaks and blockages. Check the muffler condition.

- Inspect the exhaust system components for cracks, leaks, and corrosion. Check for tight exhaust system connections.
- Check for corroded or broken metal parts and replace them as needed.
- Check that the exhaust outlet is unobstructed.

Oil Level. Check the oil level before starting the generator set and at the intervals given in Section 3, Scheduled Maintenance. Maintain the oil level at or near, not over, the full mark on the dipstick.

Operating Area. Check for obstructions that could block the flow of cooling air. Keep the air intake area clean. Do not leave rags, tools, or debris on or near the generator set.

2.2 Exercising the Generator Set

Operate the generator set without load once each week for 20 minutes. Perform all of the prestart checks before starting the exercise procedure. See Section 2.8 for instructions to set the exerciser.

2.3 RDC and DC Generator Set/ Transfer Switch Controllers

Model RES generator sets are equipped with the Residential Digital Control (RDC). Model RESL generator sets are equipped with the Digital Control (DC).

The RDC and DC control the power system generator set and Model RRT automatic transfer switch (ATS) (if equipped). The controller receives voltage sensing data from the Model RRT ATS and operates the generator set and transfer switch to provide standby power when utility power is lost.

2.4 Controller Power

The RDC and DC controllers are powered by the generator set engine starting battery.

Note: The generator sets are equipped with factory-installed battery chargers to prevent battery discharge. The battery charger must be connected to utility power.

2.5 Controller Firmware Version

The information in this manual applies to RDC and DC controllers with firmware version number 2.08 or higher. To check the firmware version number:

RDC controllers: Press and hold the Select button and the up arrow button simultaneously for about 5 seconds, until the firmware version number appears on the controller display.

DC controllers: The firmware version number is displayed during the first 2 seconds of the engine crank cycle.

TP-6734 1/11 Section 2 Operation 17

2.6 Controls and Indicators

Figure 2-1 illustrates the RDC and DC controller user interfaces.




Figure 2-1 RDC and DC Controls and Indicators

2.6.1 Controller Keypad

The Run, Off, Auto, and Down arrow or Exercise buttons control the generator set as described in Figure 2-2. See Section 2.7 for operation instructions.

RDC controller only: The Select, Up, and Down buttons on the controller keypad are used to adjust the controller parameters. The system configuration and performance is factory-set and should not require changes under normal operating conditions. To prevent inadvertent changes, a pass code is required to access the controller parameter settings. Contact an authorized distributor/dealer or service technician if adjustments are required.

Button	Button Function		
RUN	Starts the generator set. The engine start time delay is ignored.		
OFF	Shuts down the generator set. The cooldown time delay is ignored.		
	During the engine crank cycle, pressing OFF will stop the crank cycle.		
	Press and hold for 3 seconds to view event history. See Section 2.10.5.		
AUTO	Places the generator set in Auto mode. See Figure 2-5.		
DOWN	Starts an unloaded exercise.		
arrow (RDC) or EXERCISE (DC)	Press during test or exercise to change from unloaded to loaded (with RRT only).		
Select	RDC only. Used to change parameter		
UP arrow	settings. Password-protected. Contact your distributor/dealer if necessary.		

Figure 2-2 Pushbutton Operation

18 Section 2 Operation TP-6734 1/11

2.6.2 LED Display

Figure 2-3 lists status messages that may be shown on the controller's LED display.

When the system is in AUTO and the generator set is not running, the LED display shows the engine run time hours. During cranking, the display shows CC1, CC2, or CC3.

When the generator is running, the display steps through the status messages shown in Figure 2-4, as applicable. The generator set must be connected to a Model RRT transfer switch for the utility voltage display.

When a fault or warning condition exists, the controller will show the corresponding message. See Section 2.10 for more information on fault and warning codes.

Display	Description	
Blank (dark)	Controller is off.	
u#.#	Controller software version number	
XXX.X	Engine hours to 999.9	
XXXX	Engine hours, 1000 to 9999	
bXX.X	Battery voltage	
tXX.X	Engine temperature	
UXXX *	Utility voltage	
EXXX	Generator voltage	
tnLd *	Test, no load	
t Ld *	Test, loaded	
EnLd	Exercise, no load	
E Ld *	Exercise, loaded	
CC1, 2, or 3	Engine crank cycle 1, 2, or 3. Flashes during crank pause.	
Fault code	Warning or fault. See Figure 2-8.	
* Model RRT ATS is required for this display.		

Test or exercise mode, if applicable. tnLd, t LD, EnLd, or E Ld

Engine Runtime
XXX.X or XXXX hours

Battery Voltage
bXX.X VDC

Engine Temperature
tXXX

Utility Voltage
UXXX VAC

Generator Voltage
EXXX VAC

tp6734

• Generator set is running.

- Model RRT transfer switch is required for utility voltage display.
- Display steps through the parameters in sequence for 2 seconds each.

Figure 2-4 Data Displays, Generator Running

2.6.3 LED Indicators

LEDs above the RUN, OFF, and AUTO buttons indicate the mode of operation as shown in Figure 2-5.

Figure 2-3 RDC Controller Display

Mode	LED Indication	Description
RUN	RUN LED is on	The generator set was started by pressing the RUN button. Generator set is running. Remote start and stop commands are ignored.
OFF	OFF LED lights for 2 seconds, then flashes every 2 seconds.	The OFF button was pressed. Generator set and controller are off. Remote start/stop commands have no effect. The exercise cycle will not run.
AUTO	AUTO LED is on	Automatic mode. Generator set will respond to engine start and stop commands from the controller (for example, exercise start and stop commands) or an ATS. Time delays operate as described in Section 2.7.

Figure 2-5 Operation Modes and LED Indicators

TP-6734 1/11 Section 2 Operation 19

2.7 Generator Set Operation

2.7.1 Local Starting and Stopping

Start

Press the RUN button to immediately start the generator set. The engine start time delay will be ignored.

The controller attempts to start the generator set three times. See Section 2.7.2, Engine Start Crank Cycle.

Stop

- 1. Run the generator set with no load for at least 2 minutes to ensure adequate engine cooldown.
- 2. Press the OFF button. The engine stops.

Also see Section 2.9, Test.

2.7.2 Engine Start Crank Cycle

The controller attempts to start the generator set three times (three crank cycles, 15 seconds crank and 15 seconds off). See Figure 2-3 for display information during the crank cycle. If the generator set does not start in three attempts, the system shuts down on an overcrank fault. See Section 2.10.

Pressing the OFF button during the crank cycle stops the cranking. No other buttons are acknowledged during the crank cycle.

2.7.3 Engine Cooldown

The engine cooldown time delay allows the engine to run after the loads have been removed. COOL is displayed on the controller during engine cooldown.

The engine cooldown time delay is set to 5 minutes. The engine stops before the cooldown time delay expires if the temperature drops below the cooled-down temperature level, or if the temperature rises during the cooldown cycle.

If a transfer switch other than the Model RRT is used, an engine cooldown time delay may be programmed on the transfer switch. To allow the smart engine cooldown on the RDC/DC controller to operate most efficiently, set the cooldown time on the ATS controller to zero or the minimum time allowed. Refer to the instructions provided with the ATS for more information.

2.7.4 Automatic Operation with Model RRT Transfer Switch

The Model RRT transfer switch connects to the RDC/DC controller through the ATS interface board on the transfer switch. Also see Section 2.11, Model RRT Transfer Switch Operation.

The controller must be in AUTO mode. Press the AUTO button to put the controller into automatic mode.

Automatic Start

The RDC/DC controller receives utility source voltage sensing data from the Model RRT transfer switch.

- 1. If the utility source voltage falls below an acceptable level, the controller starts the engine start time delay.
- 2. If the utility source is not restored before the time delay expires, the generator set starts.
- After the Normal-to-Emergency time delay, the ATS is signaled to transfer the load to the emergency source.

Automatic Stop with Engine Cooldown

- When the utility source is restored, the Emergency-to-Normal time delay starts.
- 2. When the Emergency-to-Normal time delay expires, the load is transferred to the utility.
- 3. The generator set runs through the engine cooldown cycle and then stops.

2.7.5 Automatic Operation with Model RDT or RSB Transfer Switches

If a Kohler Model RDT or RSB transfer switch is used, the engine start contacts from the ATS must be connected to engine start leads 3 and 4 on the generator set

The controller must be in AUTO mode to respond to remote start/stop signals from an ATS or remote switch. Press the AUTO button to put the controller into automatic mode.

Automatic Start

The engine start contacts on the ATS close to signal the generator set to start, and remain closed while the generator set is running.

20 Section 2 Operation TP-6734 1/11

Automatic Stop

Open the contact across engine start leads 3 and 4 to signal the generator set to stop.

2.8 Exercise

The RDC and DC controllers can be set to automatically run the generator set at the same time and day each week. Exercising the generator set weekly is required in order to keep the engine and alternator in good operating condition.

Follow the instructions in this section to start a 20-minute exercise run and set the exerciser to run at the same time every 7 days.

Note: RDC/DC controllers with firmware version 2.08 or higher support the unloaded variable-speed exercise with Kohler Model RRT, RDT, and RSB transfer switches.

Note: With the RDT and RSB transfer switches, it is possible to have two exercise settings (one unloaded exercise set at the generator set controller, and another exercise set at the ATS controller). If the exercise times overlap, the ATS exercise setting takes priority.

Set the exercise at the RDC/DC controller or the ATS controller as shown in Figure 2-6. If a Model RDT or RSB transfer switch is used, refer to the instructions provided with the transfer switch to set an exercise at the ATS, if desired.

Exercise			
Transfer Switch Model	Unloaded Variable Speed	Unloaded Full Speed	Loaded Full Speed
RRT	RDC/DC	N/A	RDC/DC
RDT	RDC/DC	ATS	ATS
RSB	RDC/DC	ATS	ATS

Figure 2-6 Setting the Exerciser

2.8.1 Unloaded Variable-Speed Exercise with Complete System Diagnostics

An unloaded exercise runs the generator set without signalling the transfer switch to transfer the electrical load from the utility source to the generator set. The unloaded variable speed exercise runs at low speed for 15 minutes, then ramps up to full speed during the last 5 minutes.

The initial low-speed exercise allows generator set operation at lower noise levels and fuel consumption

while properly warming up the engine for longer life and better lubrication of critical components.

The full-speed portion of the exercise cycle provides the best test of engine and alternator power backup capability. Diagnostic tests at full speed can identify potential problems with the power output and alert the operator before an emergency event.

Procedure to Set Unloaded Variable-Speed Exercise

- 1. Verify that the control is in the AUTO mode with the AUTO LED ON and the Utility power available.
- 2. Press the down arrow button (RDC) or exercise button (DC) to initiate the engine start signal.
- The generator begins its crank cycles. During the crank cycles CCn appears on the display. No button presses are acknowledged during the crank cycles.
- 4. The generator runs at low speed for 15 minutes. EnLd appears on the display. The AUTO LED is illuminated. The controller monitors the system during the unloaded exercise as described in the Section 2.8.2, System Diagnostics.
- During the last 5 minutes, the engine ramps up to full speed and then shuts down. Generator output frequency and voltage diagnostics are active as described in the Section 2.8.2, System Diagnostics.

The exercise time is set to the time the down arrow or exercise button is pressed. An unloaded variable-speed exercise will occur at the same time every seven days.

2.8.2 System Diagnostics

During the unloaded variable-speed exercise, the controller monitors the following data. The controller display indicates an unloaded exercise run (EnLd) during the diagnostics, unless a fault is detected as described below.

- ATS connection. The controller verifies that the Model RRT ATS interface board, if connected, remains connected. An ATS fault is displayed if the connection is lost.
- Battery voltage. Battery voltage is checked before exercise to verify engine starting capability. Battery voltage provides a measurement of battery health. If the controller detects low battery voltage, Lb (low battery) or LCb (low charging battery) is displayed and the exercise does not start.

TP-6734 1/11 Section 2 Operation 21

- Engine speed. Engine speed is measured at low speed and full speed. An overspeed (OS) or underspeed (US) condition will result in a fault condition and shutdown.
- Generator output frequency and voltage.
 Operating the generator at full speed allows the RDC/DC controller to check the output power for correct voltage, frequency, and stability. When the engine is running at full speed, the controller verifies that the voltage and frequency are within acceptable limits. UU (undervoltage), OU (overvoltage), UF (underfrequency), or OF (overfrequency) is displayed if the voltage or frequency is out of range.
- Oil pressure. Oil pressure is verified to ensure proper lubrication of critical engine components. Pressure is monitored at both low and full speeds. If the oil pressure is low, LOP (low oil pressure) is displayed and the generator set shuts down.

2.8.3 Loaded Exercise (with RRT only)

A loaded exercise starts the generator set, ramps up to full speed, and then transfers the electrical load from the utility source to the generator set. The load is transferred back to the utility source before the generator set shuts down.

Procedure to Set a Loaded Exercise

- 1. Verify that the control is in the AUTO mode with the AUTO LED ON and the Utility power available.
- 2. Press the down arrow button (RDC) or the exercise button (DC) to initiate the engine start signal.
- The generator begins its crank cycles. During the crank cycles CCn appears on the display. No button presses are acknowledged during the crank cycles.
- 4. When the generator is running, **EnLd** appears on the display and the AUTO LED is illuminated. The generator runs at low speed with no load.
- Press the down arrow button (RDC) or exercise button (DC) a second time. The generator ramps up to normal operating speed (typically 3600 RPM) and the ATS transfers the load.
- 6. **E Ld** appears on the display and the AUTO LED is illuminated. The generator runs at normal operating speed for twenty minutes with load.

7. After 20 minutes, the ATS transfers the load back to utility power. The engine runs for 5 minutes or until cool, and then shuts down.

The exercise time is set to the time the down arrow button (RDC) or exercise button (DC) was initially pressed. A loaded, full-speed exercise will occur at the same time every seven days.

Other transfer switches: For a loaded exercise with a transfer switch other than a Kohler® Model RRT, refer to the transfer switch operation manual.

2.8.4 Power Failure During Exercise Cycle

If the utility power is lost during an unloaded exercise, the ATS transfers to the emergency source, the exercise is ended and the control remains in the AUTO mode.

If the utility power is lost during a loaded exercise, the exercise is ended. The ATS remains in the emergency position and the control goes into the AUTO mode.

The generator set continues to run and supply power to the load for the duration of the utility power outage. When Utility power is restored, the ATS will re-transfer to the utility source through normal timing sequences.

2.8.5 Exerciser Reset

To reset the exerciser to run at a different day and/or time, or to switch between a loaded and unloaded exercise, follow the procedures above to start an unloaded or loaded exercise on the desired time and day. The previous exercise setting is replaced by the new time, day, and loaded or unloaded condition.

2.8.6 Exercise Disable

Note: With the RDT and RSB transfer switches, it is possible to have two exercise settings (one set at the generator set controller, and one set at the ATS controller). If the exercise times overlap, the ATS exercise setting takes priority.

If a transfer switch other than the Model RRT is used and the exerciser is set at the transfer switch controller, you can disable the exercise on the RDC/DC controller.

To disable the exerciser on the RDC/DC controller, press and hold the OFF and DOWN arrow or EXERCISE buttons together for 3 seconds.

22 Section 2 Operation TP-6734 1/11

2.9 Test

An operator can use the buttons on the RDC/DC controller to test the generator set operation. Follow the instructions below to manually start and stop an unloaded or loaded full-speed test.

2.9.1 Unloaded Test

An unloaded test runs the generator set at full speed without signalling the transfer switch to transfer the electrical load from the utility source to the generator set.

Procedure to Run an Unloaded Full-Speed Test

- 1. Press the RUN button to start an unloaded test. The engine cranks and starts.
- When the generator is running, tnLd appears on the display and the RUN LED is illuminated. The engine runs at normal operating speed (3600 RPM) during the test sequence.
- 3. There are two ways to end an unloaded test. Perform a or b:
 - a. Press the AUTO button to enter AUTO mode. If utility is available, the generator set shuts down through normal timing sequences.
 - b. Press the OFF button to shut down the generator set. The cooldown time delay is ignored.

Also see Section 2.7.1, Local Starting and Stopping.

Figure 2-7 describes the effect of pressing the buttons during a test, with the engine running and no active faults.

Button			
Press	Response		
RUN	Press RUN to start the test. Pressing again when the engine is running has no effect.		
AUTO	Puts the generator set into AUTO mode. Shuts down the engine through normal timing sequences if utility is available. AUTO LED turns ON. RUN LED turns OFF		
OFF	Ends the test and shuts down the generator set. The cooldown time delay is ignored. The RUN LED turns OFF. The OFF LED turns ON and then flashes every 2 seconds.		
DOWN arrow/ EXERCISE	Press during the test to signal the Model RRT ATS to transfer to the emergency source. The display indicates a Loaded Test, t Ld .		

Figure 2-7 Button Functions During Test

2.9.2 Loaded Test (with RRT only)

A loaded test starts the generator set and then signals the Model RRT transfer switch to transfer the electrical load from the utility source to the generator set. The load is transferred back to the utility source before the generator set shuts down.

Note: If a Model RDT or RSB transfer switch is used, a *loaded* test cannot be initiated from the RDC or DC controller. To run a loaded test, refer to the instructions provided with the transfer switch.

Procedure to Run a Loaded Full-Speed Test

- Press the RUN button to start an unloaded test as described in Section 2.9.1. When the generator is running, tnLd appears on the display.
- Press the down arrow button (RDC) or the exercise button (DC) to signal the ATS to transfer the load. The display indicates a loaded test, t Ld.
- 3. To end the test, press the AUTO button to shut down the generator set through normal timing sequences. The generator set goes into Auto mode. The load is transferred to utility power, if available. The engine cooldown cycle runs before the generator set engine stops.

Immediate Shutdown During a Loaded Test

Press the OFF button to shut the generator set down immediately, if necessary. The cooldown time delay is ignored, and the controller goes to OFF mode. The controller signals the RRT transfer switch to transfer the load back to utility power.

Note: Running the generator set with no load for at least 2 minutes is recommended to ensure adequate engine cooldown. Use the OFF button to stop a loaded test only if necessary.

2.9.3 Power Failure During Test Cycle

If the utility power is lost during an unloaded test, the controller goes into the AUTO mode and the ATS transfers to the emergency source.

If the utility power is lost during a loaded test, the controller goes into the AUTO mode. The ATS remains in the emergency position.

The generator set continues to run and supply power to the load for the duration of the Utility power outage. When Utility power is restored, the ATS re-transfers to the utility source through normal timing sequences.

2.10 Faults

Fault conditions are shown in Figure 2-8. Fault conditions are classified as warnings or shutdowns.

2.10.1 Warnings

The controller displays a fault code but the generator set does not shut down on a warning. The controller resets automatically after a warning condition is corrected.

2.10.2 Shutdowns

Under a fault shutdown condition, the generator set shuts down automatically and the controller displays a fault code. In some cases, the engine cooldown cycle runs before the engine shuts down. See Figure 2-8.

Shutdown switches (such as the low oil pressure switch or high engine temperature switch) on the generator set will automatically reset when the problem is corrected. However, the fault condition at the controller does not clear until the controller is reset.

The generator set cannot be restarted until the fault condition is corrected and the controller is reset. See Section 2.10.4 to reset the controller after a fault shutdown.

2.10.3 ATS Communication Errors

An ATS fault can be caused by two conditions.

- When a Model RRT transfer switch is used, an ATS fault indicates that the connection to the interface board on the transfer switch has been lost. The generator set shuts down. Check the connection to the ATS interface board.
- If an RRT transfer switch is connected after the controller has powered up, the ATS warning is displayed. To clear the fault, disconnect and then reconnect battery power to the controller.

Code	Fault	Warning (W) or Shutdown (SD)	Condition	Check
AC	Loss of AC sensing	W (1 sec.) SD (3 sec.) *	Generator output AC sensing is lost. Starts 10 seconds after crank disconnect.	Contact an authorized distributor/dealer for service.
			Warning: after 1 second if no output detected after crank disconnect.	
			Shutdown: after 3 seconds if voltage was present and then lost.	
AF	Auxiliary fault input	SD*	An optional customer-connected input is closed.	Check customer-supplied equipment.
ATS	ATS communication	SD*	Shutdown if ATS interface connection is lost. See Section 2.10.3.	Check connection to Model RRT transfer switch interface board.
	error	W	Warning is displayed if RRT interface board is connected after controller is powered up. See Section 2.10.3.	Disconnect and then reconnect battery power to controller.
Hb	High battery voltage	W	Engine starting battery voltage rises above 125% of the battery voltage setting for more than 10 seconds when the engine is running. Not operative during the engine crank cycle.	Check the battery rating and condition. Check the battery charger operation.
			Clears when the battery voltage returns to an acceptable level.	
HE	High engine temperature	SD*	Engine coolant temperature exceeds the maximum temperature for more than 5 seconds. Function becomes active after crank disconnect.	Check for blocked air inlets and exhaust outlets.
Lb	Low battery voltage	W	Engine starting battery voltage falls below the battery voltage setting (typically 12 volts) for more than 90 seconds when the engine is not running. Not operative during the engine crank cycle. Clears when the battery voltage returns to an acceptable level.	Check the battery rating and condition. Check the battery charger operation. Charge or replace the battery.

24 Section 2 Operation TP-6734 1/11

Code	Fault	Warning (W) or Shutdown (SD)	Condition	Check
LCb	Low cranking voltage	W	Battery voltage falls below 60% of system battery voltage for more than 6 seconds while the starter is engaged.	Charge or replace the battery.
LOP	Low oil pressure	SD*	The LOP switch indicates low oil pressure for more than 5 seconds. Function becomes active 30 seconds after crank disconnect (30 second inhibit).	Check for leaks in the lubrication system. Check the oil level and add oil if the level is low.
			Note: The low oil pressure shutdown does not protect against low oil level. Check the engine oil level regularly as recommended in Section 3.	
Lr	Locked rotor	SD	No engine rotation is sensed during cranking. Shuts down 3 seconds after	Check the fuel supply, spark plug, and battery.
			the fault is detected.	Check for loose connections.
				Contact an authorized distributor/dealer for service.
LrC	Loss of voltage regulator communication	SD*	No communication between controller and voltage regulator.	Contact an authorized distributor/dealer for service.
oc	Overcrank	SD	Three unsuccessful starting attempts.	Check the fuel supply, spark plug, and battery.
				Check for loose connections.
				Contact an authorized distributor/dealer for service.
OF	Overfrequency	SD*	Governed frequency exceeds 110% of the system's frequency setpoint for more than 5 seconds. Function becomes active 10 seconds after engine start (10 second inhibit).	Contact an authorized distributor/dealer for service.
os	Overspeed	SD*	Engine speed exceeds 115% of the normal running speed for more than 0.3 seconds.	Contact an authorized distributor/dealer for service.
OU	Overvoltage	SD*	Output voltage exceeds 120% of the system nominal voltage for more than 2 seconds.	Contact an authorized distributor/dealer for service.
SS	Speed sensor failure	SD	Engine speed sensor has failed.	Contact an authorized distributor/dealer for service.
UF	Underfrequency	SD*	Governed frequency falls below 90% of the system frequency setting for more	Reduce the load and restart the generator set.
			than 5 seconds, or 1 Hz below the system frequency setting for more than 60 seconds.	Contact an authorized distributor/dealer for service.
			Function becomes active 10 seconds after engine start (10 second inhibit).	
US	Underspeed		Engine speed drops below 85% of the	Reduce the load.
			normal running speed for more than 0.3 seconds.	Contact an authorized distributor/dealer for service.
UU	Undervoltage	SD*	Output voltage falls below 80% of the nominal system voltage for more than	Reduce the load and restart the generator set.
			10 seconds.	Contact an authorized distributor/dealer for service.

Figure 2-8 Controller Fault Codes

TP-6734 1/11 Section 2 Operation 25

2.10.4 Resetting the Controller after a Fault Shutdown

Always identify and correct the cause of a fault shutdown before resetting the controller. Check the fault code displayed on the controller and refer to Figure 2-8 to identify and correct the fault condition before proceeding. Contact an authorized distributor/dealer for service, if necessary.

Procedure to Reset the Controller after a Fault Shutdown

- 1. Press OFF to turn off the generator set.
- Disconnect the generator set from the load using the line circuit breaker or ATS. See the safety precautions at the beginning of this manual before proceeding.
- Identify and correct the cause of the fault shutdown. See the safety precautions at the beginning of this manual before proceeding. Refer to Section 4, Troubleshooting.
- 4. Start the generator set by pressing RUN. Check the generator set operation to verify that the cause of the shutdown has been corrected.
- 5. Press the OFF button to stop the generator set.
- 6. Reconnect the generator set to the load using the line circuit breaker or ATS.
- 7. Press AUTO to put the generator set into automatic mode.

2.10.5 Event History

The last ten controller faults can be viewed from the controller display when the controller is off. Each event is displayed with the fault code followed by the engine hours at which time the event occurred. During event history viewing, the OFF LED flashes once per second.

NIA (not in Auto) will be listed in the event history, but is not displayed on the controller when active.

Procedure to View Event History

- Press and hold the OFF button for 3 seconds. The first event appears on the screen. The OFF LED flashes once per second.
- Press the OFF button to cycle through the engine hours and subsequent events. After cycling through all ten events, the control automatically turns off. The OFF LED flashes once every 2 seconds.

To stop viewing the event history before the last event, press the down arrow or exercise button. The controller will turn off.

26 Section 2 Operation TP-6734 1/11

2.11 Model RRT Transfer Switch Operation

The RDC/DC generator set/transfer switch controller manages automatic transfer switch (ATS) functions when connected to a Kohler® Model RRT transfer switch through the ATS interface board.

2.11.1 Source Availability

The Model RRT transfer switch supplies voltage sensing data to the RDC/DC controller through the ATS interface board. If the source voltage falls below the undervoltage dropout setting, the source is considered to have failed. See Figure 2-9.

Item	Setting				
Accuracy	± 5%				
Undervoltage Dropout	90% of Pickup				
Undervoltage Pickup	90% of Nominal				

Figure 2-9 Voltage Sensing Parameters

2.11.2 ATS Control Sequence of Operation

See Figure 2-10 for time delay settings.

Preferred Source Fails:

- 1. The load control contact opens.
- 2. The engine start time delay times out.
- 3. The generator set is signaled to start.
- 4. The generator starts and the emergency source becomes available.
- 5. The normal-to-emergency time delay times out.
- 6. The transfer switch transfers to the emergency source.

- 7. The load control contact time delay times out.
- 8. The load control contact closes.

Normal Source Returns:

- 1. The emergency-to-normal time delay times out.
- 2. The contactor transfers to the normal source.
- 3. The engine cooldown time delay times out.
- 4. The generator is signaled to stop.

2.11.3 Time Delays

Time delays are factory-set to the values shown in Figure 2-10. An authorized distributor/dealer can adjust time delays using a personal computer and Kohler® SiteTech™ software.

Time delays described in this section operate only when the controller is connected to a Kohler[®] Model RRT transfer switch.

The engine start and load transfer time delays prevent engine start and load transfer caused by brief variations in the utility power source.

2.11.4 Load Control Time Delay

The load control time delay allows delayed starting of large motor loads (such as air conditioners), preventing simultaneous starting of large motors after transfer to the generator set. The load control time delay is fixed at 5 minutes. It is not adjustable.

The load must be connected to the load control output on the interface board of the Model RRT transfer switch. See the transfer switch operation and installation manual for connection instructions.

Time Delay	Setting	Description
Engine Start	3 seconds	Time delay after utility source is lost until the engine start cycle begins. Guards against starting the generator set because of a brief change in the utility source.
Transfer, Normal to Emergency	3 seconds	Time delay after emergency source becomes available until transfer to emergency source.
Transfer, Emergency to Normal	2 minutes	Time delay after the utility source returns until transfer back to normal. Ensures that the the utility source is stable before transferring from the emergency source.
Load Control	5 minutes	Allows delayed connection of selected loads to the generator set. Prevents simultaneous starting of large motors after transfer to the emergency source. Recommended for delayed starting of air conditioners.

Figure 2-10 Time Delays

TP-6734 1/11 Section 2 Operation 27

Notes

28 Section 2 Operation TP-6734 1/11


WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.



Operate the generator set only when all guards and electrical enclosures are in place.

Can cause severe injury or death.



Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Scheduled Maintenance 3.1

Refer to the following service schedules and the runtime hours displayed on the controller display to schedule routine maintenance. Intervals are shown in hours of operation and/or time intervals (i.e. weekly, monthly, quarterly, etc.) Have an authorized distributor/dealer service the generator set at the designated intervals in the service schedule for the life of the generator set. Service units subject to extreme weather, long operating hours, or dusty or dirty conditions more frequently.

Contact an authorized distributor/dealer for parts.

3.1.1 Service Schedule, 14RES/RESL Models

	See Section	Procedure					
System Component or Procedure		Visually Inspect	Check	Change	Clean	Test	Frequency
Fuel							
Flexible lines and connections		Х		R			Quarterly
Main tank supply level			Х				Weekly
Fuel piping		Х					Yearly
Lubrication	3.2						
Oil level		Х	Х				8 hours or before use
Crankcase breather hose		Х					Yearly or 500 hours
Change oil				Х			Yearly or 100 hour
Replace filter				Х			Yearly or 200 hour
Cooling	3.5						
Air ducts, louvers			Х		Х		Yearly
Exhaust Line	3.6						
Leakage		Х	Х				Weekly
Insulation, fire hazards		X	,,				Yearly
Obstructions or combustible materials near exhaust outlet		X					Weekly
DC Electrical System	3.7						
Battery charger operation, charge rate (if equipped)		Х					Monthly
Remove corrosion, clean and dry battery and rack		X			Х		Yearly
Clean and tighten battery terminals and inspect boots		X	Х				Yearly
Battery electrolyte level and specific gravity *			Х				Yearly
AC Electrical System							,
Tighten control and power wiring connections			Х				Yearly
Remote control system, if equipped						Х	Monthly
Visible wear or damage		Х					Quarterly
Wire abrasions where subject to motion		X	X				Six Months
Wire-cable insulation condition		X					3 Years or 500 hour
Engine and Mounting							o reare or occ rical
Visible wear or damage		X					Weekly
Air cleaner and precleaner service †	3.4	^		R			Yearly or 100 hours
·				X			Yearly or 300 hours
Spark plugs Replace stepper motor coupling and bushing	3.3			D			500 hours
Generator				U			Joo Hours
				<u> </u>	1		Ougstorie
Visible wear or damage		X			 	~	Quarterly
Exercise generator set		D			D	Х	Weekly
Brushes and collector ring Measure and record resistance readings of		U			U		Yearly
windings with insulation tester (Megger®, with SCR assembly or rectifier and load leads disconnected) *						D	3 Years
General Condition of Equipment							
Evidence of vibration, leakage, excessive noise, temperature, or deterioration		х	х		Х		Weekly
Interior of sound enclosure		Х			Х		Quarterly
* Not necessary for maintenance-free batteries. † Service more frequently under extremely dusty/dirty of Megger® is a registered trademark of Biddle Instruments			ized distrib e as nece	outor/dealer ssary	only	•	

3.1.2 Service Schedule, 20RES/RESL Models

	See Section		Р				
System Component or Procedure		Visually Inspect	Check	Change	Clean	Test	Frequency
Fuel							
Flexible lines and connections		X		R			Quarterly
Main tank supply level			Х				Weekly
Fuel piping		Х					Yearly
Lubrication	3.2						
Oil level			Х				8 hours or before each use
Change oil				Х			Yearly or 150 hours
Replace filter				Х			Yearly or 150 hours
Crankcase breather hose		Х					Yearly or 500 hours
Oil cooler		Х			Х		Yearly or 100 hours
Cooling	3.5						
Air ducts, louvers			Х		Х		Yearly
Exhaust System	3.6						
Leakage		Х	X				Weekly
Insulation, fire hazards		X					Yearly
Obstructions or combustible materials near exhaust outlet		X					Weekly
DC Electrical System	3.7						
Battery charger operation, charge rate		Х					Monthly
Remove corrosion, clean and dry battery and rack		X			Х		Yearly
Clean and tighten battery terminals and inspect boots		Х	Х				Yearly
Battery electrolyte level and specific gravity *			Х				Yearly
AC Electrical System							
Tighten control and power wiring connections			Х				Yearly
Remote control system, if equipped						Х	Monthly
Visible wear or damage		Х					Quarterly
Wire abrasions where subject to motion		X	Х				Six Months
Wire-cable insulation condition		X					3 Years or 500 hours
Engine and Mounting							
Visible wear or damage		Х					Weekly
Air cleaner service †	3.4		150	300			Yearly or hours shown
Spark plugs	3.3		150	300			Yearly or hours shown
Replace stepper motor coupling and bushing	0.0		100	D			500 hours
Generator				U			JOU HOUIS
		X					Quartarly
Visible wear or damage		^				W	Quarterly
Exercise generator set		D			D	VV	Weekly
Brushes and collector ring		D			U		Yearly
Measure and record resistance readings of windings with insulation tester (Megger®, with SCR assembly or rectifier and load leads disconnected)						D	3 Years
General Condition of Equipment							
Evidence of vibration, leakage, deterioration, unusual or excessive noise or temperature		х	х		х		Weekly
Interior of sound enclosure		Х			Х		Quarterly
* Not necessary for maintenance-free batteries. † Service more frequently under extremely dusty/d Megger® is a registered trademark of Biddle Instrur	•	ıs.		on norized distri lace as nece	butor/deal	er only	

3.2 Lubrication System

See the service schedules in Section 3.1 for oil change and oil filter replacement intervals. See the service views in Section 1.7 for the oil drain, oil check, oil fill, and oil filter locations.

3.2.1 Low Oil Pressure Shutdown

The low oil pressure (LOP) shutdown feature protects the engine against internal damage if the oil pressure drops below a minimum pressure because of oil pump failure or other malfunction.

Note: The LOP shutdown feature does not protect against damage caused by operating when the oil level is low; it is not a low oil level shutdown. Check the oil level regularly, and add oil as needed.

3.2.2 Oil Check

The generator set is shipped with oil. Before operating the generator set, check the engine oil in the crankcase. See Figure 3-1.

Maintain the oil level at or near, not over, the full mark on the dipstick. Add 5W-30 synthetic oil when the oil level is low.

Check the oil level before each use. For extended operation, check the oil level every 8 hours. Do not check the oil level when the generator set is running. Shut down the generator set and wait several minutes before checking the oil.




Figure 3-1 Oil Check (typical)

3.2.3 **Engine Oil Recommendation**

Use 5W-30 API (American Petroleum Institute) Service Class SG, SH, or SJ synthetic oil. Synthetic oil oxidizes and thickens less than other oils and leaves the engine intake valves and pistons cleaner.

3.2.4 Oil Change Procedure

Note: Dispose of all waste materials (engine oil, fuel, filter, etc.) in an environmentally safe manner.

Drain the oil while it is still warm.

1. Drain the oil.

- a. Press the OFF button on the generator set controller.
- b. Disconnect the power to the battery charger.
- c. Disconnect the generator set engine starting battery, negative (-) lead first.
- d. Remove the housing side panel.
- e. Clean the area around the dipstick and oil fill
- f. Remove the oil drain hose from its retaining clip. Remove the cap from the oil drain hose and lower the hose into an oil collection container.
- g. Open the oil drain valve on the engine.
- h. Remove the dipstick and oil fill cap. Allow time for the engine oil to drain completely.
- i. Close the oil drain valve. Replace the cap on the oil drain hose. Replace the oil drain hose in its retaining clip.
- j. Replace the dipstick.

2. Replace the oil filter.

- a. Clean the area around the oil filter. Remove the oil filter by rotating it counterclockwise with an oil filter wrench.
- b. Clean the gasket sealing surface of the oil filter adapter.
- c. Apply a light coat of clean oil to the rubber seal of the new oil filter.
- d. Install the new oil filter following the instructions provided with the filter.

3. Fill with oil.

a. Fill the engine to the F mark on the dipstick. The engine oil capacity is shown in Figure 3-2. See Section 3.2.3, Engine Oil Recommendation, for oil selection.

Generator Set Model	Oil Capacity, L (qt.)
14RES/RESL	1.9 (2.0)
20RES/RESL	2.8 (3.0)

Figure 3-2 Engine Oil Capacity

- b. Reinstall the dipstick and the oil fill cap.
- c. Check that the generator set master switch is in the OFF position.
- d. Reconnect the generator set engine starting battery, negative (-) lead last.
- e. Reconnect the power to the battery charger.
- f. Start and run the generator set for a minute to allow the oil pressure to reach operating range.
- g. Stop the generator set, wait 1 minute, and then recheck the oil level. Add oil to bring the level up to the F mark on the dipstick.

4. Check for leaks.

- a. Check for oil leaks.
- b. Fix leaks and recheck the oil level.
- c. Reinstall the housing side panel.

3.2.5 Oil Cooler 20RES/RESL

Inspect and clean the oil cooler at the intervals indicated in the service schedule. The oil cooler must be kept free of debris.

See Figure 3-3 for the oil cooler location. The oil cooler is located under the No. 2 cylinder shroud. Remove the top mounting screw and loosen the two side screws, then lift off the cylinder shroud.

Clean the outside of the oil cooler fins with a brush or with compressed air.




Figure 3-3 Oil Cooler Location

3.3 Spark Plugs

Reset the spark plug gap or replace the plugs with new plugs as necessary.

- 1. Clean the area around the base of the spark plug to keep dirt and debris out of the engine.
- 2. Remove the spark plug and check its condition. Replace the spark plug if it is worn or if its reuse is questionable.
- 3. Check the spark plug gap using a wire feeler gauge. See Figure 3-4 for the recommended spark plug gap. Adjust the gap by carefully bending the ground electrode. See Figure 3-5 and Figure 3-6.
- 4. Reinstall the spark plug into the cylinder head. Torque the spark plug to 24.4-29.8 Nm (18-22 ft. lb.)

Generator Set Model	Spark Plug Gap			
14/20RES/RESL	0.76 mm (0.030 in.)			

Figure 3-4 Spark Plug Gap




Figure 3-5 Checking the Spark Plug Gap




Figure 3-6 Adjusting the Spark Plug Gap

3.4 Air Cleaner Service

3.4.1 Air Cleaner, 14RES/RESL Models

The engine has a replaceable high-density paper air cleaner element with an oiled foam precleaner. See Figure 3-7.




Figure 3-7 Air Cleaner Components

Check for a buildup of dirt and debris around the air cleaner system. Keep this area clean. Also check for loose or damaged components. Replace all bent or damaged air cleaner components.

Note: Operating the engine with loose or damaged air cleaner components could allow unfiltered air into the engine causing premature wear and failure.

Precleaner Service

Use the following procedure to wash and reoil the precleaner as indicated in the service schedule. Wash and reoil the precleaner more often under extremely dusty or dirty conditions.

 Press the OFF button on the generator set controller.

- 2. Disconnect the power to the battery charger.
- 3. Disconnect the battery, negative (-) lead first.
- 4. Loosen the cover retaining knob and remove the cover. Remove the precleaner from the paper element. Wash the precleaner in warm water with detergent. Rinse the precleaner thoroughly until all traces of detergent are eliminated. Squeeze out excess water (do not wring). Allow the precleaner to air dry.
- 5. Saturate the precleaner with new engine oil. Squeeze out all of the excess oil.
- 6. Reinstall the precleaner over the paper element.
- 7. Reinstall the air cleaner cover. Secure the cover with the cover retaining knob.
- 8. Reconnect the power to the battery charger.
- 9. Reconnect the generator set engine starting battery, negative (-) lead last.

Paper Element Service

Use the following procedure to replace the paper element at the intervals specified in the service schedule. Replace the paper element more often under extremely dusty or dirty conditions.

- Press the OFF button on the generator set controller.
- 2. Disconnect the power to the battery charger.
- 3. Disconnect the generator set engine starting battery, negative (-) lead first.
- 4. Loosen the cover retaining knob and remove the cover.
- 5. Remove the element cover nut, element cover, and the paper element with precleaner.
- 6. Remove the precleaner from the paper element.

Note: Do not wash the paper element or clean it with pressurized air, as this will damage the element.

- 7. Replace the element if it is dirty, bent, or damaged.
- 8. Check the air cleaner base. Make sure it is secure and not bent or damaged. Also check the element cover for damage and fit. Replace all damaged air cleaner components. Remove any loose dirt or debris from the air cleaner base. Wipe the base carefully so that no dirt drops into the intake throat.

- Check the condition of the rubber seal on the air cleaner stud and replace the seal if necessary.
- 9. Reinstall the paper element, precleaner, element cover, element cover nut, and the air cleaner cover. Secure the cover with the cover retaining knob.
- 10. Reconnect the power to the battery charger.
- 11. Reconnect the generator set engine starting battery, negative (-) lead last.

3.4.2 Air Cleaner, 20RES/RESL Models

The engine is equipped with a replaceable, high density paper air cleaner element. See Figure 3-8.




Figure 3-8 Air Cleaner Components

Check the air cleaner daily or before starting the engine. Check for a buildup of dirt and debris around the air cleaner system. Keep this area clean. Also check for loose or damaged components. Replace all bent or damaged air cleaner components.

Note: Operating the engine with loose or damaged air cleaner components could allow unfiltered air into the engine causing premature wear and failure.

Paper Element Service

Replace the paper element at the intervals indicated in the service schedule. See Section 3.1.2 for the service See Figure 3-8 for the air cleaner schedule. components.

- 1. Loosen the two cover retaining knobs and remove the cover.
- 2. Remove the paper element.
- 3. Do not wash the paper element or use pressurized air, as this will damage the element. Replace a dirty, bent, or damaged element. Handle new elements carefully; do not use if the sealing surfaces are bent or damaged.
- 4. When servicing the air cleaner, check the air cleaner base. Make sure it is secured and not bent or damaged. Also, check the element cover for damage or improper fit. Replace all damaged air cleaner components.

Note: If any loose dirt or debris fell on the air cleaner base when the element was removed, carefully remove it and wipe the base clean. Be careful that none of it drops into the intake throat.

- 5. Reinstall the paper element onto the air cleaner base. Make sure the element is flat and properly seated.
- 6. Install the air cleaner cover and secure with the two retaining knobs.
- 7. When element replacement is necessary, order genuine Kohler parts.

3.5 Cooling System

The engine fan draws cooling air through the openings in the sides and end near the battery. The alternator fan draws cooling air through openings on the side walls of the enclosure. The cooling air mixes with the engine exhaust and is discharged at the exhaust outlet. See Figure 1-2, Service View, for air intake and exhaust locations. To prevent generator set damage caused by overheating, keep the housing cooling inlets and outlets clean and unobstructed at all times.

Note: Do not block the generator set cooling air inlets or mount other equipment above them. Overheating and severe generator damage may occur.

3.6 **Exhaust System**

Remove all combustible materials from the exhaust location. Combustible materials include building materials as well as natural surroundings. Keep dry field grass, foliage, and combustible landscaping material a minimum of 1.5 m (5 ft.) from the exhaust outlet.

Periodically inspect the exhaust system components for cracks, leaks, and corrosion.

- Check for corroded or broken metal parts and replace them as needed.
- Check that the exhaust outlet is clear.

Battery

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Refer to this section for general battery information and maintenance. Also consult the battery manufacturer's instructions for battery maintenance.

All generator set models use a negative ground with a 12-volt engine electrical system. Consult the generator set nameplate for the engine electrical system voltage. Consult the generator spec sheet for battery capacity recommendations for replacement purposes. diagrams provide battery connection information. See Figure 3-9 for typical battery connections.




Figure 3-9 12-Volt Engine Electrical System Single Starter Motor, Typical Battery Connection

Clean the battery and cables and tighten battery terminals using the service schedule recommendations. To prevent corrosion, maintain tight, dry electrical connections at the battery terminals. To remove corrosion from battery terminals, disconnect the cables from the battery and scrub the terminals with a wire brush. Clean the battery and cables with a solution of baking soda and water. After cleaning, flush the battery and cables with clean water and wipe them with a dry, lint-free cloth.

After reconnecting the battery cables, coat the battery terminals with petroleum jelly, silicone grease, or other nonconductive grease.

3.8 Battery Charger

The generator set is equipped with a battery charger to maintain the engine starting battery. The charger's DC leads are factory-wired. Periodically check and tighten all connections.

3.8.1 RES Battery Charger

RES model generator sets are equipped with a 6-amp float/equalize battery charger to maintain the engine starting battery. The charger's power cord must be connected to a 120 VAC power source. Figure 3-10 illustrates the battery charger.

The battery charger uses an AGS 10 inline fuse. The fuse is located in the battery lead. See Figure 3-10.




Figure 3-10 6-Amp Float/Equalize Battery Charger

Battery Charger Operation

Figure 3-11 illustrates the three-stage charging method. Red and green LEDs indicate charger operation. The chart in Figure 3-12 describes the LED indicator operation during each stage of the charging process. See Section 4.4 for battery charger troubleshooting information, if necessary.




Figure 3-11 Charging Method

Display	Operating Condition
Red ON Green OFF	When the red LED is on, it indicates the battery is discharged and the battery charger is recharging at the BULK rate (stage 1). This charging rate is 6 amps. While the red LED is on, the voltage measured (with the battery charger on) will be 11.8-14 volts.
	If the red LED stays on for more than 24 hours, refer to Section 4.4 in this manual.
Red ON Green ON	When both the green and the red LEDs are on, the battery charger is charging at an ABSORPTION rate of between 1.5 and 5 amps (stage 2). This mode of charging gradually tops off your battery, and reduces harmful sulfating. While both LEDs are on, the voltage measured (with the battery charger on) should be approximately 14.0-14.5 VDC.
	If both LEDs stay on longer than 24 hours, refer to Section 4.4 in this manual.
Red OFF Green ON	When the green LED is on, the battery charger is charging at a FLOAT or MAINTENANCE rate of less than 1.5 amps (stage 3). Your battery is now 90% charged and ready for use. This float charging current will gradually decrease to as low as 0.1 amps as the battery reaches 100% charge. It will now be kept at full charge without overcharging.
	If the green LED stays on when your battery is known to be low, refer to Section 4.4 in this manual.

Figure 3-12 Battery Charger LED Indicator Functions

3.9 Circuit Protection

If the generator set circuit breaker trips or the fuses blow repeatedly, see Section 4, Troubleshooting, for possible causes.

3.9.1 **Line Circuit Breaker**

A line circuit breaker interrupts the generator output in the event of a fault in the wiring between the generator and the load. The line circuit breaker location is shown in Figure 1-2. If the circuit breaker trips, reduce the load and switch the breaker back to the ON position. With the breaker in the OFF position the generator set runs but the generator output is disconnected from the load.

3.9.2 **Fuses**

A 20-amp circuit breaker protects the alternator and two fuses protect the electrical controls. See Section 4.2 for fuse locations. A 10-amp inline fuse protects the battery charger.

See Figure 3-13 for fuse part numbers. Always identify and correct the cause of a blown fuse before restarting the generator set. Refer to Section 4, Troubleshooting, for conditions that may indicate a blown fuse. Replace blown fuses with identical replacement parts.

Fuse	Label	Rating, Amp	Part Number
Controller power	F3	3	GM66128
Fuel solenoid/ Starter relay/ Throttle control	F2	7.5	GM66129
Battery charger (RES)	_	10	223316

Figure 3-13 Fuses

3.10 Storage Procedure

Perform the following storage procedure before removing the generator set from service for three months or longer. Follow the engine manufacturer's recommendations for storage, if available.

Note: Run the generator set monthly whenever possible.

3.10.1 Lubricating System

- 1. Operate the generator set until it reaches operating temperature, or about 15 minutes.
- 2. Stop the generator set.
- 3. While the engine is still warm, drain the engine lubrication oil from the engine crankcase.
- 4. Refill engine crankcase with oil. See Section 3.2.3 for oil recommendations.
- 5. Run the generator set for a few minutes to distribute the clean oil.
- 6. Stop the generator set.

3.10.2 Fuel System

- 1. Start the generator set.
- 2. With the generator set running, shut off the gas supply.
- 3. Run the generator set until the engine stops.
- 4. Press the OFF button on the generator set controller.

3.10.3 Cylinder Lubrication

- 1. Remove the spark plugs.
- 2. Pour one tablespoon of engine oil into each spark plug hole. Install the spark plugs and ground the spark plug leads. Do not connect the leads to the plugs.
- 3. Crank the engine two or three revolutions to lubricate the cylinders.

3.10.4 Exterior Preparation

- 1. Clean the exterior surface of the generator set.
- 2. Seal all openings in the engine with nonabsorbent adhesive tape.
- 3. Mask all areas to be used for electrical contact.
- 4. Spread a light film of oil over unpainted metallic surfaces to prevent rust and corrosion.

3.10.5 **Battery**

Perform battery storage last.

- 1. Press the OFF button on the generator set controller.
- 2. Disconnect the battery, negative (-) lead first.
- 3. Clean the battery.
- 4. Place the battery in a warm, dry location.
- 5. Connect the battery to a float/equalize battery charger, or charge the battery monthly using a trickle charger. Follow the battery charger manufacturer's recommendations.

4.1 Introduction

Use the following charts to diagnose and correct common problems. First check for simple causes such as a dead engine starting battery, loose connections, or an open circuit breaker. The charts include a list of common problems, possible causes of the problem, and recommended corrective actions.

If the procedures in this manual do not explain how to correct the problem, contact an authorized distributor/dealer. Maintain a record of repairs and adjustments performed on the equipment. Use the record to help describe the problem and repairs or adjustments made to the equipment.

4.2 Controller Service Access

The controller fuses and alternator winding circuit breaker are accessible from the front of the controller. Remove the service access door to reach the circuit breaker and fuses. See Figure 4-1.

Obtain replacement fuses from a Kohler authorized distributor/dealer.




Figure 4-1 Controller Service Access (cover removed)

4.3 Generator Set Troubleshooting

Figure 4-2 contains generator set troubleshooting, diagnostic, and repair information. Check for loose connections before replacing parts.

Fault Codes

The controller displays fault codes to aid in troubleshooting. Fault codes, descriptions, and recommended actions are listed in Section 2.10.

If a fault code is displayed, identify and correct the cause of the fault condition. Then reset the controller. See Section 2.10.4.

TP-6734 1/11 Section 4 Troubleshooting 41

Problem	Possible Cause	Corrective Action		
Controller LED display is off.	Controller is OFF (check the OFF LED)	Press RUN to start the generator set or AUTO for automatic operation.		
	Controller fuse (F3) is blown.	Replace the fuse. If the fuse blows again, contact an authorized distributor/dealer.		
	Low or no battery voltage.	Check battery connections. Check the engine starting battery and battery charger. See Figure 4-3.		
The generator set does not crank.	Fault shutdown	Check for a fault code on the controller display. See Section 2.10.		
	Battery weak or dead	Check power to the battery charger. See Figure 4-3. Recharge or replace the battery.		
	Battery charger fuse blown	Replace the fuse. Contact an authorized distributor/ dealer for service if fuse blows repeatedly.		
	Battery connections reversed or poor	Check battery connections.		
	Fuse F2 blown	Replace the fuse. Contact an authorized distributor/ dealer for service if fuse blows repeatedly.		
	Fuse F3 blown	Replace the fuse. Contact an authorized distributor/ dealer for service if fuse blows repeatedly.		
	Controller is OFF (check the OFF LED)	Press AUTO for remote start or RUN for local start.		
The generator set	Air cleaner clogged	Clean and/or replace the air cleaner.		
cranks but does not start, starts hard, lacks power, or	Battery weak or dead	Check power to the battery charger. Recharge or replace the battery.		
operates erratically.	Battery connection poor	Clean and tighten the battery connections.		
	Spark plug wire connection loose	Check the spark plug wires.		
	Low oil pressure shutdown	Check the oil level.		
	Fuel pressure insufficient	Check the fuel supply and valves.		
	Engine malfunction	Contact an authorized distributor/dealer.		
No AC output.	AC circuit breaker in the OFF position	Place the circuit breaker in the ON position.		
	AC circuit breaker tripping because of overload	Reduce the load on the generator set.		
	AC circuit breaker tripping because of short circuit	Contact an authorized distributor/dealer for service.		
	Auxiliary winding circuit breaker tripped	Reset the circuit breaker. See Figure 4-1. Contact an authorized distributor/ dealer for service if circuit breaker trips repeatedly.		
Low output or excessive drop in voltage.	Generator set overloaded	Reduce the load.		
Generator set stops	Low oil pressure shutdown	Check the oil level. Check for signs of oil leaks.		
suddenly.	No fuel	Check fuel supply. Contact fuel supplier.		
	Overcrank shutdown	Reset the controller. If the overcrank fault occurs again, contact an authorized distributor/dealer.		
	Controller fuse (F3) blown	Replace the fuse. If the fuse blows again, contact an authorized distributor/dealer.		
	Overspeed shutdown	Reset the controller. If the overspeed fault occurs again, contact an authorized distributor/dealer.		
	Generator set master switch in the OFF/RESET position	Move the switch to the correct position (RUN or AUTO).		
	Remote stop command received from a remote switch or ATS	Check the remote switch position.		
	Engine malfunction	Contact an authorized distributor/dealer.		
	Auxiliary winding circuit breaker tripped	Reset the circuit breaker. See Figure 4-1. Contact an authorized distributor/dealer for service if circuit breaker trips repeatedly.		

Figure 4-2 General Troubleshooting Chart

42 Section 4 Troubleshooting TP-6734 1/11

4.4 Battery Charger Troubleshooting

Use the battery charger's LED indicators and the table in Figure 4-3 to troubleshoot battery charger operation problems.

Problem	Cause	Solution
Red LED stays on for more than 24 hours	One or more inoperative or damaged cells.	Load test the battery and replace, if necessary.
	Battery charger has reduced its output voltage below the normal level due to a DC overload or a DC short.	Remove the source of the overload or short. Disconnect the battery charger's black (NEGATIVE) ring terminal from the battery. Reapply AC power and the green LED only should now light.
	Onboard DC systems are drawing more current than the battery charger can replace.	Turn off all DC equipment while charging.
Red and green LEDs stay on for more than 24 hours	Onboard DC systems are drawing between 1.5 and 5 amps.	Turn off all DC equipment while charging.
	One or more inoperative or damaged cells.	Load test the battery and replace, if necessary.
	Extremely low AC voltage at the battery charger.	Apply a higher AC voltage source or reduce the length of the extension cord.
Green LED stays on	Open DC output fuse.	Replace AGS-10 fuse.
when the battery is known to be low	Faulty or contaminated terminal connections.	Clean and tighten or repair all terminal connections.
	One or more inoperative or damaged cells.	Load test the battery and replace, if necessary.
Neither of the LEDs turn on when the	No AC power available at the battery charger.	Connect AC power or reset the AC breaker on the main panel.
AC power is applied	Component failure.	Replace battery charger.

Figure 4-3 6-Amp Battery Charger Troubleshooting

TP-6734 1/11 Section 4 Troubleshooting 43

Notes

44 Section 4 Troubleshooting TP-6734 1/11

Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

	9	•	, , ,		
A, amp	ampere	cfm	cubic feet per minute	exh.	exhaust
ABDC	after bottom dead center	CG	center of gravity	ext.	external
AC	alternating current	CID	cubic inch displacement	F	Fahrenheit, female
A/D	analog to digital	CL	centerline	FHM	flat head machine (screw)
ADC			centimeter	fl. oz.	fluid ounce
ADC	advanced digital control;	cm			
	analog to digital converter	CMOS	complementary metal oxide	flex.	flexible
adj.	adjust, adjustment		substrate (semiconductor)	freq.	frequency
ADV	advertising dimensional	com	communications (port)	FS	full scale
	drawing	coml	commercial	ft.	foot, feet
Ah	amp-hour	Coml/Rec	Commercial/Recreational	ft. lb.	foot pounds (torque)
AHWT	anticipatory high water	conn.	connection	ft./min.	feet per minute
,	temperature			. '	•
AISI	American Iron and Steel	cont.	continued	ftp	file transfer protocol
AISI		CPVC	chlorinated polyvinyl chloride	g	gram
41.00	Institute	crit.	critical	ga.	gauge (meters, wire size)
ALOP	anticipatory low oil pressure	CSA	Canadian Standards	gal.	gallon
alt.	alternator		Association	gen.	generator
Al	aluminum	CT	current transformer	-	Š .
ANSI	American National Standards	Cu	copper	genset	generator set
, .	Institute (formerly American		• •	GFI	ground fault interrupter
	Standards Association, ASA)	cUL	Canadian Underwriter's	GND,	ground
AO	anticipatory only		Laboratories		Š .
		CUL	Canadian Underwriter's	gov.	governor
APDC	Air Pollution Control District		Laboratories	gph	gallons per hour
API	American Petroleum Institute	cu. in.	cubic inch	gpm	gallons per minute
approx.	approximate, approximately	CW.	clockwise	gr.	grade, gross
APU	Auxiliary Power Unit	CWC	city water-cooled	ĞRD	equipment ground
AQMD	Air Quality Management District		•	gr. wt.	gross weight
AR	as required, as requested	cyl.	cylinder		height by width by depth
		D/A	digital to analog		
AS	as supplied, as stated, as	DAC	digital to analog converter	HC	hex cap
	suggested	dB	decibel	HCHT	high cylinder head temperature
ASE	American Society of Engineers	dB(A)	decibel (A weighted)	HD	heavy duty
ASME	American Society of	DC	direct current	HET	high exhaust temp., high
	Mechanical Engineers				engine temp.
assy.	assembly	DCR	direct current resistance	hex	hexagon
ASTM	American Society for Testing	deg., °	degree		
710 T W	Materials	dept.	department	Hg	mercury (element)
ATDC		dia.	diameter	HH	hex head
ATDC	after top dead center	DI/EO	dual inlet/end outlet	HHC	hex head cap
ATS	automatic transfer switch	DIN	Deutsches Institut fur Normung	HP	horsepower
auto.	automatic	DIN	e. V. (also Deutsche Industrie	hr.	hour
aux.	auxiliary			HS	heat shrink
avg.	average	DID	Normenausschuss)		
AVR	automatic voltage regulator	DIP	dual inline package	hsg.	housing
AWG	ŭ ŭ	DPDT	double-pole, double-throw	HVAC	heating, ventilation, and air
	American Wire Gauge	DPST	double-pole, single-throw	—	conditioning
AWM	appliance wiring material	DS	disconnect switch	HWT	high water temperature
bat.	battery	DVR	digital voltage regulator	Hz	hertz (cycles per second)
BBDC	before bottom dead center	E ² PROM,		IBC	International Building Code
BC	battery charger, battery	L I ITOWI,		IC	integrated circuit
	charging		electrically-erasable programmable read-only	ID	inside diameter, identification
BCA	battery charging alternator				,
	, , ,		memory	IEC	International Electrotechnical
BCI	Battery Council International	E, emer.	emergency (power source)		Commission
BDC	before dead center	ECM	electronic control module,	IEEE	Institute of Electrical and
BHP	brake horsepower		engine control module		Electronics Engineers
blk.	black (paint color), block	EDI	electronic data interchange	IMS	improved motor starting
	(engine)	EFR	emergency frequency relay	in.	inch
blk. htr.	block heater	e.g.	for example (exempli gratia)	in. H₂O	inches of water
BMEP	brake mean effective pressure	EG.	electronic governor	_	
	·			in. Hg	inches of mercury
bps	bits per second	EGSA	Electrical Generating Systems	in. lb.	inch pounds
br.	brass		Association	Inc.	incorporated
BTDC	before top dead center	EIA	Electronic Industries	ind.	industrial
Btu	British thermal unit		Association	int.	internal
Btu/min.	British thermal units per minute	EI/EO	end inlet/end outlet	int./ext.	internal/external
C	Celsius, centigrade	EMI	electromagnetic interference		
	, 0	emiss.	emission	I/O	input/output
cal.	calorie			IP	internet protocol
CAN	controller area network	eng.	engine	ISO	International Organization for
CARB	California Air Resources Board	EPA	Environmental Protection		Standardization
CAT5	Category 5 (network cable)		Agency	J	joule
СВ	circuit breaker	EPS	emergency power system	JIS	Japanese Industry Standard
CC	crank cycle	ER	emergency relay	k	kilo (1000)
	•	ES	engineering special,		,
CC	cubic centimeter		engineered special	K	kelvin
CCA	cold cranking amps	ESD	•	kA	kiloampere
CCW.	counterclockwise		electrostatic discharge	KB	kilobyte (2 ¹⁰ bytes)
CEC	Canadian Electrical Code	est.	estimated	KBus	Kohler communication protocol
cert.	certificate, certification, certified	E-Stop	emergency stop	kg	kilogram
cfh	cubic feet per hour	etc.	et cetera (and so forth)	٠.5	g··
J	Sabis for float				

TP-6734 1/11 Appendix 45

kg/cm ²	kilograms per square centimeter	NBS	National Bureau of Standards	RTU	remote terminal unit
kam	kilogram-meter	NC	normally closed	RTV	room temperature vulcanization
kgm kg/m ³		NEC	National Electrical Code	RW	read/write
	kilograms per cubic meter	NEMA	National Electrical	SAE	Society of Automotive
kHz	kilohertz	NEDA	Manufacturers Association		Engineers
kJ	kilojoule	NFPA	National Fire Protection	scfm	standard cubic feet per minute
km	kilometer	Nim	Association	SCR	silicon controlled rectifier
kOhm, kΩ		Nm	newton meter	s, sec.	second
kPa ·	kilopascal	NO	normally open	SI	Systeme international d'unites,
kph	kilometers per hour	no., nos.	number, numbers	01/50	International System of Units
kV	kilovolt	NPS	National Pipe, Straight	SI/EO	side in/end out
kVA	kilovolt ampere	NPSC	National Pipe, Straight-coupling	sil.	silencer
kVAR	kilovolt ampere reactive	NPT	National Standard taper pipe	SMTP	simple mail transfer protocol
kW	kilowatt		thread per general use	SN	serial number
kWh	kilowatt-hour	NPTF	National Pipe, Taper-Fine	SNMP	simple network management
kWm	kilowatt mechanical	NR	not required, normal relay		protocol
kWth	kilowatt-thermal	ns	nanosecond	SPDT	single-pole, double-throw
L	liter	OC	overcrank	SPST	single-pole, single-throw
LAN	local area network	OD	outside diameter	spec	specification
LxWxH	length by width by height	OEM	original equipment	specs	specification(s)
lb.	pound, pounds		manufacturer	sq.	square
lbm/ft ³	pounds mass per cubic feet	OF	overfrequency	sq. cm	square centimeter
LCB	line circuit breaker	opt.	option, optional	sq. in.	square inch
LCD	liquid crystal display	os	oversize, overspeed	SMS	short message service
LED	light emitting diode	OSHA	Occupational Safety and Health	SS	stainless steel
Lph	liters per hour		Administration	std.	standard
Lpm	liters per minute	OV	overvoltage	stl.	steel
LOP	•	OZ.	ounce	tach.	tachometer
	low oil pressure	p., pp.	page, pages	TB	terminal block
LP LPG	liquefied petroleum	PC	personal computer	TCP	transmission control protocol
	liquefied petroleum gas	PCB	printed circuit board	TD.	time delay
LS	left side	pF	picofarad	TDC	top dead center
L _{wa}	sound power level, A weighted	PF	power factor	TDEC	time delay engine cooldown
LWL	low water level	ph., ∅	phase	TDEN	time delay emergency to
LWT	low water temperature	PHC	Phillips® head Crimptite®	IDLIN	normal
m	meter, milli (1/1000)		(screw)	TDES	time delay engine start
M	mega (10 ⁶ when used with SI	PHH	Phillips® hex head (screw)	TDNE	time delay normal to
3	units), male	PHM	pan head machine (screw)	IDINE	emergency
m ³	cubic meter	PLC	programmable logic control	TDOE	time delay off to emergency
m ³ /hr.	cubic meters per hour	PMG	permanent magnet generator	TDON	time delay off to normal
m ³ /min.	cubic meters per minute	pot	potentiometer, potential	temp.	temperature
mA	milliampere	ppm	parts per million	term.	terminal
man.	manual	PROM	programmable read-only	THD	total harmonic distortion
max.	maximum	1 110101	memory	TIF	telephone influence factor
MB	megabyte (2 ²⁰ bytes)	psi	pounds per square inch	tol.	tolerance
MCCB	molded-case circuit breaker	psig	pounds per square inch gauge		
MCM	one thousand circular mils	pt.	pint	turbo.	turbocharger
meggar	megohmmeter	PTC	positive temperature coefficient	typ.	typical (same in multiple locations)
MHz	megahertz	PTO	power takeoff	UF	underfrequency
mi.	mile	PVC	polyvinyl chloride	UHF	, ,
mil	one one-thousandth of an inch				ultrahigh frequency
min.	minimum, minute	qt.	quart, quarts quantity	UIF	user interface
misc.	miscellaneous	qty.		UL	Underwriter's Laboratories, Inc.
MJ	megajoule	R	replacement (emergency) power source	UNC	unified coarse thread (was NC)
mJ	millijoule	rad.	radiator, radius	UNF	unified fine thread (was NF)
mm	millimeter			univ.	universal
mOhm, mΩ		RAM	random access memory	URL	uniform resource locator
MOhm, MS		RDO	relay driver output		(web address)
MOV	metal oxide varistor	ref.	reference	US	undersize, underspeed
MPa	megapascal	rem.	remote	UV	ultraviolet, undervoltage
	miles per gallon	Res/Coml	· · · · · · · · · · · · · · · · · · ·	V	volt
mpg		RFI	radio frequency interference	VAC	volts alternating current
mph Me	miles per hour	RH	round head	VAR	voltampere reactive
MS ma	military standard	RHM	round head machine (screw)	VDC	volts direct current
ms m/aaa	millisecond	rly.	relay	VFD	vacuum fluorescent display
m/sec.	meters per second	rms	root mean square	VGA	video graphics adapter
	mounting	rnd.	round	VHF	very high frequency
	Motoren-und Turbinen-Union	RO	read only	W	watt
mtg. MTU		DOM	read only memory	WCR	withstand and closing rating
MTU MW	megawatt	ROM			
MTU MW mW	milliwatt	rot.	rotate, rotating	w/	with
MTU MW mW μF	milliwatt microfarad	rot.	rotate, rotating	w/ WO	with write only
MTU MW mW μF N, norm.	milliwatt microfarad normal (power source)		rotate, rotating revolutions per minute	WO	write only
MTU MW mW μF	milliwatt microfarad	rot. rpm	rotate, rotating		

46 Appendix TP-6734 1/11

KOHLERPOVVER SYSTEMS

KOHLER CO. Kohler, Wisconsin 53044 Phone 920-457-4441, Fax 920-459-1646 For the nearest sales/service outlet in the US and Canada, phone 1-800-544-2444 KohlerPower.com

Kohler Power Systems Asia Pacific Headquarters 7 Jurong Pier Road Singapore 619159 Phone (65) 6264-6422, Fax (65) 6264-6455