Installation

Residential/Commercial Generator Sets



Models:

12RESM1 12/18RESL

Controller: DC-RET Digital Control



KOHLER® POWER SYSTEMS_____

California Proposition 65



WARNING

Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Product Identification Information

Generator Set Identification Numbers	Engine Identification
Record the product identification numbers from the generator set nameplate(s).	Record the product identification information from the engine nameplate.
Model Designation	Manufacturer
Specification Number	Model Designation
Serial Number	Serial Number
Accessory Number	Controller Identification
	Record the controller description from the generator set operation manual, spec sheet, or sales invoice.
	Controller Description
	·

Table of Contents

Product Identification	Informat	tion	2
Safety Precautions an	d Instru	ctions	5
Introduction			9
Service Assistance			11
Section 1 Installation			13
1.1	General		13
1.2	Lifting .		13
1.3	Generat	or Set Inspection	13
1.4	Location	n and Mounting	13
	1.4.1	Exhaust Requirements	14
	1.4.2	Air Requirements	14
1.5	Power S	Supply	14
1.6	Fuel Re	quirements	15
	1.6.1	Fuel Supply	15
	1.6.2	Fuel Pipe Size	16
	1.6.3	Fuel Inlet Connection	16
1.7	Fuel Co	nversion	16
1.8	Electrica	al Connections	18
	1.8.1	Field Connections	18
	1.8.2	Remote Start Connection	19
	1.8.3	Grounding	20
	1.8.4	Battery Charger Power	20
1.9	Battery .		20
1.10	Carbure	tor Heater (optional)	22
1.11	Prestart	Installation Check	23
1.12	Startup	Notification	23
Section 2 Dimension	Drawing	s and Wiring Diagrams	25
Appendix A Abbreviation	ons		35

Notes

4 TP-6793 10/11

Safety Precautions and Instructions

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. SAVE THESE INSTRUCTIONS.

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.



DANGER

Danger indicates the presence of a hazard that will cause severe personal injury, death, or substantial property damage.



WARNING

Warning indicates the presence of a hazard that *can cause severe* personal injury, death, or substantial property damage.



CAUTION

Caution indicates the presence of a hazard that *will* or *can cause minor personal injury* or *property damage*.

NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator Accidental starting can cause severe injury or death. working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

Battery

A

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

▲ WARNING



Explosion.

Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eves or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all iewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death.

Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Engine Backfire/Flash Fire



Fire.
Can cause severe injury or death.

Do not smoke or permit flames or sparks near fuels or the fuel system.

Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner removed.

Servicing the fuel system. A flash fire can cause severe injury or death.

Do not smoke or permit flames or sparks near the carburetor, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Catch fuels in an approved container when removing the fuel line or carburetor.

Combustible materials. A fire can cause severe injury or death. Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or BC for electrical fires or as recommended by the local fire code or an authorized agency. Train all fire extinguisher personnel on operation and fire prevention procedures.

Exhaust System



Carbon monoxide.
Can cause severe nausea, fainting, or death.

The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

Fuel System



Explosive fuel vapors.
Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

Gas fuel leaks. **Explosive fuel** vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LP vapor gas or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces per square inch (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

Hazardous Noise

▲ CAUTION



Hazardous noise. Can cause hearing loss.

Never operate the generator set without a muffler or with a faulty exhaust system.

Engine noise. Hazardous noise can cause hearing loss. Generator sets not equipped with sound enclosures can produce noise levels greater than 105 dBA. Prolonged exposure to noise levels greater than 85 dBA can cause permanent hearing loss. Wear hearing protection when near an operating generator set.

Hazardous Voltage/ Moving Parts







Hazardous voltage. Moving parts. Can cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

WARNING



Hazardous voltage.

Backfeed to the utility system can cause property damage, severe injury, or death.

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply. **A** CAUTION



Welding the generator set.

Can cause severe electrical equipment damage.

Never weld components of the generator set without first disconnecting the battery, controller wiring harness, and engine electronic control module (ECM).

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Welding on the generator set. Can cause severe electrical equipment damage. Before welding on the generator set perform the following steps: (1) Remove the battery cables, negative (-) lead first. (2) Disconnect all engine electronic control module (ECM) connectors. (3) Disconnect all generator set controller and voltage regulator circuit board connectors. (4) Disconnect the engine battery-charging alternator connections. (5) Attach the weld ground connection close to the weld location.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death. Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.

A WARNING



Airborne particles.
Can cause severe injury or blindness.

Wear protective goggles and clothing when using power tools, hand tools, or compressed air.

Heavy Equipment

▲ WARNING



Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.

Do not use lifting eyes.

Lift the generator set using lifting bars inserted through the lifting holes on the skid.

Hot Parts



Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Servicing the engine heater. Hot parts can cause minor personal injury or property damage. Install the heater before connecting it to power. Operating the heater before installation can cause burns and component damage. Disconnect power to the heater and allow it to cool before servicing the heater or nearby parts.

Notice

NOTICE

Canadian installations only. For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code, Part 1.

9

This manual provides installation instructions for Model 12RESL/12RESM1 and 18RESL residential/commercial generator sets equipped with the Kohler® DC-RET Digital Control. Refer to TP-6517, Operation Manual, for generator set operation and maintenance instructions.

The generator set is approved for use in stationary applications in locations served by a reliable utility power source.

Have an authorized distributor/dealer install the generator set outdoors according to the instructions in this manual. The generator set installation must comply with the National Electrical Code (NEC) and local code requirements. Do not install this generator set indoors.

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual.

See Figure 1 or Figure 2 for generator set component locations.




Figure 1 Generator Set Component Locations, Model 12RESL/12RESM1

TP-6793 10/11




Figure 2 Generator Set Component Locations, Model 18RESL

10 TP-6793 10/11

For professional advice on generator set power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KohlerPower.com.
- Look at the labels and stickers on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

Headquarters Europe, Middle East, Africa (EMEA)

Kohler Power Systems 3 rue de Brennus 93200 Saint Denis

France

Phone: (33) 1 49 178300 Fax: (33) 1 49 178301

Asia Pacific

Power Systems Asia Pacific Regional Office Singapore, Republic of Singapore

Phone: (65) 6264-6422 Fax: (65) 6264-6455

China

North China Regional Office, Beijing

Phone: (86) 10 6518 7950

(86) 10 6518 7951

(86) 10 6518 7952 Fax: (86) 10 6518 7955

East China Regional Office, Shanghai

Phone: (86) 21 6288 0500 Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office Bangalore, India

Phone: (91) 80 3366208

(91) 80 3366231

Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office

Tokyo, Japan

Phone: (813) 3440-4515 Fax: (813) 3440-2727

TP-6793 10/11 11

Notes

12 TP-6793 10/11

1.1 General

Have an authorized distributor/dealer install the generator set outdoors according to the instructions in this manual. The generator set installation must comply with the National Electrical Code (NEC) and local code requirements. Do not install this generator set indoors.

Use the generator set and transfer switch dimension drawings and wiring diagrams for installation. See Section 2 for the generator set dimension drawings and wiring diagrams.

1.2 Lifting



Approximate generator set weights are shown in Figure 1-1. Use lifting bars inserted through the holes in the skid to lift the unit. See the dimension drawings in Section 2 for lifting hole locations.

Model	Weight, kg (lb.)
12RESL/12RESM1	186 (410)
18RESL	227 (500)

Figure 1-1 Approximate Weights

1.3 Generator Set Inspection

Complete a thorough inspection of the generator set. Check for the following:

- Inspect the generator set for loose or damaged parts or wires. Repair or tighten any loose parts before installation.
- Check the engine oil. Fill, if necessary, with the recommended viscosity and grade of oil. Use synthetic oil, API (American Petroleum Institute) Service Class SG or higher. See TP-6517, Operation Manual, for additional information.

1.4 Location and Mounting


See the dimension drawings in Section 2 for the generator set dimensions and fuel and electric inlet locations. The dimensions are shown in millimeters, with inches in brackets.

Install the generator set outdoors. Provide the minimum clearance around the generator set shown in the clearance drawings in Section 2. Locate the generator set so that the hot exhaust does not blow on plants or other combustible materials. Do not install the generator set where exhaust gas could accumulate and seep inside or be drawn into a potentially occupied building.

The generator set is shipped on a plastic mounting pad. Prepare a flat, level mounting area covered with a weed barrier and gravel or a concrete pad as shown in the generator set clearance drawing. Set the plastic mounting pad directly on the gravel or concrete. Do not install the mounting pad directly on grass.

See the dimension drawings in Section 2 for special mounting instructions for high wind (150 MPH) areas.

1.4.1 Exhaust Requirements



Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

The exhaust system is complete for generator sets installed outdoors. Do not install this generator set indoors.

Figure 1-2 gives the exhaust flow and temperature at rated load. The engine exhaust mixes with the generator set cooling air at the exhaust end of the enclosure. Mount the generator set so that the hot exhaust does not blow on plants or other combustible materials. Maintain the clearances shown in the dimension drawing in Section 2.

Exhaust System	60 Hz
Exhaust flow at rated kW, m³/min. (cfm)	
12RESL/12RESM1	3.8 (135)
18RESL	5.3 (187)
Exhaust gas temperature exiting the enclosure at rated kW, °C (°F)	216 (420)

Figure 1-2 Exhaust Flow and Temperature

1.4.2 Air Requirements

The generator set requires correct air flow for cooling and combustion. The inlet and outlet openings in the sound enclosure provide the cooling and combustion air. Figure 1-3 shows the locations of the cooling air intake and exhaust vents. Inspect the air inlet and outlet openings inside and outside the housing to ensure that the air flow is not blocked.




Figure 1-3 Cooling Air Intake and Exhaust

	Air Requirements, m³/min. (cfm)			
Model	Hz	Hz Cooling Combustion Air		Total Inlet Air
100501	60	26.9 (950)	1.1 (39.2)	28.0 (990)
12RESL	50	22.4 (790)	0.9 (32.6)	23.4 (826)
100501	60	28.0 (989)	1.62 (57.3)	29.6 (1045)
18RESL	50	22.6 (798)	1.42 (50.1)	24.0 (848)

Figure 1-4 Air Requirements

1.5 Power Supply

Power must be supplied from a source that is GFCI protected to the generator set location for the battery charger and the optional carburetor heater. See Section 1.8. Connect power from a circuit on the essential loads panel to the 120-VAC receptacles. The circuit must be backed up by the generator set. Figure 1-5 lists the power requirements for the battery charger and accessories.

	Power Requirement, Max.		
Equipment	Watts	Amps	Volts
Battery charger	192	1.6	
Carburetor heater:			
12RESL	38	0.32	120
18RESL	40	0.34	
Battery heater	110	0.92	

Figure 1-5 Power Requirements

1.6 Fuel Requirements

The generator set operates using natural gas or LP vapor fuel. The generator set is EPA-certified for both natural gas and LP vapor fuels.

The fuel system installation must comply with the NEC and local codes.

1.6.1 Fuel Supply

Because of variable climates and geographical considerations, contact the local fuel supplier for fuel system planning and installation. Figure 1-6 lists the recommended fuel ratings and other fuel supply information for natural gas and LP vapor fuels.

Verify that the output pressure from the primary gas utility (or LP tank) pressure regulator is within the range shown in Figure 1-6 and that the utility gas meter flow rate is sufficient to supply the generator set at rated load plus all other gas-consuming appliances. See Figure 1-7 or Figure 1-8 for fuel consumption. Contact the fuel supplier for flow rate information or a gas meter upgrade, if necessary.

Fuel types	Natural Gas	LP Vapor
Fuel supply inlet	1/2 NPT	1/2 NPT
Fuel supply pressure, kPa (in. H ₂ O):		
12RESL	1.3-2.7 (5-11)	1.7-2.7 (7-11)
18RESL	1.7-2.7 (7-11)	1.7-2.7 (7-11)
Fuel flow rate, Btu/hr.:		
12RESL	193000	203000
18RESL	242000	280000
Nominal Fuel Rating, Btu/ft ³	1000	2500

Figure 1-6 Fuel Supply

12RESL	Fuel Consumption, m ³ /hr. (cfh)	
% Rated Load	Natural Gas	LP Vapor
100%	5.4 (193)	2.3 (81)
75%	4.7 (163)	2.1 (75)
50%	3.5 (124)	1.8 (60)
25%	2.6 (93)	1.2 (45)

LP vapor conversion factors:

8.58 ft. 3 = 1 lb. 0.535 m 3 = 1 kg 36.39 ft. 3 = 1 gal.

Nominal fuel rating:

Natural gas: 37 MJ/m³ (1000 Btu/ft.³) LP vapor: 93 MJ/m³ (2500 Btu/ft.³)

Figure 1-7 Fuel Consumption, 12RESL Models

18RESL	Fuel Consumption, m ³ /hr. (cfh)	
% Rated Load	Natural Gas	LP Vapor
100%	6.9 (242)	3.2 (112)
75%	5.8 (204)	2.7 (96)
50%	4.4 (155)	2.1 (74)
25%	3.4 (120)	1.6 (57)

LP vapor conversion factors:

8.58 ft.³ = 1 lb. 0.535 m³ = 1 kg 36.39 ft.³ = 1 gal.

Nominal fuel rating:

Natural gas: 37 MJ/m³ (1000 Btu/ft.³) LP vapor: 93 MJ/m³ (2500 Btu/ft.³)

Figure 1-8 Fuel Consumption, 18RESL Models

1.6.2 Fuel Pipe Size

Ensure that the fuel supply pipe size and length meet the specifications in Figure 1-9 or Figure 1-10. Measure the pipe length from the primary gas pressure regulator to the pipe connection on the generator set fuel inlet. Add 2.4 m (8 ft.) to the measured length for each 90 degree elbow. Compare the total pipe length with the chart in Figure 1-9 or Figure 1-10 to find the required pipe size.

Contact the local LP provider for LP installation information.

Minim	Minimum Gas Pipe Size Recommendation, in. NPT			
		12RESL/12RESM1		
	_ength, (ft.)	Natural Gas (193,000 Btu/hr.)	LP Vapor (203,000 Btu/hr.)	
8 m	(25 ft.)	3/4	3/4	
15 m	(50 ft.)	1	3/4	
30 m	(100 ft.)	1	1	
46 m	(150 ft.)	1 1/4	1	
61 m	(200 ft.)	1 1/4	1	

Figure 1-9 Fuel Pipe Size, 12RESL/12RESM1

Minimum Gas Pipe Size Recommendation, in. NPT				
		18RESL		
	_ength, (ft.)	Natural Gas (242,000 Btu/hr.)	LP Vapor (280,000 Btu/hr.)	
8 m	(25 ft.)	1	3/4	
15 m	(50 ft.)	1	1	
30 m	(100 ft.)	1 1/4	1	
46 m	(150 ft.)	1 1/4	1 1/4	
61 m	(200 ft.)	1 1/4	1 1/4	

Figure 1-10 Fuel Pipe Size, 18RESL

1.6.3 Fuel Inlet Connection

See the dimension drawings in Section 2 (or Figure 1-15 and Figure 1-16) for the location of the fuel inlet connection. Use flexible sections to prevent fuel line breakage caused by vibration. Hold the fuel solenoid valve with a wrench when tightening the fuel connections. Protect all fuel lines from machinery or equipment contact, adverse weather conditions, and environmental damage.

1.7 Fuel Conversion

The multi-fuel system allows conversion from natural gas to LP vapor (or vice-versa) in the field while maintaining emissions-standard compliance. A trained technician or authorized distributor/dealer can convert the fuel system.



Accidental starting.
Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or connected equipment, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.



Explosive fuel vapors.
Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

For LP vapor fuel, an orifice is used in the fuel line. The unit is typically shipped set up for natural gas, with the loose LP orifice tied near the fuel line. To convert to LP vapor, install the orifice and disconnect the spark advance leads as described in the following procedure. See Figure 1-11 for the fuel system component locations.

To convert from LP vapor to natural gas, remove the fuel orifice and connect the DSAI leads together.

Procedure to Convert from NG to LP

- 1. Place the generator set master switch in the OFF position.
- 2. Disconnect the power to the battery charger.
- 3. Disconnect the generator set engine starting battery, negative (-) lead first.
- 4. Turn off the fuel supply.
- 5. Remove the hose clamp and fuel hose from the hose fitting. See Figure 1-11.




Figure 1-11 Fuel System Components, Air Inlet Side, 18RESL Shown

6. Place the orifice into the hose fitting. See Figure 1-12.




Figure 1-12 LP Fuel Orifice Installation

- 7. Slide the hose onto the hose fitting and secure it with the clamp.
- 8. Disconnect the digital spark-advance module (DSAI) leads for LP. (Connect the leads for natural gas.) See Figure 1-13 and Figure 1-14.

Fuel	DSAI Leads
Natural Gas	Connect
LP	Disconnect

Figure 1-13 DSAI Connection




Figure 1-14 Digital Spark Advance (DSAI) Leads (located in generator set air intake area)

- 9. Connect and turn on the new fuel supply.
- 10. Check that the generator set master switch is in the OFF position.
- 11. Reconnect the generator set engine starting battery leads, negative (-) lead last.
- 12. Reconnect power to the battery charger.
- 13. Start the generator set by moving the generator set master switch to the RUN position.
- 14. Check for leaks using a gas leak detector.
- 15. Move the generator set master switch to the OFF/ RESET position to shut down the generator set.

1.8 Electrical Connections



Hazardous voltage. Backfeed to the utility system can cause property damage, severe injury, or death.

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death. Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.

NOTICE

Canadian installations only. For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code. Part 1.

Have an authorized distributor/dealer or a licensed electrician make the following electrical connections. Verify that the electrical installation complies with the National Electrical Code (NEC) and all applicable local codes. Ground the generator set according to applicable codes.

1.8.1 Field Connections

The generator set is equipped with a field-connection terminal block located in the air inlet area near the junction box. Leads have been factory-installed from the junction box to the terminal block for easier field wiring. Refer to the decal near the terminal block for connections. Also see the wiring diagrams in Section 2.

Refer to the decal below the terminal block and the transfer switch specifications for the acceptable cable sizes. Route leads through flexible conduit. Use separate conduit for AC wiring and low-voltage engine start leads. Ensure that the leads and conduit do not interfere with the operation of the generator set or obstruct the service areas.

The electrical installation must comply with the National Electrical Code (NEC) and all applicable local codes.

Connection Procedure

- 1. 12RESL: Remove the cover from the electrical connection access area. See Figure 1-15.
- Drill holes for conduit fittings as described for each model below:
 - a. 12RESL: See Figure 1-15 for the electrical inlet location. Remove the cover from the electrical inlet area. Drill holes in the cover for the conduit fittings and replace the cover. Use separate conduit for AC wiring and low-voltage engine start leads. Feed the cables through the openings.
 - b. 18RESL: See Figure 1-16 for the recommended electrical inlet location. Drill holes for the conduit fittings. Use separate conduit for AC wiring and low-voltage engine start leads. Feed the cables through the openings.




Figure 1-15 12RESL/12RESM1 Electrical Connection Area




Figure 1-16 18RESL Electrical Inlets

- See Figure 1-17. Connect the leads from the transfer switch emergency source lugs to the L1 and L2 connections on the generator set terminal block.
- Connect the neutral (L0) and ground (GRD) leads from the ATS and the main panel to the corresponding connection points on the terminal block. See Section 1.8.3, Grounding.
- Connect 120 VAC utility power to the terminals marked Utility Power. Power to this circuit must be backed-up by the generator set. See Section 1.5 for more information about the utility power requirement.
- 6. Connect the engine start leads from the automatic transfer switch or remote start switch to terminals 3 and 4 on the terminal block.
- 7. 12RESL/12RESM1: Replace the cover over the electrical connection access area. See Figure 1-15.




Figure 1-17 Field-Connection Terminal Block

1.8.2 Remote Start Connection

Connect engine start leads from terminals 3 and 4 to the automatic transfer switch's engine start terminals or to an optional remote start/stop switch. Route the engine start leads through separate conduit from the AC power and load leads.

1.8.3 Grounding

Ground the generator set. The grounding method must comply with NEC and local codes. Connect the grounding strap to the generator set ground lug, terminal GND inside the controller compartment.

Generator sets are shipped with the generator neutral bonded (connected) to the generator ground in the junction box. The requirement for having a bonded (grounded) or ungrounded neutral is determined by the type of installation. At installation, the neutral can be grounded at the generator set or lifted from the ground stud and isolated if the installation requires an ungrounded neutral connection at the generator. The generator set will operate properly with the neutral either bonded to ground or isolated from ground at the generator.

Various regulations and site configurations including the National Electrical Code (NEC), local codes, and the type of transfer switch used in the application determine the grounding of the neutral at the generator. NEC Section 250 is one example that has a very good explanation of the neutral grounding requirements for generators.

1.8.4 Battery Charger Power

A 6-amp battery charger is factory-installed in the battery compartment to keep the starting battery fully charged. The battery charger's DC leads are factory-connected.

Plug the battery charger's power cord into the receptacle on the bottom of the controller junction box. See Section 1.5, Power Supply. Refer to the generator set Operation Manual for battery charger operation information.

1.9 Battery

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.



Explosion.

Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Use a 12-volt battery with a minimum rating of 500 cold cranking amps at 0°F. The generator set uses a negative ground with a 12-volt engine electrical system. See Figure 1-18 for battery connections. Make sure that the battery is correctly connected and the terminals are tight.

Note: The generator set will not start and circuit board damage may occur if the battery is connected in reverse.




Figure 1-18 12-Volt Engine Electrical System Single Starter Motor Typical Battery Connection

Figure 1-19 shows the location of the engine starting battery. Standard battery cables provide easy connection to the battery. Use the following procedure to install and connect the battery.




Figure 1-19 Battery Location, Air Intake End (typical)

Battery Installation Procedure

- 1. Ensure that the starting battery is fully charged before placing the battery in service.
- 2. Clean the battery posts and/or adapters if necessary.
- 3. Install the battery post adapters, if needed.
- 4. Place the battery in the housing.
- 5. Verify that the controller master switch is in the OFF position.
- 6. Connect the positive (+) lead to the engine starting battery.
- 7. Connect the negative (-) lead to the engine starting battery.

Refer to the generator set Operation Manual and the battery manufacturer's instructions for battery maintenance instructions.

1.10 Carburetor Heater (optional)

Have accessories installed by an authorized distributor/ dealer or a licensed electrician. Follow the installation instructions provided with each kit. Use separate conduit for AC and DC leads to reduce the possibility of electrical interference. Verify that the leads and conduit do not interfere with the operation of the generator set or obstruct the service areas. Verify that the electrical installation complies with the National Electrical Code (NEC) and all applicable local codes. See the wiring diagrams in Section 2 for more information regarding generator set electrical connections.

An optional carburetor heater is recommended for improved cold starting in locations where the ambient temperature drops below 0°C (32°F). The carburetor heater prevents condensation and carburetor icing. The heater turns on when the temperature at the thermostat falls below approximately 4°C (40°F) and turns off when the temperature rises above approximately 16°C (60°F). See Figure 1-20 through Figure 1-23.

The heater thermostat is installed in the cord. Figure 1-23 shows the location of the thermostat on the power cord.




Figure 1-20 Carburetor Heater Location, 12RESL

The heater requires a continuous source of 120 VAC power. The heater power cord and thermostat are located in the generator set housing air intake area/

battery compartment. See Figure 1-19 and Figure 1-21. Plug the carburetor heater into an outlet that supplies continuous 120 VAC power.

Note: Do not place the heater thermostat inside the generator set engine compartment. The thermostat must be exposed to the ambient air. Thermostat will shut off power to the heater when ambient temperature reaches approximately 16°C (60°F).

Figure 1-22 shows the location of the carburetor heater on the 18RESL generator set engine for reference. (The engine has been removed from the generator set in this photo for a clear view.)




Figure 1-21 Carburetor Heater, 18RESL




Figure 1-22 Carburetor Heater Location, 18RESL




Figure 1-23 Carburetor Heaters

1.11 Prestart Installation Check

Review the entire installation section. Inspect all wiring and connections to verify that the generator set is ready for operation. Check all items in the following Prestart Checklist.

Prestart Checklist

Air Cleaner. Check that a clean air cleaner element is installed to prevent unfiltered air from entering the engine. See the generator set Operation Manual for instructions.

Air Inlets. Check for clean and unobstructed air inlets.

Battery. Check for tight battery connections. Consult the battery manufacturer's instructions regarding battery care and maintenance.

Exhaust System. Check for exhaust leaks and blockages. Check the muffler condition.

- Inspect the exhaust system components for cracks, leaks, and corrosion. Check for tight exhaust system connections.
- Check for corroded or broken metal parts and replace them as needed.
- Check that the exhaust outlet is unobstructed.

Oil Level. Maintain the oil level at or near, not over, the full mark on the dipstick.

Operating Area. Check for obstructions that could block the flow of cooling air. Keep the air intake area clean. Do not leave rags, tools, or debris on or near the generator set.

1.12 Startup Notification

Complete the startup and installation checklists supplied with the startup notification form. Complete and sign the startup notification form and return copies to Kohler Co. and the distributor/dealer as instructed on the form.

Standby systems not registered within 60 days of startup are automatically registered using the manufacturer's ship date as the startup date.

Notes

Section 2 Dimension Drawings and Wiring Diagrams

Refer to the dimension drawings and wiring diagrams for your model during generator set installation. Figure 2-1 lists the drawing numbers and locations.

Dimension Drawing Description	Drawing Number	Page
12RESL/12RESM1	ADV-8024	
Mounting and Dimensions	Sheet 1	26
Clearance	Sheet 2	27
High Wind Mounting	Sheet 3	28
18RESL	ADV-8025	
Mounting and Dimensions	Sheet 1	29
Clearance	Sheet 2	30
Wiring Diagram Description	Drawing Number	Page
12RESL/12RESM1		
Schematic Diagram	ADV-7325	31
Point-to-Point Wiring Diagram	GM51414	32
18RESL		
Schematic Diagram	ADV-7353	33
Point-to-Point Wiring Diagram	GM52541	34

Figure 2-1 Drawing Numbers and Locations




Figure 2-2 Generator Set Mounting Details and Dimensions, 12RESL/12RESM1 ADV-8024 Sheet 1




Figure 2-3 Generator Set Clearances, 12RESL/12RESM1 ADV-8024 Sheet 2




Figure 2-4 High Wind Mounting Detail, 12RESL/12RESM1 ADV-8024 Sheet 3




Figure 2-5 Generator Set Mounting Details and Dimensions, 18RES ADV-8025, Sheet 1





Figure 2-6 Generator Set Clearances, 18RES ADV-8025, Sheet 2



Schematic Diagram, Single Phase, 12RESL/12RESM1, ADV-7325-E Figure 2-7





Figure 2-8 Point-to-Point Wiring Diagram, Single Phase, 12RESL/12RESM1, GM51414-E



Schematic Diagram, Single Phase, 18RESL, ADV-7353-G Figure 2-9




Figure 2-10 Point-to-Point Wiring Diagram, Single Phase, 18RESL, GM52541-G

Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

	owing list contains appreviation				
A, amp	ampere	cfm	cubic feet per minute	est.	estimated
ABDC	after bottom dead center	CG	center of gravity	E-Stop	emergency stop
AC	alternating current	CID	cubic inch displacement	etc.	et cetera (and so forth)
A/D ADC	analog to digital	CL	centerline	exh.	exhaust
ADC	advanced digital control; analog to digital converter	cm CMOS	centimeter complementary metal oxide	ext. F	external Fahrenheit, female
adj.	adjust, adjustment	CIVIOS	substrate (semiconductor)	fglass.	fiberglass
ADV	advertising dimensional	cogen.	cogeneration	rgiass. FHM	flat head machine (screw)
,	drawing	com	communications (port)	fl. oz.	fluid ounce
Ah	amp-hour	coml	commercial	flex.	flexible
AHWT	anticipatory high water		Commercial/Recreational	freq.	frequency
	temperature	conn.	connection	FS	full scale
AISI	American Iron and Steel	cont.	continued	ft.	foot, feet
41.05	Institute	CPVC	chlorinated polyvinyl chloride	ft. lb.	foot pounds (torque)
ALOP	anticipatory low oil pressure	crit.	critical	ft./min.	feet per minute
alt.	alternator	CRT	cathode ray tube	ftp	file transfer protocol
AI ANSI	aluminum American National Standards	CSA	Canadian Standards	g	gram
ANSI	Institute (formerly American		Association	ga.	gauge (meters, wire size)
	Standards Association, ASA)	CT	current transformer	gal.	gallon
AO	anticipatory only	Cu	copper	gen.	generator
APDC	Air Pollution Control District	cUL	Canadian Underwriter's	genset	generator set
API	American Petroleum Institute	OL II	Laboratories	ĞFI	ground fault interrupter
approx.	approximate, approximately	CUL	Canadian Underwriter's Laboratories	GND, 🚇	ground
AQMD	Air Quality Management District	cu. in.	cubic inch	gov.	governor
AR	as required, as requested	CW.	clockwise	gph	gallons per hour
AS	as supplied, as stated, as	CWC	city water-cooled	gpm	gallons per minute
	suggested	cyl.	cylinder	gr.	grade, gross
ASE	American Society of Engineers	D/A	digital to analog	GRD	equipment ground
ASME	American Society of	DAC	digital to analog converter	gr. wt.	gross weight
0001	Mechanical Engineers	dB	decibel	•	height by width by depth
assy. ASTM	American Society for Tooting	dB(A)	decibel (A weighted)	HC	hex cap
ASTIVI	American Society for Testing Materials	DC ´	direct current	HCHT	high cylinder head temperature
ATDC	after top dead center	DCR	direct current resistance	HD	heavy duty
ATS	automatic transfer switch	deg., °	degree	HET	high exhaust temp., high
auto.	automatic	dept.	department		engine temp.
aux.	auxiliary	DFMEA	Design Failure Mode and	hex	hexagon
avg.	average		Effects Analysis	Hg	mercury (element)
AVR	automatic voltage regulator	dia.	diameter	HH	hex head
AWG	American Wire Gauge	DI/EO	dual inlet/end outlet	HHC	hex head cap
AWM	appliance wiring material	DIN	Deutsches Institut fur Normung	HP	horsepower
bat.	battery		e. V. (also Deutsche Industrie	hr.	hour
BBDC	before bottom dead center	DIP	Normenausschuss) dual inline package	HS	heat shrink
BC	battery charger, battery	DPDT	double-pole, double-throw	hsg.	housing
	charging	DPST	double-pole, single-throw	HVAC	heating, ventilation, and air
BCA	battery charging alternator	DIS	disconnect switch	HWT	conditioning
BCI	Battery Council International	DVR	digital voltage regulator		high water temperature
BDC	before dead center	E, emer.	emergency (power source)	Hz IC	hertz (cycles per second) integrated circuit
BHP	brake horsepower	ECM	electronic control module,	ID	inside diameter, identification
blk.	black (paint color), block	LOW	engine control module	IEC	International Electrotechnical
hills haden	(engine)	EDI	electronic data interchange	iLO	Commission
blk. htr.	block heater	EFR	emergency frequency relay	IEEE	Institute of Electrical and
BMEP	brake mean effective pressure	e.g.	for example (exempli gratia)		Electronics Engineers
bps	bits per second	EG	electronic governor	IMS	improved motor starting
br. BTDC	brass before top dead center	EGSA	Electrical Generating Systems	in.	inch
Btu	British thermal unit		Association	in. H ₂ O	inches of water
Btu/min.	British thermal units per minute	EIA	Electronic Industries	in. Hg	inches of mercury
C	Celsius, centigrade	FVFO	Association	in. lb.	inch pounds
cal.	calorie	EI/EO	end inlet/end outlet	Inc.	incorporated
CAN	controller area network	EMI	electromagnetic interference	ind.	industrial
CARB	California Air Resources Board	emiss.	emission	int.	internal
CARD	circuit breaker	eng.	engine	int./ext.	internal/external
CC	cubic centimeter	EPA	Environmental Protection Agency	I/O	input/output
CCA	cold cranking amps	EPS	emergency power system	IP	iron pipe
CCW.	counterclockwise	ER	emergency relay	ISO	International Organization for
CEC	Canadian Electrical Code	ES	engineering special,		Standardization
cert.	certificate, certification, certified		engineered special	J	joule
cfh	cubic feet per hour	ESD	electrostatic discharge	JIS	Japanese Industry Standard
-	1		÷		

TP-6793 10/11 Appendix 35

k	kilo (1000)	MTBO	mean time between overhauls	rms	root mean square
K	kelvin	mtg.	mounting	rnd.	round
kA	kiloampere	MTU	Motoren-und Turbinen-Union	ROM	read only memory
KB	kilobyte (2 ¹⁰ bytes)	MW	megawatt	rot.	rotate, rotating
KBus	Kohler communication protocol	mW	milliwatt	rpm	revolutions per minute
kg	kilogram	μF	microfarad	RS	right side
kg/cm ²	kilograms per square	N, norm.	normal (power source)	RTU	remote terminal unit
kg/ciii	centimeter	NA NA	not available, not applicable	RTV	room temperature vulcanization
kgm	kilogram-meter			RW	read/write
kg/m ³	kilograms per cubic meter	nat. gas	natural gas	SAE	•
kHz	kilohertz	NBS	National Bureau of Standards	SAE	Society of Automotive Engineers
kJ	kilojoule	NC	normally closed	scfm	standard cubic feet per minute
km	kilometer	NEC	National Electrical Code	SCR	silicon controlled rectifier
		NEMA	National Electrical Manufacturers Association		
kOhm, kΩ		NEDA	National Fire Protection	s, sec.	second
kPa	kilopascal	NFPA	Association	SI	Systeme international d'unites, International System of Units
kph	kilometers per hour	Nm	newton meter	SI/EO	side in/end out
kV	kilovolt	NO		sil.	silencer
kVA	kilovolt ampere		normally open	SII. SN	
kVAR	kilovolt ampere reactive	no., nos.	number, numbers		serial number
kW	kilowatt	NPS	National Pipe, Straight	SNMP	simple network management protocol
kWh	kilowatt-hour	NPSC	National Pipe, Straight-coupling	SPDT	single-pole, double-throw
kWm	kilowatt mechanical	NPT	National Standard taper pipe	SPST	single-pole, double-throw
kWth	kilowatt-thermal	NPTF	thread per general use		
L	liter		National Pipe, Taper-Fine	spec	specification
LAN	local area network	NR	not required, normal relay	specs	specification(s)
LxWxH	length by width by height	ns	nanosecond	sq.	square
lb.	pound, pounds	OC	overcrank	sq. cm	square centimeter
lbm/ft ³	pounds mass per cubic feet	OD	outside diameter	sq. in.	square inch
LCB	line circuit breaker	OEM	original equipment	SS	stainless steel
LCD	liquid crystal display	0.5	manufacturer	std.	standard
ld. shd.	load shed	OF	overfrequency	stl.	steel
LED	light emitting diode	opt.	option, optional	tach.	tachometer
Lph	liters per hour	OS	oversize, overspeed	TD	time delay
Lpm	liters per minute	OSHA	Occupational Safety and Health	TDC	top dead center
LOP	low oil pressure		Administration	TDEC	time delay engine cooldown
LP	liquefied petroleum	OV	overvoltage	TDEN	time delay emergency to
LPG	liquefied petroleum gas	OZ.	ounce		normal
LS	left side	p., pp.	page, pages	TDES	time delay engine start
		PC	personal computer	TDNE	time delay normal to
L _{wa} LWL	sound power level, A weighted low water level	PCB	printed circuit board		emergency
		pF	picofarad	TDOE	time delay off to emergency
LWT	low water temperature	PF	power factor	TDON	time delay off to normal
m M	meter, milli (1/1000)	ph., ∅	phase	temp.	temperature
М	mega (10 ⁶ when used with Sl units), male	PHC	Phillips® head Crimptite®	term.	terminal
m ³	cubic meter		(screw)	THD	total harmonic distortion
m ³ /hr.		PHH	Phillips® hex head (screw)	TIF	telephone influence factor
	cubic meters per hour	PHM	pan head machine (screw)	TIR	total indicator reading
m ³ /min.	cubic meters per minute	PLC	programmable logic control	tol.	tolerance
mA	milliampere	PMG	permanent magnet generator	turbo.	turbocharger
man.	manual	pot	potentiometer, potential	typ.	typical (same in multiple
max.	maximum	ppm	parts per million	,,	locations)
MB	megabyte (2 ²⁰ bytes)	PROM	programmable read-only	UF	underfrequency
MCCB	molded-case circuit breaker		memory	UHF	ultrahigh frequency
MCM	one thousand circular mils	psi	pounds per square inch	UL	Underwriter's Laboratories, Inc.
meggar	megohmmeter	psig	pounds per square inch gauge	UNC	unified coarse thread (was NC)
MHz	megahertz	pt.	pint	UNF	unified fine thread (was NF)
mi.	mile	PTC	positive temperature coefficient	univ.	universal
mil	one one-thousandth of an inch	PTO	power takeoff	US	undersize, underspeed
min.	minimum, minute	PVC	polyvinyl chloride	UV	ultraviolet, undervoltage
misc.	miscellaneous	qt.	quart, quarts	V	volt
MJ	megajoule	qty.	quantity	VAC	volts alternating current
mJ	millijoule	Ŕ	replacement (emergency)	VAR	voltampere reactive
mm	millimeter		power source	VDC	volts direct current
		rad.	radiator, radius	VFD	vacuum fluorescent display
mOhm, ms	Ω milliohm				
,	Ωmilliohm Ωmegohm	RAM	random access memory	V/GA	video graphics adapter
,			random access memory relay driver output	VGA VHE	video graphics adapter
MOhm, M	Ωmegohm	RAM	-	VHF	very high frequency
MOhm, M MOV MPa	Ωmegohm metal oxide varistor megapascal	RAM RDO	relay driver output	VHF W	very high frequency watt
MOhm, M MOV MPa mpg	Ωmegohm metal oxide varistor megapascal miles per gallon	RAM RDO ref. rem.	relay driver output reference remote	VHF W WCR	very high frequency watt withstand and closing rating
MOhm, M MOV MPa mpg mph	Ωmegohm metal oxide varistor megapascal miles per gallon miles per hour	RAM RDO ref. rem. Res/Coml	relay driver output reference remote Residential/Commercial	VHF W WCR w/	very high frequency watt withstand and closing rating with
MOhm, M MOV MPa mpg mph MS	Ωmegohm metal oxide varistor megapascal miles per gallon miles per hour military standard	RAM RDO ref. rem. Res/Coml RFI	relay driver output reference remote Residential/Commercial radio frequency interference	VHF W WCR w/ w/o	very high frequency watt withstand and closing rating with without
MOhm, M MOV MPa mpg mph MS ms	Ωmegohm metal oxide varistor megapascal miles per gallon miles per hour military standard millisecond	RAM RDO ref. rem. Res/Coml RFI RH	relay driver output reference remote Residential/Commercial radio frequency interference round head	VHF W WCR w/ w/o wt.	very high frequency watt withstand and closing rating with without weight
MOhm, M MOV MPa mpg mph MS	Ωmegohm metal oxide varistor megapascal miles per gallon miles per hour military standard	RAM RDO ref. rem. Res/Coml RFI	relay driver output reference remote Residential/Commercial radio frequency interference	VHF W WCR w/ w/o	very high frequency watt withstand and closing rating with without

36 Appendix TP-6793 10/11

Notes

TP-6793 10/11 37

Notes

38 TP-6793 10/11

KOHLER POVVER SYSTEMS

KOHLER CO. Kohler, Wisconsin 53044 Phone 920-457-4441, Fax 920-459-1646 For the nearest sales/service outlet in the US and Canada, phone 1-800-544-2444 KohlerPower.com

Kohler Power Systems Asia Pacific Headquarters 7 Jurong Pier Road Singapore 619159 Phone (65) 6264-6422, Fax (65) 6264-6455