
Wiring Diagrams

Service Entrance Rated Automatic Transfer Switches



Models:



Controls: Decision-Maker® MPAC 1500



KOHLERPower Systems _

TP-6919 6/17b

Product Identification Information

Product identification numbers determine service parts. Record the product identification numbers in the spaces below immediately after unpacking the products so that the numbers are readily available for future reference. Record field-installed kit numbers after installing the kits.

Transfer Switch Identification Numbers Record the product identification numbers from the

transfer switch namepla	ate.
Model Designation Serial Number	
Accessory Number	Accessory Description

This manual provides wiring diagrams for the automatic transfer switch models listed on the front cover.

Use the chart on the next page to identify the diagrams for your model. Diagrams are arranged in alphanumerical order.

Information in this publication represents data available at the time of print. The manufacturer of Kohler Co. products reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Service Assistance

For professional advice on generator set power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KOHLERPower.com.
- Look at the labels and decals on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

Headquarters Europe, Middle East, Africa (EMEA)

Kohler Power Systems Netherlands B.V. Kristallaan 1 4761 ZC Zevenbergen The Netherlands

Phone: (31) 168 331630 Fax: (31) 168 331631

Asia Pacific

Power Systems Asia Pacific Regional Office Singapore, Republic of Singapore

Phone: (65) 6264-6422 Fax: (65) 6264-6455

China

North China Regional Office, Beijing

Phone: (86) 10 6518 7950 (86) 10 6518 7951 (86) 10 6518 7952

Fax: (86) 10 6518 7955

East China Regional Office, Shanghai

Phone: (86) 21 6288 0500 Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office Bangalore, India

Phone: (91) 80 3366208

(91) 80 3366231

Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office

Tokyo, Japan

Phone: (813) 3440-4515 Fax: (813) 3440-2727

TP-6919 6/17 Introduction 3

Schematics and Wiring Diagrams

In order to determine which diagrams apply to your unit, follow the instructions below to identify the transfer switch size (amps), the switch type (MCCB or ICCB), and the transformer assembly installed on your unit. Then refer to Figure 3, Wiring Diagram Reference, to find the applicable drawings.

MCCB and ICCB Models

Check the model designation on the ATS nameplate to determine whether the model uses molded case circuit breakers (MCCB) or insulated case circuit breakers (ICCB) on the utility side. The second-to-last digit in the model designation identifies the utility side power switching device. See Figure 1. Also check the size of the transfer switch in amps.

Example:

KEP-DMTA-**0400**S-**N**K has a letter N in the second-to-last place, which indicates MCCB. The transfer switch size is 400 amps.

Code	Power Switching Device Type				
M					
N	MCCB				
Р					
R					
Т	ICCB				

Figure 1 Utility Side Power Switching Device

Transformer Assemblies

Revised transformer assemblies were introduced with the release of service disconnect to OFF units and controller firmware version 1.10.

To identify the transformer assembly, open the enclosure door and compare the transformer assembly to Figure 2 or check the accessories section of the ATS nameplate. The nameplate is located on the controller cover on the inside of the enclosure door. The transformer assembly is typically mounted on the right side of the enclosure; the location varies for different ATS sizes and enclosure types.

If the transfer switch is equipped with the revised transformer assembly, kit number GM94796-AA1 or GM94796-AA2 will appear in the accessories section of the transfer switch nameplate. Transfer switches equipped with an original transformer assembly GM69797-KA1 or GM69797-KA2 do not have the transformer kit number printed on the nameplate.

- Transfer switches equipped with an original transformer assembly GM69797-KA1 or GM69797-KA2 must use the Service Disconnect to Emergency position only.
- Transfer switches using revised transformer assembly number GM94796-AA1 (for MCCB models) or GM94796-AA2 (for ICCB models) are factory-set to use the Service Disconnect to OFF position.

Note: In some applications, an ATS equipped with the revised transformer assembly GM94796-AA1 or GM94796-AA2 may have been converted in the field to use the Service Disconnect to Emergency position. In this case, programmable output 1 on the main logic board will be disconnected and some connections to the transformer assembly terminal block TB will be different than shown on the wiring diagrams in this manual. See the Transfer Switch Operation/Installation Manual, TP-6946 revision 3/16b or later, for details.






Figure 2 Transformer Assemblies


		Schematic	Schematic		Wiring Diagram	
Model	Description	Drawing Number	Page	Drawing Number	Page	
Units with Transformer Assembly GM69797-KA1 or GM69797-KA2 (Service Disconnect to EMERGENCY Models)	100-1200 Amp MCCB	GM89725	7	GM89726 Sheet 1	8	
				Sheet 2 Sheet 3	9 10	
	800-4000 Amp ICCB	GM89727	11	GM89728 Sheet 1 Sheet 2 Sheet 3	12 13 14	
Units with Transformer Assembly GM94796-AA1 or GM94796-AA2 (Service Disconnect to OFF Models)†	100-1200 Amp MCCB	GM95676 Sheet 1 Sheet 2	15 16	GM95677 Sheet 1 Sheet 2 Sheet 3 Sheet 4	17 18 19 20	
	800-4000 Amp ICCB	GM95678	21	GM95679 Sheet 1 Sheet 2 Sheet 3	22 23 24	


[†] Transfer switches equipped with transformer assembly GM94796-AA1 or GM94796-AA2 may be converted to use the Service Disconnect to Emergency position. See TP-6946, Transfer Switch Operation and Installation Manual.


Figure 3 Wiring Diagram Reference


















































KOHLER. Power Systems

KOHLER CO. Kohler, Wisconsin 53044 Phone 920-457-4441, Fax 920-459-1646 For the nearest sales/service outlet in the US and Canada, phone 1-800-544-2444 KOHLERPower.com

Kohler Power Systems Asia Pacific Headquarters 7 Jurong Pier Road Singapore 619159 Phone (65) 6264-6422, Fax (65) 6264-6455