Installation

Residential/Commercial Generator Sets



Model:

20RESB 20RESD

Controller: RDC2



KOHLER.
Power Systems _____

TP-6925 6/15b

California Proposition 65



Engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Product Identification Information

Generator Set Identification Numbers	Engine Identification
Record the product identification numbers from the generator set nameplate(s).	Record the product identification information from the engine nameplate.
Model Designation	Manufacturer
Specification Number	Model Designation
Serial Number	Serial Number
Accessory Number	Controller Identification
	Record the controller description from the generator set operation manual, spec sheet, or sales invoice.
	Controller Description

Table of Contents

Product Identification Information 2					
Safety Precautions and Instructions5					
Introduction			9		
Service Assistance			10		
Section 1 Installati	n		11		
1.	Introductio	n	11		
1.3	Lifting		12		
1.3	Generator	Set Inspection	12		
1.4	Location a	nd Mounting	12		
		lounting Area	12		
		igh Wind Installation	12		
		xhaust Requirements	13		
1.5	Dimension	Drawings	13		
1.0		irements	13		
	•	uel Supply	14		
		uel Pipe Size	14		
		onnecting the Fuel Supply	15		
1.1		ersion	16		
	1.7.1 F	uel Conversion	16		
1.3			17		
1.9	•	Connections	18		
		irounding	19		
		lectrical Lead Entry	19		
		ield-Connection Terminal Block	20		
		C Power Supply	21		
1.			21		
		•	21		
		ommunication Cable Specifications	23		
			24		
1.		stallation Check	27		
		erciser	28		
		et Exercise Procedure	28		
			28		
Section 2 Accesso			29		
2.			29		
2.:					
		Programmable Interface Module (PIM)			
2.:		Load Management 30 2.3.1 Power Relay Module 30			
0		•			
2.		OnCue Plus Generator Management System			
2.5		Carburetor Heater			
2.0	-	Heater	33		
2.	-	, ,	33		
2.5	PowerSyn	c Automatic Paralleling Module (APM)	34		
Section 3 Drawings and Diagrams					
Appendix A Abbre	iations		53		

Notes

4 TP-6925 6/15

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. SAVE THESE INSTRUCTIONS.

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.



DANGER

Danger indicates the presence of a hazard that *will cause severe* personal injury, death, or substantial property damage.



WARNING

Warning indicates the presence of a hazard that *can cause severe personal injury, death,* or *substantial property damage*.



CAUTION

Caution indicates the presence of a hazard that *will* or *can cause minor personal injury* or *property damage*.

NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

A

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Press the generator set off/reset button to shut down the generator set. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

Battery

A

WARNING



Sulfuric acid in batteries.
Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.

▲ WARNING



Explosion.

Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all iewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death.

Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Engine Backfire/Flash Fire



Risk of fire. Can cause severe injury or death.

Do not smoke or permit flames or sparks near fuels or the fuel system.

Servicing the air cleaner. A sudden backfire can cause severe injury or death. Do not operate the generator set with the air cleaner removed.

Servicing the fuel system. A flash fire can cause severe injury or death. Do not smoke or permit flames or sparks near the carburetor, fuel line, fuel filter, fuel pump, or other potential sources of spilled fuels or fuel vapors. Catch fuels in an approved container when removing the fuel line or carburetor.

Combustible materials. A fire can cause severe injury or death. Generator set engine fuels and fuel vapors are flammable and explosive. Handle these materials carefully to minimize the risk of fire or explosion. Equip the compartment or nearby area with a fully charged fire extinguisher. Select a fire extinguisher rated ABC or electrical fires or BC for recommended by the local fire code or an authorized agency. Train all personnel on fire extinguisher operation and fire prevention procedures.

Exhaust System



Carbon monoxide.
Can cause severe nausea, fainting, or death.

The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

Carbon monoxide detectors. Carbon monoxide can cause severe nausea, fainting, or death. Install carbon monoxide detectors on each level of any building adjacent to the generator set. Locate the detectors to adequately warn the building's occupants of the presence of carbon monoxide. Keep the detectors operational at all times. Periodically test and replace the carbon monoxide detectors according to manufacturer's instructions.

Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

Fuel System



Explosive fuel vapors.

Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

The fuel system. Explosive fuel vapors can cause severe injury or death. Vaporized fuels are highly explosive. Use extreme care when handling and storing fuels. Store fuels in a well-ventilated area away from spark-producing equipment and out of the reach of children. Never add fuel to the tank while the engine is running because spilled fuel may ignite on contact with hot parts or from sparks. Do not smoke or permit flames or sparks to occur near sources of spilled fuel or fuel vapors. Keep the fuel lines and connections tight and in good condition. Do not replace flexible fuel lines with rigid lines. Use flexible sections to avoid fuel line breakage caused by vibration. Do not operate the generator set in the presence of fuel leaks, fuel accumulation, or sparks. Repair fuel systems before resuming generator set operation.

Explosive fuel Gas fuel leaks. vapors can cause severe injury or death. Fuel leakage can cause an explosion. Check the LPG vapor or natural gas fuel system for leakage by using a soap and water solution with the fuel system test pressurized to 6-8 ounces square per (10-14 inches water column). Do not use a soap solution containing either ammonia or chlorine because both prevent bubble formation. A successful test depends on the ability of the solution to bubble.

Explosive fuel vapors can cause severe injury or death. Take additional precautions when using the following fuels:

Propane (LPG)—Adequate ventilation is mandatory. Because propane is heavier than air, install propane gas detectors low in a room. Inspect the detectors per the manufacturer's instructions.

Natural Gas—Adequate ventilation is mandatory. Because natural gas rises, install natural gas detectors high in a room. Inspect the detectors per the manufacturer's instructions.

Hazardous Noise

CAUTION



Hazardous noise. Can cause hearing loss.

Never operate the generator set without a muffler or with a faulty exhaust system.

Engine noise. Hazardous noise can cause hearing loss. Generator sets not equipped with sound enclosures can produce noise levels greater than 105 dBA. Prolonged exposure to noise levels greater than 85 dBA can cause permanent hearing loss. Wear hearing protection when near an operating generator set.

Hazardous Voltage/ Moving Parts



Hazardous voltage. Will cause severe injury or death.

This equipment must be installed and serviced by qualified electrical personnel.

▲ WARNING





Hazardous voltage. Moving parts. Can cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.

WARNING



Hazardous voltage. Backfeed to the utility system can cause property damage, severe injury, or death.

If the generator set is used for standby power, install an automatic transfer switch to prevent inadvertent interconnection of standby and normal sources of supply.

CAUTION



Welding the generator set.

Can cause severe electrical equipment damage.

Never weld components of the generator set without first disconnecting the battery, controller wiring harness, and engine electronic control module (ECM).

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Welding on the generator set. Can cause severe electrical equipment Before welding on the damage. generator set perform the following steps: (1) Remove the battery cables, negative (-) lead first. (2) Disconnect all engine electronic control module (ECM) connectors. (3) Disconnect all generator set controller and voltage regulator circuit board connectors. (4) Disconnect the engine batteryalternator connections. (5) Attach the weld ground connection close to the weld location.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death. Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.

Heavy Equipment



Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.

Do not use lifting eyes.

Lift the generator set using lifting bars inserted through the lifting holes on the skid.

Hot Parts



Hot engine and exhaust system. Can cause severe injury or death.

Do not work on the generator set until it cools.

Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Servicing the engine heater. Hot parts can cause minor personal injury or property damage. Install the heater before connecting it to power. Operating the heater before installation can cause burns and component damage. Disconnect power to the heater and allow it to cool before servicing the heater or nearby parts.

Notice

NOTICE

Canadian installations only. For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code, Part 1.

This manual provides installation instructions for Residential/Commercial Model 20RESB and 20RESD generator sets. See Figure 1. Refer to TP-6926, Operation Manual, for generator set operation and maintenance instructions.

The generator set is approved for use in stationary applications in locations served by a reliable utility power source.

Have a Kohler® authorized distributor/dealer install the generator set **outdoors** according to the instructions in this manual. The generator set installation must comply with the National Electrical Code (NEC) and local code requirements. **Do not install this generator set indoors.**

Information in this publication represents data available at the time of print. Kohler Co. reserves the right to change this publication and the products represented without notice and without any obligation or liability whatsoever.

Read this manual and carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety Precautions and Instructions section at the beginning of this manual.




Figure 1 20RESB Generator Set

List of Related Literature

Figure 2 identifies related literature available for the generator sets covered in this manual. Only trained and qualified personnel should install or service the generator set.

Literature Type	Part Number
Specification Sheet, 20RESB	G4-244
Specification Sheet, 20RESD	G4-247
Operation Manual, 20RESB/20RESD Generator Set	TP-6926
Service Manual, 14/20RESA/RESAL/ 20RESB/20RESD Generator Set	TP-6805
Operation Manual, OnCue® Plus Generator Management System	TP-6928
Operation/Installation Manual, Model RDT Transfer Switch	TP-6345
Operation/Installation Manual, Model RXT Automatic Transfer Switch	TP-6807
Installation Instructions, Programmable Interface Module (PIM)	TT-1584
Installation Instructions, PowerSync® Automatic Paralleling Module (APM)	TT-1596
Installation Instructions, Load Shed Kit	TT-1609
Installation Instructions, Power Relay Modules	TT-1646

Figure 2 Related Literature

Startup and Registration

When the generator set is installed, complete the startup and installation checklists supplied with the startup notification form. Complete and sign the startup notification form and register the unit using the Kohler online Warranty Processing System.

TP-6925 6/15 9

For professional advice on generator set power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KOHLERPower.com.
- Look at the labels and decals on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

Headquarters Europe, Middle East, Africa (EMEA)

Kohler Power Systems Netherlands B.V. Kristallaan 1 4761 ZC Zevenbergen The Netherlands

Phone: (31) 168 331630 Fax: (31) 168 331631

Asia Pacific

Power Systems Asia Pacific Regional Office Singapore. Republic of Singapore

Phone: (65) 6264-6422 Fax: (65) 6264-6455

China

North China Regional Office, Beijing

Phone: (86) 10 6518 7950 (86) 10 6518 7951 (86) 10 6518 7952

Fax: (86) 10 6518 7955

East China Regional Office, Shanghai

Phone: (86) 21 6288 0500 Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office Bangalore, India

Phone: (91) 80 3366208

(91) 80 3366231

Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office

Tokyo, Japan

Phone: (813) 3440-4515 Fax: (813) 3440-2727

Latin America

Latin America Regional Office Lakeland, Florida, USA

Phone: (863) 619-7568 Fax: (863) 701-7131


10 TP-6925 6/15

1.1 Introduction



Hazardous voltage. Will cause severe injury or death.

This equipment must be installed and serviced by qualified electrical personnel.



Can cause severe nausea, fainting, or death.

The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

Carbon monoxide detectors. Carbon monoxide can cause severe nausea, fainting, or death. Install carbon monoxide detectors on each level of any building adjacent to the generator set. Locate the detectors to adequately warn the building's occupants of the presence of carbon monoxide. Keep the detectors operational at all times. Periodically test and replace the carbon monoxide detectors according to the manufacturer's instructions.

Have the generator set installed by an authorized Kohler distributor/dealer or authorized representative. For all locations, ensure that the installation complies with applicable national and local codes. Install the equipment in compliance with the National Electrical Code (NEC) and local codes. For Canadian installations, refer to the Canadian Electrical Code (CEC).

The generator set must be installed outdoors. The exhaust systems on enclosed units are designed for outdoor installation only.

Note: DO NOT install these generator sets inside a building.

Note: Install carbon monoxide (CO) detector(s) on each level of any building adjacent to a generator set. Locate the detectors to adequately warn the building's occupants of the presence of carbon monoxide.

Obtain a building permit and contact your local utility companies to mark the locations of underground pipes and cables.

Read and follow the safety precautions in this manual and observe the decals on the equipment. Refer to the diagrams and drawings in this manual for dimensions and electrical connections during the installation procedure. Read the entire installation procedure and obtain the accessories and tools needed before beginning installation. Perform the steps in the order shown.

To install optional accessories, follow the instructions provided with each kit.

1.2 Lifting



Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.

Do not use lifting eyes. Lift the generator set using lifting bars inserted through the lifting holes on the skid.

The approximate weight of the generator set without packaging is shown in Figure 1-1. Use lifting bars inserted through the holes in the skid to lift the unit. See the dimension drawings in Section 3 for lifting hole locations.

Model	Weight, kg (lb.)
20RESB with aluminum enclosure 20RESD with aluminum enclosure	223 (490)

Figure 1-1 Approximate Weight

1.3 Generator Set Inspection

Complete a thorough inspection of the generator set. Check for the following:

- Inspect the generator set for loose or damaged parts or wires. Repair or tighten any loose parts before installation.
- Check the engine oil. Fill, if necessary, with the recommended viscosity and grade of oil. Use synthetic oil, API (American Petroleum Institute) Service Class SG or higher. See the Operation Manual for additional information.

1.4 Location and Mounting

Install the generator set outdoors near the incoming gas service. The required distance from a structure is dependent on state and local codes. See the dimension drawing in Section 3 for the minimum clearance from structures and non-combustible materials.

Locate the generator set so that the hot exhaust does not blow on plants or other combustible materials. No plants, shrubs, or other combustible materials are allowed within 1.2 m (4 ft.) of the exhaust end of the generator set.

Do not install the generator set where exhaust gas could accumulate and seep inside or be drawn into a potentially occupied building. Furnace and other similar intakes must be at least 3 m (10 ft.) from the exhaust end of the generator set.

Notice

DO NOT locate the generator set near patios, decks, play areas, or animal shelters. Keep items such as lawn furniture, toys, sports equipment, and all combustible materials away from the generator set exhaust outlet.

Remind family members, children, and visitors to use caution near the generator set. Generator sets connected to automatic transfer switches start automatically during exercise periods and power outages. Some generator set components become hot when the generator set is running and remain hot for a time after the generator set shuts down.

1.4.1 Mounting Area

The generator set is shipped on an aluminum skid. Prepare a flat, level mounting area covered with a weed barrier and gravel or a concrete mounting pad. Set the skid directly on the gravel or concrete.


Note: For high-wind installations, see Section 1.4.2.

Do not install the generator set directly on grass, wood, or other combustible materials. Clear all combustible materials, including plants and shrubs, building materials, and lawn furniture, from the area beyond the exhaust end of the generator set as shown on the dimension drawing in Section 3.

1.4.2 High Wind Installation

For high-wind installations (up to 181 mph), use a concrete mounting pad and four mounting bolts. See the dimension drawing in Section 3 for mounting hole locations.

1.4.3 Exhaust Requirements



Servicing the exhaust system. Hot parts can cause severe injury or death. Do not touch hot engine parts. The engine and exhaust system components become extremely hot during operation.

Figure 1-2 gives the exhaust temperature at rated load. The engine exhaust mixes with the generator set cooling air at the exhaust end of the enclosure. Mount the generator set so that the hot exhaust does not blow on plants or other combustible materials. Maintain the clearances shown on the dimension drawing in Section 3.

Exhaust	Temperature, °C (°F)
Exhaust gas exiting the enclosure at rated kW, °C (°F)	260 (500)

Figure 1-2 Exhaust Flow and Temperature

The generator set requires correct air flow for cooling and combustion. The inlet and outlet openings in the sound enclosure provide the cooling and combustion air. Figure 1-3 shows the locations of the cooling air intake and exhaust vents. Inspect the air inlet and outlet openings inside and outside the housing to ensure that the air flow is not blocked.




Figure 1-3 Cooling Air Intake and Exhaust

1.5 Dimension Drawings

See the dimension drawings in Section 3 for the generator set dimensions, fuel and electric inlet locations, and recommended clearance.

1.6 Fuel Requirements



Explosive fuel vapors.
Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

Explosive fuel vapors can cause severe injury or death. Take additional precautions when using the following fuels:

Propane (LPG)—Adequate ventilation is mandatory. Because propane is heavier than air, install propane gas detectors low in a room. Inspect the detectors per the manufacturer's instructions.

Natural Gas—Adequate ventilation is mandatory. Because natural gas rises, install natural gas detectors high in a room. Inspect the detectors per the manufacturer's instructions.

The generator set operates using natural gas or LPG fuel. The generator set is EPA-certified for both natural gas and LPG fuels.

The fuel system installation must comply with applicable national, state, and local codes.

1.6.1 Fuel Supply

Because of variable climates and geographical considerations, contact the local fuel supplier for fuel system planning and installation. Figure 1-4 lists the recommended fuel ratings and other fuel supply information for natural gas and LPG fuels.

	T	T
Fuel type	Natural Gas	LPG
Fuel type	Gas	LPG
Fuel supply inlet	1/2 NPT	
Fuel supply pressure, kPa (in. H	₂ O):	
20RESB	1.3-2.7	
	(5-11)	1.7-2.7
20RESD	0.9-2.7	(7-11)
	(3.5-11)	
Fuel flow rate, maximum, Btu/hr.:		
20RESB/20RESD	281,000	340,000
Nominal Fuel Rating, Btu/ft. ³		
Natural gas	1000	
LPG	2500	

Figure 1-4 Fuel Supply Specifications

Verify that the output pressure from the primary gas utility pressure regulator is within the specifications shown in Figure 1-4 and that the utility gas meter flow rate is sufficient to supply the generator set at rated load plus all other gas-consuming appliances. For LPG tanks, verify that the output pressure is within the specifications shown in Figure 1-4. See Figure 1-6 for fuel consumption. Contact the fuel supplier for flow rate information or a gas meter upgrade, if necessary.

1.6.2 Fuel Pipe Size

Ensure that the fuel pipe size and length meet the specifications in Figure 1-5. Measure the pipe length from the primary gas pressure regulator to the pipe connection on the generator set fuel inlet. Add 2.4 m (8 ft.) to the measured length for each 90 degree elbow. Compare the total pipe length with the chart in Figure 1-5 to find the required pipe size.

Contact local LPG provider for LPG installation information.

Mini	Minimum Gas Pipe Size Recommendation, in. NPT			
		20RESB/20RESD		
Pipe Length		Natural Gas	LPG	
m	(ft.)	(281,000 Btu/hr.)	(340,000 Btu/hr.)	
8	(25)	1	3/4	
15	(50)	1	1	
30	(100)	1 1/4	1	
46	(150)	1 1/4	1 1/4	
61	(200)	1 1/4	1 1/4	

Figure 1-5 Fuel Pipe Size Recommendations

Load	60		3/20RESD	
	60	Hz		
100%		114	50	Hz
	8.0	(281)	6.4	(225)
75%	6.9	(243)	5.4	(189)
50%	4.6	(161)	3.9	(139)
25%	3.6	(127)	2.9	(103)
100%	3.9	(136)	2.9	(102)
75%	3.1	(109)	2.4	(85)
50%	2.3	(82)	1.8	(63)
25%	1.7	(59)	1.3	(47)
LPG conversion factors: 8.58 ft. ³ = 1 lb. 0.535 m ³ = 1 kg 36.39 ft. ³ = 1 gal.		ral gas: `u/ft. ³)	g: 37 MJ/m ³ 93 MJ/m ³	
	50% 25% factors: lb. 1 kg	2.3 25% 1.7 factors: Nominal ib. Natur 1 kg (1000 Btu 1 gal. LPG:	2.3 (82) 25% 1.7 (59) factors: Nominal fuel rating lb. Natural gas: (1000 Btu/ft.³) 1 gal. LPG:	50% 2.3 (82) 1.8 25% 1.7 (59) 1.3 factors: Nominal fuel rating: lb. Natural gas: 37 MJ/m ³ 1 kg (1000 Btu/ft. ³)

Figure 1-6 Fuel Consumption

1.6.3 Connecting the Fuel Supply

▲ WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Press the generator set off/reset button to shut down the generator set. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.



Explosive fuel vapors.
Can cause severe injury or death.

Use extreme care when handling, storing, and using fuels.

Explosive fuel vapors can cause severe injury or death. Take additional precautions when using the following fuels:

Propane (LPG)—Adequate ventilation is mandatory. Because propane is heavier than air, install propane gas detectors low in a room. Inspect the detectors per the manufacturer's instructions.

Natural Gas—Adequate ventilation is mandatory. Because natural gas rises, install natural gas detectors high in a room. Inspect the detectors per the manufacturer's instructions.

The dimension drawing in Section 3 shows the location of the fuel inlet connection. Have the fuel supplier install rigid gas piping and a manual fuel shut-off valve. The fuel supply line should line up with the generator set fuel inlet and end about 12 inches away to allow connection with a section of flexible fuel line. Use flexible sections to prevent fuel line breakage caused by vibration.

Note: Do not bend the flexible fuel line to make up for misalignment of the fuel supply line and the generator set fuel inlet.

Apply pipe sealant that is approved for fuel connections. Hold the fuel solenoid valve with a wrench on the flats of the valve when tightening the fuel connections.

Note: Do not hold the fuel solenoid valve coil when tightening the fuel connections. See Figure 1-7 for the recommended wrench locations.




Figure 1-7 Holding Fuel Valve to Tighten Fuel Connections

Open the manual fuel valves and test all fuel connections using soapy water. If a leak is found, close the fuel valves, clean the fittings, and apply fresh sealant. Check for fuel leaks again with the generator set running.

Protect all fuel lines from machinery or equipment contact, adverse weather conditions, and environmental damage.

1.7 Fuel Conversion

The multi-fuel system allows conversion from natural gas to LPG (or vice-versa) in the field while maintaining emissions-standard compliance. A trained technician or an authorized distributor/dealer can convert the fuel system.

See Figure 1-8 for the fuel system components.

Rating Change

Converting the fuel will change the generator set rating. See the generator set specification sheet for ratings with natural gas and LP. Order a new nameplate with the updated rating and fuel information from an authorized distributor/dealer, if necessary. Provide the following information from the original nameplate:

- Model Number
- Spec Number
- Serial Number
- Fuel (original and new)
- kW

- kVA
- Amps
- Volts
- Hz

Attach the new nameplate over the old one. Do NOT cover the UL listing information on the old nameplate.




Figure 1-8 Fuel System

1.7.1 Fuel Conversion

For LPG fuel, an orifice is used in the fuel line. The unit is typically shipped set up for natural gas, with the loose orifice tied near the fuel solenoid valve. To convert to LPG, install the orifice as described below. See Figure 1-8 for the fuel system component locations.

Procedure to Convert from NG to LP

- Press the OFF button on the generator set controller.
- 2. Disconnect the power to the battery charger.
- 3. Disconnect the generator set engine starting battery, negative (-) lead first.
- 4. Turn off the fuel supply.
- Remove the hose clamp and fuel hose from the hose fitting. See Figure 1-8.
- 6. Insert the orifice into the hose fitting. See Figure 1-8.
- 7. Slide the hose onto the hose fitting and secure it with the clamp.
- 8. Connect and turn on the new fuel supply.
- 9. Reconnect the generator set engine starting battery leads, negative (-) lead last.
- 10. Reconnect power to the battery charger.
- 11. Start the generator set by pressing the RUN button on the generator set controller.
- 12. Check for leaks using a gas leak detector.
- 13. Run the generator set and check the operation.
- Press the OFF button to shut down the generator set

Conversion from LPG to Natural Gas

To convert from LPG to natural gas, repeat the steps above to remove the fuel orifice.

1.8 Battery

WARNING



Sulfuric acid in batteries. Can cause severe injury or death.

Wear protective goggles and clothing. Battery acid may cause blindness and burn skin.



Explosion.

Can cause severe injury or death. Relays in the battery charger cause arcs or sparks.

Locate the battery in a well-ventilated area. Isolate the battery charger from explosive fumes.



Hazardous voltage. Will cause severe injury or death.

This equipment must be installed and serviced by qualified electrical personnel.

Battery electrolyte is a diluted sulfuric acid. Battery acid can cause severe injury or death. Battery acid can cause blindness and burn skin. Always wear splashproof safety goggles, rubber gloves, and boots when servicing the battery. Do not open a sealed battery or mutilate the battery case. If battery acid splashes in the eyes or on the skin, immediately flush the affected area for 15 minutes with large quantities of clean water. Seek immediate medical aid in the case of eye contact. Never add acid to a battery after placing the battery in service, as this may result in hazardous spattering of battery acid.

Battery acid cleanup. Battery acid can cause severe injury or death. Battery acid is electrically conductive and corrosive. Add 500 g (1 lb.) of bicarbonate of soda (baking soda) to a container with 4 L (1 gal.) of water and mix the neutralizing solution. Pour the neutralizing solution on the spilled battery acid and continue to add the neutralizing solution to the spilled battery acid until all evidence of a chemical reaction (foaming) has ceased. Flush the resulting liquid with water and dry the area.

Battery gases. Explosion can cause severe injury or death. Battery gases can cause an explosion. Do not smoke or permit flames or sparks to occur near a battery at any time, particularly when it is charging. Do not dispose of a battery in a fire. To prevent burns and sparks that could cause an explosion, avoid touching the battery terminals with tools or other metal objects. Remove all jewelry before servicing the equipment. Discharge static electricity from your body before touching batteries by first touching a grounded metal surface away from the battery. To avoid sparks, do not disturb the battery charger connections while the battery is charging. Always turn the battery charger off before disconnecting the battery connections. Ventilate the compartments containing batteries to prevent accumulation of explosive gases.

Battery short circuits. Explosion can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Disconnect the battery before generator set installation or maintenance. Remove all jewelry before servicing the equipment. Use tools with insulated handles. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery. Never connect the negative (-) battery cable to the positive (+) connection terminal of the starter solenoid. Do not test the battery condition by shorting the terminals together.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Battery Description

Starting batteries are usually the lead-acid type. Use a 12-volt group 26 battery with a minimum rating of 500 cold cranking amps at 0°F. The generator set uses a negative ground with a 12-volt engine electrical system. See Figure 1-9 for battery connections. Make sure that the battery is correctly connected and the terminals are tight.

Note: The generator set will not start and circuit board damage may occur if the battery is connected in reverse.

See the dimension drawing in Section 3 for the engine starting battery location on the air intake side of the generator set. Standard battery cables provide easy connection to the battery.




Figure 1-9 Typical Battery Connection

Use the following procedure to install and connect the battery.

Battery Installation Procedure


- 1. Ensure that the starting battery is fully charged before placing the battery in service.
- 2. Clean the battery posts and/or adapters if necessary.
- 3. Install the battery post adapters, if needed.
- 4. Place the battery in the housing.
- 5. Connect the positive (+) lead to the engine starting battery.
- 6. Connect the negative (-) lead to the engine starting battery.

Refer to the generator set operation manual and the battery manufacturer's instructions for battery maintenance instructions.

When power is applied to the RDC2 controller (that is, when the battery is connected), you will be prompted to set the date and time, and then to set the exerciser. See Section 1.12 and the generator set operation manual for instructions.

If the battery is disconnected for service or replacement, the exercise settings on the RDC2 controller are lost. Set the exerciser after installing and connecting the battery. See Section 1.12, Set Exerciser.

1.9 Electrical Connections



Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocution is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Electrical backfeed to the utility. Hazardous backfeed voltage can cause severe injury or death. Install a transfer switch in standby power installations to prevent the connection of standby and other sources of power. Electrical backfeed into a utility electrical system can cause severe injury or death to utility personnel working on power lines.

NOTICE

Canadian installations only. For standby service connect the output of the generator set to a suitably rated transfer switch in accordance with Canadian Electrical Code, Part 1.

Have an authorized distributor/dealer or a licensed electrician make the following electrical connections. The electrical installation must comply with the National Electrical Code® (NEC) class 1 wire designation and all applicable local codes. Use Class 1 wiring methods for field wiring connections to a Class 2 circuit. Canadian installations must comply with the Canadian Electrical Code (CEC) and applicable local codes.

AC circuit protection. All AC circuits must include circuit breaker or fuse protection. The circuit breaker must be rated for a maximum of 125% of the rated generator set output current. The circuit breaker must open all ungrounded connectors. The generator set is equipped with a factory-installed circuit breaker.

The National Electrical Code® is a registered trademark of the National Fire Protection Association, Inc.

For customer-supplied wiring, select the wire temperature rating in Figure 1-10 based upon the following criteria:

- Select row 1, 2, 3, or 4 if the circuit rating is 110 amperes or less or requires #1 AWG (42.4 mm²) or smaller conductors.
- Select row 3 or 4 if the circuit rating is greater than 110 amperes or requires #1 AWG (42.4 mm²) or larger conductors.

Row	Temp. Rating	Copper (Cu) Only	Cu/Aluminum (Al) Combinations	Al Only
1	60°C (140°F) or 75°C (167°F)	Use No. * AWG, 60°C wire or use No. * AWG, 75°C wire	Use 60°C wire, either No. * AWG Cu, or No. * AWG AI or use 75°C wire, either No. * AWG Cu or No. * AWG AI	Use 60°C wire, No. * AWG or use 75°C wire, No. * AWG
2	60°C (140°F)	Use No. * AWG, 60°C wire	Use 60°C wire, either No. * AWG Cu or No. * AWG AI	Use 60°C wire, No. * AWG
3	75°C (167°F)	Use No. *† AWG, 75°C wire	Use 75°C wire, either No. *† AWG Cu or No. *† AWG AI	Use 75°C wire, No.*† AWG
4	90°C (194°F)	Use No. *† AWG, 90°C wire	Use 90°C wire, either No. *† AWG Cu or No. *† AWG AI	Use 90°C wire, No.*† AWG

^{*} The wire size for 60°C (140°F) wire is not required to be included in the marking. If included, the wire size is based on ampacities for the wire given in Table 310-16 of the National Electrical Code®, in ANSI/NFPA 70, and on 115% of the maximum current that the circuit carries under rated conditions. The National Electrical Code® is a registered trademark of the National Fire Protection Association, Inc.

Figure 1-10 Terminal Markings for Various Temperature Ratings and Conductors

1.9.1 Grounding

Ground the generator set. The grounding method must comply with NEC and local codes. Connect the ground to the generator set ground lug, terminal GND inside the controller compartment.

Generator sets are shipped with the generator neutral bonded (connected) to the generator ground in the junction box. The requirement for having a bonded (grounded) neutral or ungrounded neutral is determined by the type of installation. At installation, the neutral can be grounded at the generator set or lifted from the ground stud and isolated if the installation requires an ungrounded neutral connection at the generator. The generator set will operate properly with the neutral either bonded to ground or isolated from ground at the generator.

Various regulations and site configurations including the National Electrical Code (NEC), local codes, and the type of transfer switch used in the application determine the grounding of the neutral at the generator. NEC Section 250 is one example that has a very good explanation of the neutral grounding requirements for generators.

1.9.2 Electrical Lead Entry

Drill or punch holes in the enclosure for the electrical conduit in the locations shown in Figure 1-11. Pilot holes are provided at the recommended locations. Do not drill or punch holes in any other locations on the back panel.




Figure 1-11 Electrical Lead Entry Locations

[†] Use the larger of the following conductors: the same size conductor as that used for the temperature test or one selected using the guide-lines in the preceding footnote.

1.9.3 Field-Connection Terminal Block

The generator set is equipped with a field-connection terminal block located in the air inlet area near the junction box. Leads have been factory-installed from the junction box to the terminal block for easy field wiring.

See the dimension drawing in Section 3 for the terminal block location. See Figure 1-12 for terminal block details. Refer to the terminal block decal for connections and cable sizes. Also see the wiring diagram in Section 3.

Electrical conduits must include flexible sections to isolate vibration and prevent breakage. Ensure that the leads and conduit do not interfere with the operation of the generator set or obstruct the service areas. Route low-voltage communication leads through separate conduit.




Figure 1-12 Field Connection Terminal Block

Procedure

- 1. Drill holes for the conduit fittings. See Figure 1-11 for the recommended electrical inlet locations. Feed the cables through the openings.
- Connect the leads from the transfer switch emergency source lugs to the L1 and L2 connections on the generator set terminal block.

- Connect the neutral (L0) and ground (GRD) leads from the ATS and the main panel to the corresponding connection points on the terminal block. See Section 1.9.1, Grounding.
- 4. Connect AC power source leads to the terminal block connections labeled BLK, WHT, and GRN. Connect the circuit to the load side of the transfer switch. See Section 1.9.4 for more information about the AC power requirement.

Note: AC power must be connected to maintain the charge on the engine starting battery.

5. For connection of optional transfer switches, the programmable interface module (PIM), and/or a load shed kit, see Section 1.10.

Note: Optional OnCue® Plus and OnCue® Plus Wireless Generator Management System kits are available for remote generator monitoring and control. The OnCue® Plus system requires installation of a network cable from the generator to the owner's computer router. OnCue® Plus Wireless does not require installation of a network cable to the owner's router.

6. If the OnCue® Plus Generator Management System will be used with the generator set, run category 5E network cable from the generator set to the customer's router or modem.

Note: Installation of the network cable at the time of generator set installation is highly recommended (unless installing OnCue® Plus Wireless). Installing the Ethernet cable now will make connection much easier if you choose to add OnCue® Plus later.

- a. Route the network cable with other low-voltage signal wiring (for example, the RBUS communication leads or engine start leads to the transfer switch), in separate conduit from the AC load leads. If a network cable is longer than 100 meters (328 ft.), use a repeater or switch.
- b. Use an RJ45 inline coupler to connect the Ethernet cable to the cable in the customer connection box. The inline coupler is included with the OnCue® Plus kit.

1.9.4 AC Power Supply

The installer must connect AC power for the battery charger (which is integral to the RDC2 controller) and optional accessories shown in Figure 1-13. The power source must comply with state and local codes. The power to the battery charger and accessories must be backed up by the generator so that power is available at all times.

Be sure to disconnect power at the distribution panel before making the connections. Connect power leads to the AC power connection points labeled BLK, WHT, and GRN on the field-connection terminal block. Connect the circuit to the load side of the transfer switch so that it is backed up by the generator. See Figure 1-12 and the wiring diagrams in Section 3 for connection details.

	Power Requirement, Max.	
Equipment	Watts	Volts @ 50/60 Hz
Battery charger (standard)	50	100-250 VAC
Carburetor heater *	37	
Battery heater *	110	120 VAC
Fuel regulator heater *	60	
* Optional accessory		

Figure 1-13 Power Requirements

1.10 ATS and Accessory Communication Connections

The following sections cover communication connections from the generator set to automatic transfer switches and RBUS accessories, including the programmable interface module (PIM) and the load shed kit.

1.10.1 Transfer Switch Connection

Connect the automatic transfer switch (ATS) or remote start/stop switch. Connect the load leads from the generator set to the Emergency source lugs on the ATS. Connect the RBUS or engine start connections as described below. Route low-voltage communication

leads through separate conduit from the AC power and load leads. All connections must comply with applicable state and local codes.

Note: Do not use the Kohler® Model RRT transfer switch with the 20RESB or 20RESD generator set.

RBUS communication connections for a Kohler® Model RXT transfer switch

One Model RXT transfer switch can be connected to the generator set. See Figure 1-14. Use shielded, twisted-pair communication cable to connect P10-1 through P10-4 on the transfer switch interface module to the generator set terminal block TB1 connections A, B, PWR, and COM. See Section 1.10.2 for the communication cable recommendations and maximum cable length.

The Model RXT transfer switch with the combined interface/load management board requires one set of RBUS connections to the generator set. However, the combined board acts as two RBUS modules: one RXT transfer switch and one load management device.


Note: Connections 3 and 4 on the generator set are not used with the Model RXT transfer switch.

Engine start connection for other transfer switches or a remote start/stop switch

These instructions apply to a remote start/stop switch or a transfer switch other than the Kohler Model RXT ATS.

Connect the engine start leads from the transfer switch or remote start switch to terminals 3 and 4 on the terminal block. See Figure 1-15. See the connection decal on the generator set and the transfer switch information for acceptable wire sizes. Route the engine start leads through separate conduit from the AC power and load leads.

Close the remote start contacts to start and run the generator set. Open the contacts to signal the generator set to stop. The generator set controller must be in AUTO mode for remote start/stop.



Note: Connections 3 and 4 are NOT USED with the Model RXT ATS.

- 1. Customer connection terminal block. See the dimension drawing in Section 3 for location. Check the decal on the generator set for terminal block connections.
- 2. Connect one end of each cable shield to GROUND at the generator set.
- 3. Communication cable Belden #9402 or equivalent 20 AWG shielded, twisted-pair cable. See Section 1.10.2, Cable Specifications, and Figure 1-16.
- 4. Leave one end of each cable shield disconnected. If accessory modules are connected, see Section 1.10.3.

Figure 1-14 Model RXT Transfer Switch Communication Connection to Generator Set Terminal Block




Figure 1-15 Engine Start Connections with Transfer Switch Models other than Model RXT

1.10.2 Communication Cable Specifications

RBUS Connections A and B

For the RBUS communication connections A and B to the optional RBUS modules, use 20 AWG shielded, twisted-pair communication cable. Belden #9402 (two-pair) or Belden #8762 (single-pair) or equivalent cable is recommended. Optional RBUS modules can include the Model RXT transfer switch, RXT combined interface/load management board, automatic paralleling module (APM), programmable interface module (PIM), and/or the load shed kit for the RDT or RXT transfer switch.

For outdoor installations, including those with buried cables and/or conduit, use outdoor-rated Belden #1075A or equivalent 20 AWG shielded, twisted-pair communication cable.

PWR and COM Connections

For the PWR and COM connections, the cable size and maximum cable length depends on the number of modules connected. See Figure 1-16.

- For short cable runs shown in the first two rows of Figure 1-16, use one pair in the two-pair communication cable for the A and B connections, and use the second pair for the PWR and COM connections.
- For the longer cable runs shown in the last two rows of Figure 1-16, use 12 or 14 AWG cable for PWR and COM, and use the 20 AWG communication cable specified above for the A and B connections only. In this case, single-pair communication cable such as Belden #8762 can be used for the A and B connections.

The maximum cable length depends on the number of optional modules connected. See Figure 1-16 for the maximum cable lengths with 1 to 4 modules per cable run. Note the shield connections shown in Figure 1-17.

Note: A model RXT transfer switch with combined interface/load management board acts as two RBUS modules: one RXT transfer switch and one load management device.

Power relay modules are not RBUS modules and do not add to the number of modules in Figure 1-16.

	Maximum length per run, meters (ft.)			
	Number of Modules	Number of Modules (RXT, APM, PIM, and/or load management device) per Run		
Cable (TB1-PWR and COM)	1 Module	2 Modules	3 Modules	4 Modules
Belden #9402 or equivalent 20AWG for indoor installations	46 (150)	15 (50)	5 (17)	Do not use 20AWG for PWR and COM
Belden #1075A or equivalent 20AWG for outdoor installations or buried cables	46 (150)	15 (50)	5 (17)	Do not use 20AWG for PWR and COM
14 AWG *	137 (450)	137 (450)	107 (350)	107 (350)
12 AWG *	137 (450)	137 (450)	137 (450)	137 (450)
12 AWG * * Use 12 or 14 AWG cable for PWR and C	,	` '	,	` '

^{*} Use 12 or 14 AWG cable for PWR and COM connections only. For RBUS connections A and B, use shielded, twisted pair communication cable specified above.

Figure 1-16 Total Cable Lengths for PWR and COM Connections

1.10.3 System Connections with Accessory Modules

See Figure 1-17 through Figure 1-20 for connection options with up to three accessory modules. Accessory modules can include one Model RXT transfer switch, one programmable interface module (PIM), and/or one load shed kit.

Note: Refer to the installation instructions provided with the Automatic Paralleling Module (APM) for RBUS connections to the APM.

Connect A to A, B to B, PWR to PWR, and COM to COM. See Figure 1-16 for the maximum total cable length with 1, 2, or 3 accessory modules per cable run.




Figure 1-17 Accessory Module Communication Connections Using Two-Pair Communication Cable




Figure 1-18 Accessory Module Connections Using Single-Pair Communication Cable and 12-14 AWG Power Leads (one cable run with three modules shown)




Figure 1-19 Multiple Connections to the Generator Set




Figure 1-20 Accessory Module Connections with Two Cable Runs

1.11 Prestart Installation Check



Hazardous voltage. Moving parts. Can cause severe injury or death.

Operate the generator set only when all guards and electrical enclosures are in place.



Carbon monoxide.
Can cause severe nausea, fainting, or death.

The exhaust system must be leakproof and routinely inspected.

Generator set operation. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Avoid breathing exhaust fumes when working on or near the generator set. Never operate the generator set inside a building. Never operate the generator set where exhaust gas could seep inside or be drawn into a potentially occupied building through windows, air intake vents, or other openings.

Carbon monoxide symptoms. Carbon monoxide can cause severe nausea, fainting, or death. Carbon monoxide is a poisonous gas present in exhaust gases. Carbon monoxide is an odorless, colorless, tasteless, nonirritating gas that can cause death if inhaled for even a short time. Carbon monoxide poisoning symptoms include but are not limited to the following:

- Light-headedness, dizziness
- Physical fatigue, weakness in joints and muscles
- Sleepiness, mental fatigue, inability to concentrate or speak clearly, blurred vision
- Stomachache, vomiting, nausea

If experiencing any of these symptoms and carbon monoxide poisoning is possible, seek fresh air immediately and remain active. Do not sit, lie down, or fall asleep. Alert others to the possibility of carbon monoxide poisoning. Seek medical attention if the condition of affected persons does not improve within minutes of breathing fresh air.

Review the entire installation section. Inspect all wiring and connections to verify that the generator set is ready for operation. Check all items in the following Prestart Checklist.

Prestart Checklist

Air Cleaner. Check that a clean air cleaner element is installed to prevent unfiltered air from entering the engine. See the generator set operation manual for instructions

Air Inlets. Check for clean and unobstructed air inlets.

Battery. Check for tight battery connections. Consult the battery manufacturer's instructions regarding battery care and maintenance.

Enclosure. Check that all enclosure panels and internal baffling are in place.

Exhaust System. Check for exhaust leaks and blockages. Check the muffler condition.

- Inspect the exhaust system components for cracks, leaks, and corrosion. Check for tight exhaust system connections.
- Check for corroded or broken metal parts and replace them as needed.
- Check that the exhaust outlet is unobstructed.

Oil Level. Maintain the oil level at or near, not over, the full mark on the dipstick.

Operating Area. Check for obstructions that could block the flow of cooling air. Keep the air intake area clean. Do not leave rags, tools, or debris on or near the generator set.

1.12 Set the Exerciser

Set the exerciser to automatically run the generator set on the desired day and time every week or every two weeks. See the generator set Operation Manual for detailed descriptions of the unloaded and loaded exercise operation.

1.12.1 Set Exercise Procedure

When power is applied to the RDC2 controller (when the battery or the utility power for the battery charger is connected), you will be prompted to set the date and time, and then to set the exerciser.

The first setting will flash. Press the Up and Down arrow buttons to change the setting. Press Select to save the setting and move on to the next. Repeat until the date, time, and exercise are set and the controller display shows the main menu. See the generator set Operation Manual for more detailed instructions to set the date and time and set the exerciser.

Press AUTO to place the generator set controller into automatic mode.




Figure 1-21 Set Time, Date, and Exercise (RDC2)

1.12.2 Loaded Exercise

In order to set a loaded exercise using the RDC2 controller, a Kohler® Model RXT transfer switch must be connected. See the generator set operation manual for instructions to set a loaded exercise.

To set a loaded exercise on a generator set connected to a transfer switch other than a Model RXT, use the transfer switch controller to set the exercise. Refer to the transfer switch operation manual for instructions.

2.1 Introduction

Have accessories installed by an authorized distributor/ dealer or a licensed electrician. Follow the installation instructions provided with each kit. Use separate conduit for AC and DC leads to reduce the possibility of electrical interference. Verify that the leads and conduit do not interfere with the operation of the generator set or obstruct the service areas. Verify that the electrical installation complies with the National Electrical Code (NEC) and all applicable local codes. See the wiring diagrams in Section 3 for more information regarding generator set electrical connections.

2.2 Programmable Interface Module (PIM)

The optional programmable interface module (PIM) provides two programmable inputs and six dry contact outputs, four of which are programmable. See TT-1584 for PIM installation and connection instructions. Also see Section 1.10 of this manual for connection to the generator set.

The default settings for the inputs and outputs are shown in Figure 2-2. To change the input and output settings, use a personal computer running Kohler® SiteTech™ software. See TP-6701, SiteTech Software Operation Manual, for instructions.

Kohler® OnCue® Plus can be used to actively control PIM outputs. See the OnCue® Plus Operation Manual for instructions.




Figure 2-1 Optional PIM

PIM Connection	Factory Default Setting
Input 1	None
Input 2	None
Output 1 (Relay 1)	Run
Output 2 (Relay 2)	Common Fault
Output 3 (Relay 3)	Low Battery Voltage (Program-mable)
Output 4 (Relay 4)	Not in Auto (Programmable)
Output 5 (Relay 5)	Cooldown (Programmable)
Output 6 (Relay 6)	Normal Source Failure (Programmable)

Figure 2-2 PIM Inputs and Outputs

TP-6925 6/15 Section 2 Accessories 29

2.3 Load Management

Two optional load management devices are available for use with single-phase generator sets and a model RXT or RDT transfer switch:

- The optional Load Shed Kit mounts inside a model RDT or RXT transfer switch. Figure 2-3 shows the load shed assembly.
- The combined interface/load management board is available for the Model RXT transfer switch.

The devices provide an automatic load management system to comply with Section 702.5 of NEC 2008. The installer is responsible for ensuring that the power system installation complies with all applicable state and local codes.

Note: The load management devices are only compatible with single-phase generator sets.

With a load management system, less critical appliances can be powered by the generator set when the more important appliances are not running, allowing the use of a smaller generator set than would be needed to run all of the building's electrical equipment at the same time.

The load management device automatically manages up to six residential loads.

- Up to four normally closed power relays can be connected through normally open relay contacts on the circuit board. See the load shed kit installation instructions for relay specifications. Kohler[®] Power Relay Modules are recomended.
- Two relays are included to control two independent heating, ventilation, and air conditioning (HVAC) loads.

Note: Connect only non-essential loads to the load shed kit.

The load management device receives commands from the RDC2 or DC2 generator controller and energizes or de-energizes the appropriate load relays to add or shed non-critical loads according to their priority.

An adequate electrical supply is required for operation of the customer-supplied power relays connected to the load shed kit. Check the electrical requirements of the customer-provided equipment prior to installation to determine the wire size and circuit protection required.

For detailed installation and connection instructions, see the installation instructions provided with the load shed kit or the Operation/Installation Manual for the Model RXT transfer switch.




Figure 2-3 Load Shed Assembly GM88281-1 (mounts inside the transfer switch enclosure)

2.3.1 Power Relay Module

The power relay module kit contains one 50 amp normally closed relay with connecting lugs in a NEMA type 3R enclosure. Connect up to four (4) power relay modules to the load management devices listed above.

The power relay modules can be mounted indoors or outdoors. Two (2) 120 VAC loads (shed simultaneously) or a single 240 VAC load can be wired to each relay.

For detailed installation and connection instructions, see the installation instructions provided with the power relay module kit.



Figure 2-4 Power Relay Module

30 Section 2 Accessories TP-6925 6/15

2.4 OnCue Plus Generator Management System

The OnCue® Plus Generator Management System allows monitoring and control of your generator set from a personal computer, smart phone, or tablet. OnCue Plus can also be configured to send email or text message notifications in the event of a generator set fault. Both a network cable connection version (OnCue Plus) and a wireless version (OnCue Plus Wireless) are available. See TP-6928, OnCue Plus Operation Manual, for instructions.

OnCue Plus

OnCue Plus is available separately as a loose kit. Use category 5E network cable to connect the RDC2 controller to the customer-supplied Ethernet router or modem. Route the cable with other low-voltage signal wiring (for example, the RBUS communication leads or engine start leads to the transfer switch), in separate conduit from the AC load leads. If a network cable is longer than 100 meters (328 ft.), use a repeater or switch.

Recommended: Use a laptop computer to verify the network connection before connecting to the generator set.

Checking the network connection

- 1. Check for and turn OFF any wireless connections to the laptop.
- 2. Connect the network cable to the laptop. Connect the other end of the network cable to the customer's router or modem.
- 3. Verify the Internet connection by opening your web browser and going to www.kohlerpower.com or any known website.
- 4. After verifying the connection through the network cable, disconnect the network cable from the laptop and turn the laptop wireless connections back on.

Connect to the Ethernet cable in the customer connection area of the generator set. See Figure 2-5. Use an RJ45 inline coupler, provided with the OnCue Plus kit, to connect the customer's Ethernet cable to the cable in the customer connection box.




Figure 2-5 Network Connection for OnCue® Plus

OnCue Plus Wireless

The OnCue Plus Wireless kit allows connection of the generator set to the Internet through the customer's wireless router without running a network cable from the generator to the customer's Ethernet router. Follow the instructions provided with the kit to install and set up the wireless kit.

TP-6925 6/15 Section 2 Accessories 31

2.5 Carburetor Heater

An optional carburetor heater is recommended for improved cold starting in locations where the ambient temperature drops below 0°C (32°F). The carburetor heater prevents condensation and carburetor icing. The heater turns on when the temperature at the thermostat falls below approximately 4°C (40°F) and turns off when the temperature rises above approximately 16°C (60°F). The carburetor heater is shown in Figure 2-6.

To install the carburetor heater, follow the instructions provided with the kit. Figure 2-7 shows the carburetor heater kit location.

The heater thermostat is installed in the cord. Figure 2-6 shows the location of the thermostat on the power cord. The heater power cord and thermostat are located in the generator set housing air intake area/ battery compartment.

The heater requires a continuous source of power. Plug the carburetor heater into the AC receptacle provided.





Figure 2-6 Carburetor Heater



 Carburetor heater location under air cleaner. Insert from the back of the generator set.

Figure 2-7 Carburetor Heater Location



Figure 2-8 Carburetor Heater Location

32 Section 2 Accessories TP-6925 6/15

2.6 Regulator Heater

The regulator heater kit is recommended in addition to the carburetor heater for reliable engine starting in temperatures below -18° C (0°F). See Figure 2-9 for heater specifications.

Regulator Heater		
Heater rating	120 VAC, 60 W	
Thermostat	4°C/13°C (40°F/55°F) Snap action	
Pad diameter	127 mm (5 in.)	
Cord length	610 mm (24 in.)	

Figure 2-9 Regulator Heater Specifications

The regulator heater requires a source of AC power. The generator set is equipped with one 120 VAC receptacle. The kit includes an outlet splitter for powering the regulator heater and an optional carburetor heater.

To install the regulator heater kit, follow the instructions in TT-1569, provided with the kit. Figure 2-10 shows the installed regulator heater kit.




Figure 2-10 Installed Fuel Regulator Heater Kit

2.7 Emergency Stop Button

An emergency stop button is available as a loose kit. See the instructions provided with the kit for installation and connection procedures.



Figure 2-11 Optional Emergency Stop Pushbutton

TP-6925 6/15 Section 2 Accessories 33

2.8 PowerSync Automatic Paralleling Module (APM)

The PowerSync® Automatic Paralleling Module (APM) allows the use of two Model 20RESA/B/C/D generator sets in a single-phase paralleling system to supply power to one building or site. See Figure 2-12.

The APM provides a common connection point for paralleling generators and permits individual control of the generator connections, allowing for synchronization, redundancy, and generator management.

Generator management provides these features and benefits:

- Generator management runs one generator set when power requirements are low, and automatically starts, synchronizes, and connects the second generator set when the load increases.
- Longer generator life: Smart generator management automatically operates the generator with the lowest operating hours first, splitting the run time evenly between the two generator sets and extending the life of both units.
- Redundancy: If one generator set requires service or even fails, the other generator set is still available to provide power to your critical electronics.
- Dual fuels: Allows operation of one generator set on natural gas and the other on LPG, if desired.
- Simultaneous exercise: Setting the exercise time and date on one generator set schedules both generator sets to exercise at the same time.
- Power during generator service: Customer override allows maintenance or service to one generator set while the other continues to run.

The following combinations of single-phase generator sets can be paralleled:

• Two single-phase model 20RESA/B/C/D generator sets with the same 110/220, 115/230, 120/240, 220, 230 or 240 volt configuration can be paralleled.

Automatic paralleling requires:

- Two single-phase generator sets as shown above
- RDC2 paralleling firmware version 105.4 or higher on each generator set. Download the paralleling firmware from TechTools.
- One Model RXT automatic transfer switch (ATS)
- One Automatic Paralleling Module (APM) kit
- A personal computer (laptop) with Kohler® SiteTech™ software version 3.5 or higher is required for system setup.
- A load management device is **required** if one generator set cannot support the maximum total load.

The load management device (load shed kit or RXT combined interface/load management board) is necessary in order to shed non-critical loads in the event that one generator set shuts down and the other generator set cannot support all of the loads.

See TT-1596, provided with the APM, for complete installation instructions. The APM and associated equipment must be installed by a Kohler® trained and authorized distributor or dealer.

If the APM is not installed within sight of the generator sets, local codes may require the installation of circuit breakers near the APM. Circuit breaker kits are available for installation inside the APM enclosure. See TT-1596 for the circuit breaker kit numbers.



Figure 2-12 PowerSync® Automatic Paralleling Module

34 Section 2 Accessories TP-6925 6/15

Section 3 Drawings and Diagrams

Figure 3-1 lists the wiring diagram numbers and page numbers.

Dimension Drawings	Drawing Number	Page
20RESB Dimension Drawing	ADV-8564-C	
Dimensions	Sheet 1	36
Location and clearance requirements	Sheet 2	37
20RESD Dimension Drawing	ADV-8758-A	
Dimensions	Sheet 1	38
Location and clearance requirements	Sheet 2	39
Wiring Diagrams		
20RESB Schematic Diagram	ADV-8706-C	
2-pole circuit breaker	Sheet 1	40
1-pole circuit breaker	Sheet 2	41
3-pole circuit breaker	Sheet 3	42
20RESB Wiring Diagram	GM93298-C	
2-pole circuit breaker	Sheet 1	43
1-pole circuit breaker	Sheet 2	44
3-pole circuit breaker	Sheet 3	45
20RESD Schematic Diagram	ADV-8771	
2-pole circuit breaker	Sheet 1	46
1-pole circuit breaker	Sheet 2	47
3-pole circuit breaker	Sheet 3	48
20RESD Wiring Diagram	GM96293	
2-pole circuit breaker	Sheet 1	49
1-pole circuit breaker	Sheet 2	50
3-pole circuit breaker	Sheet 3	51

Figure 3-1 Diagrams and Drawings




Figure 3-2 Dimension Drawing, 20RESB, ADV-8564 Sheet 1




Figure 3-3 Dimension Drawing, 20RESB, ADV-8564, Sheet 2 of 2




Figure 3-4 Dimension Drawing, Model 20RESD, ADV-8758, Sheet 1 of 2




Figure 3-5 Dimension Drawing, Model 20RESD, ADV-8758, Sheet 2 of 2




Figure 3-6 Schematic Diagram, 20RESB, ADV-8706, Sheet 1 of 3




Figure 3-7 Schematic Diagram, 20RESB, ADV-8706, Sheet 2 of 3




Figure 3-8 Schematic Diagram, 20RESB, ADV-8706, Sheet 3 of 3




Figure 3-9 Point-to-Point Wiring Diagram, 20RESB, GM93298, Sheet 1 of 3




Figure 3-10 Point-to-Point Wiring Diagram, 20RESB, GM93298, Sheet 2 of 3




Figure 3-11 Point-to-Point Wiring Diagram, 20RESB, GM93298, Sheet 3 of 3




Figure 3-12 Schematic Diagram, Model 20RESD, ADV-8771, Sheet 1 of 3




Figure 3-13 Schematic Diagram, Model 20RESD, ADV-8771, sheet 2 of 3




Figure 3-14 Schematic Diagram, Model 20RESD, ADV-8771, Sheet 3 of 3




Figure 3-15 Wiring Diagram, Model 20RESD, GM96293, Sheet 1 of 3




Figure 3-16 Wiring Diagram, Model 20RESD, GM96293, Sheet 2 of 3




Figure 3-17 Wiring Diagram, Model 20RESD, GM96293, Sheet 3 of 3

Notes

Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

	9				
A, amp	ampere	cfm	cubic feet per minute	exh.	exhaust
ABDC	after bottom dead center	CG	center of gravity	ext.	external
AC	alternating current	CID	cubic inch displacement	F	Fahrenheit, female
			•	-	
A/D	analog to digital	CL	centerline	FHM	flat head machine (screw)
ADC	advanced digital control;	cm	centimeter	fl. oz.	fluid ounce
	analog to digital converter	CMOS	complementary metal oxide	flex.	flexible
adi	adjust, adjustment	OWIGG	substrate (semiconductor)	_	
adj.				freq.	frequency
ADV	advertising dimensional	com	communications (port)	FS	full scale
	drawing	coml	commercial	ft.	foot, feet
Ah	amp-hour	Coml/Rec	Commercial/Recreational	ft. lb.	foot pounds (torque)
AHWT	anticipatory high water		•		,
		conn.	connection	ft./min.	feet per minute
	temperature	cont.	continued	ftp	file transfer protocol
AISI	American Iron and Steel	CPVC	chlorinated polyvinyl chloride	g	gram
	Institute	crit.	critical		
ALOP	anticipatory low oil pressure			ga.	gauge (meters, wire size)
alt.	alternator	CSA	Canadian Standards	gal.	gallon
			Association	gen.	generator
Al	aluminum	CT	current transformer	genset	generator set
ANSI	American National Standards	Cu	copper		•
	Institute (formerly American		• •	GFI	ground fault interrupter
	Standards Association, ASA)	cUL	Canadian Underwriter's	GND, ⊕	ground
40			Laboratories		•
AO	anticipatory only	CUL	Canadian Underwriter's	gov.	governor
APDC	Air Pollution Control District		Laboratories	gph	gallons per hour
API	American Petroleum Institute	cu. in.	cubic inch	gpm	gallons per minute
approx.	approximate, approximately			gr.	grade, gross
		CW.	clockwise		-
APU	Auxiliary Power Unit	CWC	city water-cooled	GRD	equipment ground
AQMD	Air Quality Management District	cyl.	cylinder	gr. wt.	gross weight
AR	as required, as requested			ΗχWχD	height by width by depth
	•	D/A	digital to analog		
AS	as supplied, as stated, as	DAC	digital to analog converter	HC	hex cap
	suggested	dB	decibel	HCHT	high cylinder head temperature
ASE	American Society of Engineers	dB(A)	decibel (A weighted)	HD	heavy duty
ASME	American Society of	` '		HET	high exhaust temp., high
/ (OIVIL	Mechanical Engineers	DC	direct current	1111	
	-	DCR	direct current resistance		engine temp.
assy.	assembly	deg., °	degree	hex	hexagon
ASTM	American Society for Testing		. •	Hg	mercury (element)
	Materials	dept.	department	нň	hex head
ATDC	after top dead center	dia.	diameter		
	•	DI/EO	dual inlet/end outlet	HHC	hex head cap
ATS	automatic transfer switch	DÍN	Deutsches Institut fur Normung	HP	horsepower
auto.	automatic	DIIN		hr.	hour
aux.	auxiliary		e. V. (also Deutsche Industrie	HS	heat shrink
avg.	average		Normenausschuss)		
		DIP	dual inline package	hsg.	housing
AVR	automatic voltage regulator	DPDT	double-pole, double-throw	HVAC	heating, ventilation, and air
AWG	American Wire Gauge	DPST	double-pole, single-throw		conditioning
AWM	appliance wiring material		, ,	HWT	high water temperature
bat.	battery	DS	disconnect switch		
	,	DVR	digital voltage regulator	Hz	hertz (cycles per second)
BBDC	before bottom dead center	E ² PROM,	FFPROM	IBC	International Building Code
BC	battery charger, battery	,	electrically-erasable	IC	integrated circuit
	charging		programmable read-only	ID	inside diameter, identification
BCA	battery charging alternator				
	, , ,	_	memory	IEC	International Electrotechnical
BCI	Battery Council International	E, emer.	emergency (power source)		Commission
BDC	before dead center	ECM	electronic control module,	IEEE	Institute of Electrical and
BHP	brake horsepower		engine control module		Electronics Engineers
blk.	black (paint color), block	EDI	electronic data interchange	IMS	improved motor starting
DIK.					
	(engine)	EFR	emergency frequency relay	in.	inch
blk. htr.	block heater	e.g.	for example (exempli gratia)	in. H₂O	inches of water
BMEP	brake mean effective pressure	EĞ	electronic governor	in. Hg	inches of mercury
bps	bits per second				
•	•	EGSA	Electrical Generating Systems	in. lb.	inch pounds
br.	brass		Association	Inc.	incorporated
BTDC	before top dead center	EIA	Electronic Industries	ind.	industrial
Btu	British thermal unit		Association	int.	internal
		EI/EO	end inlet/end outlet		
Btu/min.	British thermal units per minute		•	int./ext.	internal/external
С	Celsius, centigrade	EMI	electromagnetic interference	I/O	input/output
cal.	calorie	emiss.	emission	IP	internet protocol
CAN	controller area network	eng.	engine		•
		EPA	Environmental Protection	ISO	International Organization for
CARB	California Air Resources Board	EFA			Standardization
CAT5	Category 5 (network cable)		Agency	J	joule
CB	circuit breaker	EPS	emergency power system	JIS	Japanese Industry Standard
CC	crank cycle	ER	emergency relay	k	kilo (1000)
	,	ES	engineering special,		
CC	cubic centimeter	LO		K	kelvin
CCA	cold cranking amps		engineered special	kA	kiloampere
ccw.	counterclockwise	ESD	electrostatic discharge	KB	kilobyte (2 ¹⁰ bytes)
		est.	estimated		
CEC	Canadian Electrical Code	E-Stop	emergency stop	KBus	Kohler communication protocol
cert.	certificate, certification, certified			kg	kilogram
cfh	cubic feet per hour	etc.	et cetera (and so forth)		
	-				

TP-6925 6/15 Appendix 53

kg/cm ²	kilograms per square centimeter	NC NEC	normally closed National Electrical Code	RTU RTV	remote terminal unit
kgm	kilogram-meter	NEMA	National Electrical	RW	read/write
kg/m ³	kilograms per cubic meter	INCIVIA	Manufacturers Association		•
	• .	NEDA		SAE	Society of Automotive
kHz	kilohertz	NFPA	National Fire Protection		Engineers
kJ	kilojoule	Niss	Association	scfm	standard cubic feet per minute
km	kilometer	Nm	newton meter	SCR	silicon controlled rectifier
$cOhm, k\Omega$	kilo-ohm	NO	normally open	s, sec.	second
rΡα	kilopascal	no., nos.	number, numbers	SI	Systeme international d'unites,
κph	kilometers per hour	NPS	National Pipe, Straight		International System of Units
άV	kilovolt	NPSC	National Pipe, Straight-coupling	SI/EO	side in/end out
ίVΑ	kilovolt ampere	NPT	National Standard taper pipe	sil.	silencer
(VAR	•		thread per general use	SMTP	simple mail transfer protocol
	kilovolt ampere reactive	NPTF	National Pipe, Taper-Fine	SN	•
:W	kilowatt	NR NR			serial number
(Wh	kilowatt-hour		not required, normal relay	SNMP	simple network management
Wm	kilowatt mechanical	ns	nanosecond		protocol
Wth	kilowatt-thermal	OC	overcrank	SPDT	single-pole, double-throw
_	liter	OD	outside diameter	SPST	single-pole, single-throw
AN	local area network	OEM	original equipment	spec	specification
	length by width by height		manufacturer	specs	specification(s)
	0 , , ,	OF	overfrequency	sq.	square
). (1)3	pound, pounds	opt.	option, optional	•	square centimeter
om/ft ³	pounds mass per cubic feet	OS	oversize, overspeed	sq. cm	•
.CB	line circuit breaker			sq. in.	square inch
.CD	liquid crystal display	OSHA	Occupational Safety and Health	SMS	short message service
.ED	light emitting diode	0)/	Administration	SS	stainless steel
.ph	liters per hour	OV	overvoltage	std.	standard
.pm	liters per minute	OZ.	ounce	stl.	steel
	•	p., pp.	page, pages	tach.	tachometer
.OP	low oil pressure	PC	personal computer	TB	terminal block
.Р	liquefied petroleum	PCB	printed circuit board	TCP	transmission control protocol
.PG	liquefied petroleum gas	pF	picofarad		•
.S	left side	PF	power factor	TD	time delay
-wa	sound power level, A weighted		• .	TDC	top dead center
ŴĹ	low water level	ph., ∅	phase	TDEC	time delay engine cooldown
WT	low water temperature	PHC	Phillips® head Crimptite®	TDEN	time delay emergency to
n	meter, milli (1/1000)		(screw)		normal
		PHH	Phillips® hex head (screw)	TDES	time delay engine start
Л	mega (10 ⁶ when used with SI	PHM	pan head machine (screw)	TDNE	time delay normal to
0	units), male	PLC	programmable logic control	IDIAL	emergency
n ³	cubic meter	PMG	permanent magnet generator	TDOE	time delay off to emergency
n ³ /hr.	cubic meters per hour	pot	potentiometer, potential		
n ³ /min.	cubic meters per minute	•	•	TDON	time delay off to normal
nA	milliampere	ppm	parts per million	temp.	temperature
nan.	manual	PROM	programmable read-only	term.	terminal
nax.	maximum		memory	THD	total harmonic distortion
	megabyte (2 ²⁰ bytes)	psi	pounds per square inch	TIF	telephone influence factor
		psig	pounds per square inch gauge	tol.	tolerance
ACCB	molded-case circuit breaker	pt.	pint	turbo.	turbocharger
/ICM	one thousand circular mils	PTC	positive temperature coefficient		•
neggar	megohmmeter	PTO	power takeoff	typ.	typical (same in multiple
ИHz	megahertz	PVC			locations)
ni.	mile		polyvinyl chloride	UF	underfrequency
nil	one one-thousandth of an inch	qt.	quart, quarts	UHF	ultrahigh frequency
nin.	minimum, minute	qty.	quantity	UIF	user interface
	miscellaneous	R	replacement (emergency)	UL	Underwriter's Laboratories, Inc
nisc.			power source	UNC	unified coarse thread (was NC)
/J	megajoule	rad.	radiator, radius	UNF	unified fine thread (was NF)
nJ	millijoule	RAM	random access memory	univ.	universal
nm	millimeter	RBUS	RS-485 proprietary		
nOhm. mΩ	2 milliohm	TIDOO	communications	URL	uniform resource locator
,	Ω megohm	RDO			(web address)
лонн, м <u>.</u> ЛОV	metal oxide varistor		relay driver output	US	undersize, underspeed
10 v 1Pa		ref.	reference	UV	ultraviolet, undervoltage
	megapascal	rem.	remote	V	volt
	miles per gallon	,	Residential/Commercial	VAC	volts alternating current
	miles per hour	RFI	radio frequency interference	VAR	voltampere reactive
1S	military standard	RH	round head	VDC	voltampere reactive
าร	millisecond	RHM	round head machine (screw)		
n/sec.	meters per second	rly.	relay	VFD	vacuum fluorescent display
	mounting	•	•	VGA	video graphics adapter
ntg.		rms	root mean square	VHF	very high frequency
/ITU	Motoren-und Turbinen-Union	rnd.	round	W	watt
ΛW	megawatt	RO	read only	WCR	withstand and closing rating
nW	milliwatt	ROM	read only memory	w/	with
ιF	microfarad	rot.	rotate, rotating	W/ WO	
	normal (power source)	rpm	revolutions per minute		write only
I, norm.		ipili	iorolations bet illiliate	w/o	without
			right eide		. 2 . 1. 1
NΑ	not available, not applicable	ŔS	right side	wt.	weight
NA			right side Resistance Temperature Detectors	wt. xfmr	weight transformer

54 Appendix TP-6925 6/15

KOHLER. Power Systems

KOHLER CO. Kohler, Wisconsin 53044 Phone 920-457-4441, Fax 920-459-1646

Kohler Power Systems Asia Pacific Headquarters 7 Jurong Pier Road Singapore 619159 Phone (65) 6264-6422, Fax (65) 6264-6455

For the nearest KOHLER authorized installation, service, and sales dealer in the US and Canada:
Call 1-800-544-2444 or visit
KOHLERPower.com

TP-6925 6/15b