


Operation and Installation

Automatic Transfer Switches



Models:

ZCM/ZCB

Bypass/Isolation Switch

Contactors:

150 to 3000 Amperes

Controls:

Decision-Maker® MPAC 1500 (Conversion Kit)

KOHLER[®]
Power Systems

9001
KOHLER
POWER SYSTEMS
NATIONALLY REGISTERED

TP-7038 3/16

Table of Contents

Product Identification Information	2
Safety Precautions and Instructions	5
Introduction	7
List of Related Materials	7
Service Assistance	8
Section 1 Specifications	9
1.1 Transfer Switch Description	9
1.1.1 Purpose of Automatic Transfer Switch	9
1.1.2 Purpose of Bypass/Isolation Switch	9
1.1.3 Components of Switch	9
1.2 Specifications	10
1.3 Ratings	10
1.4 Nameplate	11
1.5 Transfer Switch Part Number Interpretation	12
Section 2 Installation	13
2.1 Receipt of Unit	13
2.1.1 Inspection	13
2.1.2 Storage	13
2.1.3 Unpacking	13
2.1.4 Lifting	13
2.2 Mechanical Installation	13
2.2.1 Preparation	13
2.2.2 Mounting	14
2.3 Electrical Wiring	15
2.3.1 Power Connections	15
2.3.2 Start Generator Connection	16
2.3.3 Other Accessory Connections	16
Section 3 Operation	17
3.1 Introduction	17
3.2 Bypass/Isolation Switch Description	17
3.2.1 Switches and Indicators	17
3.2.2 Bypass/Isolation Cabinet Lamps	17
3.2.3 Bypass/Isolation Switch Components	18
3.3 ATS Sequence of Operation	18
3.3.1 Failure of Normal Power	18
3.3.2 Restoration of Normal Power	19
3.4 Automatic Operation	19
3.4.1 Initial Settings	19
3.4.2 Automatic Operation Procedures	19
3.5 Manual Operation of Automatic Transfer Switch	19
3.6 Operation of Bypass/Isolation Switch	20
3.6.1 Bypass/Isolation Switch Operation Notes	21
3.7 Operation, 150- to 400-Amp Switches	21
3.7.1 Placing ATS in Automatic Mode	22
3.7.2 Bypassing ATS	22
3.7.3 Testing ATS	22
3.7.4 Isolating ATS	22
3.7.5 Removing ATS	22
3.7.6 Reconnecting ATS	22

Table of Contents, continued

3.8	Operation, 600- to 1200-Amp Switches	23
3.8.1	Placing ATS in Automatic Mode	23
3.8.2	Bypassing ATS	23
3.8.3	Testing ATS	23
3.8.4	Isolating ATS	23
3.8.5	Removing ATS	23
3.8.6	Reconnecting ATS	24
3.9	Operation, 1600- to 3000-Amp Switches	24
3.9.1	Placing ATS in Automatic Mode	24
3.9.2	Bypassing ATS	24
3.9.3	Testing ATS	25
3.9.4	Isolating ATS	25
3.9.5	Removing ATS	25
3.9.6	Reconnecting ATS	26
Section 4 Scheduled Maintenance		27
4.1	Inspection and Service	28
4.1.1	General Inspection	28
4.1.2	Other Inspections and Service	29
4.2	Testing	29
4.2.1	Weekly Generator Set Exercise	29
4.2.2	Monthly Automatic Control System Test	29
4.3	Service Schedule	30
Section 5 Diagrams and Drawings		31
Appendix A Abbreviations		55

Safety Precautions and Instructions

IMPORTANT SAFETY INSTRUCTIONS. Electromechanical equipment, including generator sets, transfer switches, switchgear, and accessories, can cause bodily harm and pose life-threatening danger when improperly installed, operated, or maintained. To prevent accidents be aware of potential dangers and act safely. Read and follow all safety precautions and instructions. **SAVE THESE INSTRUCTIONS.**

This manual has several types of safety precautions and instructions: Danger, Warning, Caution, and Notice.

DANGER

Danger indicates the presence of a hazard that **will cause severe personal injury, death, or substantial property damage.**

WARNING

Warning indicates the presence of a hazard that **can cause severe personal injury, death, or substantial property damage.**

CAUTION

Caution indicates the presence of a hazard that **will or can cause minor personal injury or property damage.**


NOTICE

Notice communicates installation, operation, or maintenance information that is safety related but not hazard related.

Safety decals affixed to the equipment in prominent places alert the operator or service technician to potential hazards and explain how to act safely. The decals are shown throughout this publication to improve operator recognition. Replace missing or damaged decals.

Accidental Starting

WARNING



Accidental starting.
Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

(Decision-Maker® 3+ and 550 Controllers)

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Press the generator set off/reset button to shut down the generator set. (2) Disconnect the power to the battery charger, if equipped. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent the starting of the generator set by the remote start/stop switch.

(Decision-Maker® 3000, 3500, and 6000 Controllers)

Hazardous Voltage/ Moving Parts

DANGER



Hazardous voltage.
Will cause severe injury or death.

Disconnect all power sources before opening the enclosure.

DANGER



Hazardous voltage.
Will cause severe injury or death.

Disconnect all power sources before servicing. Install the barrier after adjustments, maintenance, or servicing.

DANGER



Hazardous voltage.
Will cause severe injury or death.

Only authorized personnel should open the enclosure.

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocutation is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Installing the battery charger. Hazardous voltage can cause severe injury or death. An ungrounded battery charger may cause electrical shock. Connect the battery charger enclosure to the ground of a permanent wiring system. As an alternative, install an equipment grounding conductor with circuit conductors and connect it to the equipment grounding terminal or the lead on the battery charger. Install the battery charger as prescribed in the equipment manual. Install the battery charger in compliance with local codes and ordinances.

Connecting the battery and the battery charger. Hazardous voltage can cause severe injury or death. Reconnect the battery correctly, positive to positive and negative to negative, to avoid electrical shock and damage to the battery charger and battery(ies). Have a qualified electrician install the battery(ies).

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Servicing the transfer switch. Hazardous voltage can cause severe injury or death. Deenergize all power sources before servicing. Turn off the main circuit breakers of all transfer switch power sources and disable all generator sets as follows: (1) Move all generator set master controller switches to the OFF position. (2) Disconnect power to all battery chargers. (3) Disconnect all battery cables, negative (-) leads first. Reconnect negative (-) leads last when reconnecting the battery cables after servicing. Follow these precautions to prevent the starting of generator sets by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer. Before servicing any components inside the enclosure: (1) Remove all jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Test circuits with a voltmeter to verify that they are deenergized.

(Decision-Maker® 3+ and 550 Controllers)

Servicing the transfer switch. Hazardous voltage can cause severe injury or death. Deenergize all power sources before servicing. Turn off the main circuit breakers of all transfer switch power sources and disable all generator sets as follows: (1) Press the generator set off/reset button to shut down the generator set. (2) Disconnect power to all battery chargers. (3) Disconnect all battery cables, negative (-) leads first. Reconnect negative (-) leads last when reconnecting the battery cables after servicing. Follow these precautions to prevent the starting of generator sets by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer. Before servicing any components inside the enclosure: (1) Remove all jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Test circuits with a voltmeter to verify that they are deenergized.

(Decision-Maker® 3000, 3500 and 6000 Controllers)

Installing accessories to the transfer switch transformer assembly. Hazardous voltage can cause severe injury or death. To prevent electrical shock, deenergize all power sources and then disconnect the harness plug before installing accessories that will be connected to the transformer assembly primary terminals on microprocessor logic models. Terminals are at line voltage.

Making line or auxiliary connections. Hazardous voltage can cause severe injury or death. To prevent electrical shock deenergize the normal power source before making any line or auxiliary connections.

▲ WARNING



Airborne particles. Can cause severe injury or blindness.

Wear protective goggles and clothing when using power tools, hand tools, or compressed air.

Heavy Equipment

▲ WARNING



Unbalanced weight. Improper lifting can cause severe injury or death and equipment damage.

Use adequate lifting capacity. Never leave the transfer switch standing upright unless it is securely bolted in place or stabilized.

Notice

NOTICE

Improper operator handle usage. Use the manual operator handle on the transfer switch for maintenance purposes only. Return the transfer switch to the normal position. Remove the manual operator handle, if used, and store it in the place provided on the transfer switch when service is completed.

NOTICE

Foreign material contamination. Cover the transfer switch during installation to keep dirt, grit, metal drill chips, and other debris out of the components. Cover the solenoid mechanism during installation. After installation, use the manual operating handle to cycle the contactor to verify that it operates freely. Do not use a screwdriver to force the contactor mechanism.

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), *not a direct short*, to ground.

This manual provides operation and initial installation instructions for Kohler® Model ZCB and ZCM automatic transfer and bypass/isolation switches that use a 150- to 4000-ampere contactor as the power switching device. This manual applies to units that have had the Decision-Maker® MPAC 1500 Controller Conversion Kit installed.

Read through this manual and carefully follow all procedures and safety precautions to ensure safe, reliable operation of your automatic transfer switch. Keep a copy of this manual with the automatic transfer switch for future reference.

All information found in this publication is based on data available at time of printing. The manufacturer reserves the right to make changes to this literature and the products represented at any time without notice and without incurring obligation.

The equipment service requirements are very important to safe and efficient operation. Inspect parts often and perform required service at the prescribed intervals. Obtain service from an authorized service distributor/dealer to keep equipment in top condition.

List of Related Materials

This manual covers operation and installation information for the transfer switch's power switching device. Verify that the transfer switch's power switching device matches the model shown on the front cover of this manual before proceeding with operation or installation.

The transfer switch controller is covered in a separate operation and installation manual. To be complete, the power switching device operation and installation manual must be accompanied by a copy of the operation and installation manual for the controller used in that transfer switch.

Document	Part Number
Operation Manual, Decision-Maker® MPAC 1500 Controls	TP-6883
Installation Instructions, Decision-Maker® MPAC 1500 Controller Conversion Kit	TT-1681

Service Assistance

For professional advice on generator power requirements and conscientious service, please contact your nearest Kohler distributor or dealer.

- Consult the Yellow Pages under the heading Generators—Electric.
- Visit the Kohler Power Systems website at KOHLERPower.com.
- Look at the labels and decals on your Kohler product or review the appropriate literature or documents included with the product.
- Call toll free in the US and Canada 1-800-544-2444.
- Outside the US and Canada, call the nearest regional office.

Headquarters Europe, Middle East, Africa (EMEA)

Kohler Power Systems Netherlands B.V.
Kristallaan 1
4761 ZC Zevenbergen
The Netherlands
Phone: (31) 168 331630
Fax: (31) 168 331631

Asia Pacific

Power Systems Asia Pacific Regional Office
Singapore, Republic of Singapore
Phone: (65) 6264-6422
Fax: (65) 6264-6455

China

North China Regional Office, Beijing
Phone: (86) 10 6518 7950
(86) 10 6518 7951
(86) 10 6518 7952
Fax: (86) 10 6518 7955

East China Regional Office, Shanghai
Phone: (86) 21 6288 0500
Fax: (86) 21 6288 0550

India, Bangladesh, Sri Lanka

India Regional Office
Bangalore, India
Phone: (91) 80 3366208
(91) 80 3366231
Fax: (91) 80 3315972

Japan, Korea

North Asia Regional Office
Tokyo, Japan
Phone: (813) 3440-4515
Fax: (813) 3440-2727

Latin America

Latin America Regional Office
Lakeland, Florida, USA
Phone: (863) 619-7568
Fax: (863) 701-7131

1.1 Transfer Switch Description

1.1.1 Purpose of Automatic Transfer Switch

An Automatic Transfer Switch (ATS) is a device used for transferring critical electrical loads from a normal (preferred) source of electrical power to an emergency (standby) source. This transfer occurs automatically when the normal source voltage fails, or is substantially reduced, and the emergency source's voltage has reached an acceptable level.

Upon normal source failure, the automatic transfer switch controller signals the generator set(s) to start and transfer to the emergency source. The automatic transfer switch controller continuously senses for an acceptable normal source and will retransfer the load to the normal source after it has been restored to an acceptable level. After retransfer of the load, the generator set start signal is removed and the generator set(s) is allowed to shut down.

1.1.2 Purpose of Bypass/Isolation Switch

A bypass/isolation switch is a manually operated device used in conjunction with an ATS to provide a means of directly connecting load conductors to either a normal (preferred) power source or to an emergency (standby) power source. It is also used to disconnect the automatic transfer switch from the power sources and the load for inspection and maintenance.

The bypass switch also functions as a manual transfer switch, allowing transfer of the load from one source to the other, if required, with the automatic transfer switch removed from the system.

1.1.3 Components of Switch

A typical bypass/isolation transfer switch includes the actual power switching device, the bypass/isolation switching device, and the logic controller to perform power monitoring and transfer sequencing tasks. See Figure 1-1.

The basic switching device used in these models is a true power transfer switch. The switch is electrically actuated and then mechanically latched in the selected

position. However, the switch also includes provisions for manual mechanical operation in emergency conditions. Within the switch, there are two sets of multipole contactors. One set is used to select power from the normal source while the other set is used to select power from the emergency source. The two sets of contacts are mechanically interlocked within the switch so that only one set of contactors can be closed at a time. With this feature, it is possible to select one power source to feed the load without crosscoupling that power source to the other power source.

The functional units that make up the automatic transfer switch are mounted in an enclosure with a hinged front door. The controller mounts on the back of the door so its controls and indicators are available to an operator. A signal cable with inline connectors to facilitate component replacement and door removal connects the controller to the switching devices.




Figure 1-1 Transfer Switch Components




Figure 1-2 Basic Bypass/Isolation Transfer Switch Block Diagram

1.2 Specifications

Specifications for automatic transfer switches covered by this manual are listed below:

- The transfer switch is provided as a complete automatic transfer switch with microprocessor logic

controls in a NEMA type 1 enclosure. Other enclosures are available; contact the factory.

- The transfer switch meets UL and CSA standards.
- The transfer switch is voltage rated up to 600 VAC.
- The transfer switch is rated from 150 to 3000 amps.
- The transfer switch is available with standard or programmed transition automatic transfer switches.
- The switching device is electrically and mechanically interlocked.
- The switch is available in 2-pole, 3-pole, and 4-pole configurations.
- The 4-pole switch is fully rated.
- The load is not interrupted during bypass operation.

1.3 Ratings

Withstand and closing current ratings are shown in Figure 1-3. Refer to the transfer switch specification sheet, G11-57, for specific manufacturer's circuit breakers.

Note: The automatic transfer switch and bypass/isolation switch have identical current ratings.

Switch Rating (amps)	Withstand and Closing Current Ratings, Maximum Current in RMS Symmetrical Amperes When Coordinated With								
	Current-Limiting Fuses				Molded-Case Circuit Breakers				
	Max. Size (amps)	@ 480 VAC Max.	@ 600 VAC Max.	Class	Any Manufacturer's (3 cycles)			Specific Manufacturer's (See G11-57)	
					@ 480 VAC Max.	@ 600 VAC Max.	Max. Size (amps)	@ 480 VAC Max.	@ 600 VAC Max.
150 225 260 400	600	200,000	150,000	J	35,000	30,000	800	50,000	42,000
		100,000	—	RK5, RK1					
600	750	200,000	150,000	J, L, RK5, RK1	50,000	42,000	800	65,000	50,000
800	1000	200,000	150,000	L			1600	85,000	65,000
1000	1200								
1200	1500								
1600	2000	200,000	150,000	L	100,000	85,000	2500	100,000	85,000
2000	2500								
2500	4000								
3000									
4000	6000				4000				

* UL 1008 listed at 480 VAC and CSA listed at 600 VAC.

Figure 1-3 Withstand and Closing Current Ratings

1.4 Nameplate

A nameplate is attached to the automatic transfer switch enclosure. See Figure 1-5. The nameplate label includes a factory part number coded to provide characteristic and rating information that affects installation and operation. Copy the part number into the blank spaces provided in the introduction and then use the key in Figure 1-6 to interpret the part number.

Also copy the part number and serial number from the nameplate into the spaces provided on the inside front cover of this manual for use when requesting service or parts.

On transfer switches equipped with the Decision-Maker® MPAC 1500 controller conversion kit, refer to the information recorded on decal GM70205 located on the door near the controller assembly. See Figure 1-4.




Figure 1-4 Controller Conversion Kit Decal





Figure 1-5 Transfer Switch Nameplate

1.5 Transfer Switch Part Number Interpretation

Record the transfer switch model number in the boxes below. The transfer switch model number defines characteristics and ratings as explained in the accompanying chart.



Kohler® Part Number Key

This chart explains the Kohler® transfer switch model numbering system. The sample model number shown is for a Model ZCB automatic transfer switch that uses a standard contactor power switching device with M340+ microprocessor electrical controls rated at 600 volts, 60 hertz, 3 phase, 3 poles, and 4 wires in a NEMA type 1 enclosure with a current rating of 1000 amperes. Not all possible combinations are available.

SAMPLE MODEL NUMBER

ZCB-560341-1000

Switch Classification or Family

ZCM: 150-400 amp automatic transfer and bypass isolation switch
 ZCB: 600-4000 amp automatic transfer and bypass isolation switch

Electrical Controls †

5: M340+ microprocessor

Voltage and Frequency (other codes possible)

53: 220 Volts, 60 Hz	60: 600 Volts, 60 Hz	62: 120 Volts, 60 Hz
63: 220 Volts, 50 Hz	64: 240 Volts, 60 Hz	66: 480 Volts, 60 Hz
68: 208 Volts, 60 Hz	71: 380 Volts, 50 Hz	72: 380 Volt, 60 Hz
73: 416 Volts, 50 Hz		

Number of Poles and Phase

2: 2 pole, 1 phase 3: 3 pole, 3 phase 4: 3 pole, 1 phase
 6: 4 pole, 3 phase

Number of Wires

3: 3 wire 4: 4 wire

Enclosure

0: Open unit* 1: NEMA type 1 2: NEMA type 12*
 3: NEMA type 3R*
 * Contact the factory.

Current Rating

Numbers indicate the current rating of the switch in amperes

† For switches equipped with the Decision-Maker® MPAC 1500 controller conversion kit, refer to the information recorded on decal GM70205 near the controller assembly.

Figure 1-6 Transfer Switch Model Designations Key

Kohler® automatic transfer switches are shipped factory-wired and tested, ready for installation. The actual installation process consists of mechanically mounting and electrically wiring the unit to the normal and emergency power sources, to the load circuits, and to the generator set.

Have the equipment installed only by trained and qualified personnel. The installation must comply with applicable codes and standards.

2.1 Receipt of Unit

2.1.1 Inspection

At the time of delivery, inspect the packaging and the transfer switch for signs of shipping damage. If damage is discovered, immediately file damage claims with the shipping company and notify the distributor/dealer.

2.1.2 Storage

Protect the automatic transfer switch at all times from excessive moisture, construction grit, and metal chips. Avoid storage in low temperature, high humidity areas where moisture could condense on the unit.

2.1.3 Unpacking


Allow the equipment to warm up to room temperature for 24 hours (minimum) prior to unpacking to prevent condensation on the electrical apparatus from surrounding moist air if it is uncrated after cold weather storage.

Unpack the transfer switch as soon as possible after receipt since failure to do so may cause difficulty in making claims for damage not evident upon receipt. Carefully unpack to avoid damaging any of the transfer switch components. Remove all packing material and dirt that may have accumulated in the transfer switch or any of its components.

Note: Do not use compressed air to clean the transfer switch. Cleaning with compressed air can cause debris to lodge in the components and damage the switch.

2.1.4 Lifting

The approximate weight of each automatic transfer switch covered by this manual is given in Figure 2-1. For lifting, use a spreader bar. Attach the bar only to the enclosure's mounting holes or lifting brackets; do not lift the unit at any other points. Ensure the front door is in place and latched closed when moving or mounting the unit.



2.2 Mechanical Installation

NOTICE

Foreign material contamination. Cover the transfer switch during installation to keep dirt, grit, metal drill chips, and other debris out of the components. Cover the solenoid mechanism during installation. After installation, use the manual operating handle to cycle the contactor to verify that it operates freely. Do not use a screwdriver to force the contactor mechanism.

NOTICE

The transfer switch may use both American Standard and metric hardware. Use the correct size tools to prevent rounding of the bolt heads and nuts.

2.2.1 Preparation

Check the system voltage and frequency. Compare the voltage and frequency shown on the transfer switch nameplate to the source voltage and frequency. Do not install the transfer switch if the system voltage and frequency are different from the nominal normal (utility) source voltage and frequency or the nominal emergency source voltage and frequency shown on the generator set nameplate.

Plan the installation. Use the dimensions given on the enclosure dimension (ADV) drawings provided with the switch. Select a mounting site that complies with local electrical code restrictions for the enclosure type. Mount the transfer switch as close to the load and power sources as possible. Allow adequate space to fully open the enclosure and to service the switch. Provide cable bending space and clearance to live metal parts.

Prepare the foundation. Ensure that the supporting foundation for the enclosure is level and straight. For bottom cable entry, if used, install conduit stubs in the foundation. Refer to the enclosure dimension drawing for the conduit stub locations. When pouring a concrete floor, use interlocking conduit spacer caps or a wood or metal template to maintain proper conduit alignment.

2.2.2 Mounting

The 150- and 225-amp transfer switches covered by this manual must be mounted vertically to a wall or other rigid supporting structure. Keyhole slots for mounting purposes are provided in the mounting brackets on the top and bottom of each unit. When mounting these units, plumb the enclosure to ensure that the door hinges are vertical to avoid any distortion of the enclosure or door. Place washers behind the mounting bracket keyholes to shim the enclosure to a plumb condition.

The 260–1200 amp transfer switches covered by this manual can be floor-mounted or attached to a rigid supporting structure such as a wall. For floor mounting, bolt the mounting feet to the floor, shimming the mounting feet as needed to plumb the enclosure so that the door hinges are vertical to avoid any distortion of the enclosure or door. Keyhole slots for wall mounting are provided in the rear panel of the enclosure. When mounting these units, plumb the enclosure to ensure that that the door hinges are vertical to avoid any distortion of the enclosure or door. Place washers behind the mounting bracket keyholes to shim the enclosure to a plumb condition.


The 1600–3000 amp transfer switches covered by this manual are intended to be bolted directly to floor mounting pads. When mounting one of these units, it is important to accurately level the mounting pads so that the door hinges are plumb when the unit is installed in order to avoid any distortion of the enclosure or door.

Number of Poles	Amperes	Complete NEMA Type 1 Unit			
		Weight, kg (lb.)	Dimensions, mm (in.)		
			Height	Width	Depth
2	150, 225, 260, 400	340 (755)	2108 (83.00)	762 (30.00)	787 (31.00)
	600	549 (1220)	2286 (90.00)	914 (36.00)	718 (28.25)
	800	610 (1355)	2286 (90.00)	1016 (40.00)	718 (28.25)
3	150, 225, 260, 400	340 (755)	2108 (83.00)	762 (30.00)	787 (31.00)
	600	549 (1220)	2286 (90.00)	914 (36.00)	718 (28.25)
	800, 1000, 1200	610 (1355)	2286 (90.00)	1016 (40.00)	718 (28.25)
	1600, 2000	1406 (3100)	2286 (90.00)	1016 (40.00)	1552 (61.10)
	2500, 3000	1769 (3900)	2286 (90.00)	1016 (40.00)	1857 (73.10)
4	150, 225, 260, 400	388 (855)	2108 (83.00)	762 (30.00)	787 (31.00)
	600	614 (1365)	2286 (90.00)	1016 (40.00)	718 (28.25)
	800, 1000, 1200	707 (1570)	2286 (90.00)	1168 (46.00)	718 (28.25)
	1600, 2000	1815 (4000)	2286 (90.00)	1270 (50.00)	1552 (61.10)
	2500, 3000	2268 (5000)	2286 (90.00)	1270 (50.00)	1857 (73.10)
	4000	3311 (7300)	2286 (90.00)	1372 (54.00)	2032 (73.00)

* Height does not include lifting eyes on 150–1200 amp models.

Figure 2-1 Transfer Switch Weights and Dimensions, NEMA Type 1 Enclosures (See the dimension drawings in Section 5 for other enclosure dimensions.)

2.3 Electrical Wiring



All internal electrical connections are prewired. The only wiring necessary when installing the transfer switch is the connections from the transfer switch to the external devices. Cable sizes are shown in Figure 2-2.

Note: For easy access during installation wiring, the front door of the enclosure can be removed. Simply disconnect the cable plug that connects the front door components to the internal components and then lift the door off its hinge pins.

Al/Cu UL-Listed Solderless Screw-Type Terminals for External Power Connections		
Switch Rating (amps)	Normal, Emergency, and Load Terminals	
	Cables/Pole	Range of Wire Sizes
150-400	2	1/0 to 250 MCM
	1	#4 AWG to 600 MCM
600	2	#2 AWG to 600 MCM
800-1200	4	#2 AWG to 600 MCM
1600-4000	Bus Bar Connection	

Figure 2-2 Cable Sizes

2.3.1 Power Connections


⚠ WARNING



Accidental starting.
Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.



Making line or auxiliary connections. Hazardous voltage can cause severe injury or death. To prevent electrical shock deenergize the normal power source before making any line or auxiliary connections.

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocutation is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocutation.

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), *not a direct short*, to ground.

Schematic diagrams are furnished in Section 5 of this manual.

Some models allow top cable entry only. Refer to the enclosure drawings in Section 5 for cable entry requirements. When drilling entry holes for any conductors, cover the transfer switch components for protection from metal chips and construction grit. Remove any debris from the enclosure with a vacuum cleaner—*using compressed air for this purpose can lodge contaminants in components and cause damage.*

Connection points for the normal power, emergency power, and load are clearly marked on contactor assembly and are also shown on the drawings in Section 5. Be sure to follow the phase markings (A, B, C, and N).

Note: Connect source and load phases as indicated by the markings and drawings. Improper connections may cause short circuits. Improper connections can also cause phase-sensitive load devices to run backwards or prevent load devices from starting.

Connect the Normal, Emergency, and Load conductors to the clearly marked terminals on the transfer switch. Remove surface oxides from cables by cleaning with a wire brush. Verify that all connections are correct before tightening the lugs. Tighten all cable lug connections to the torque values shown in Figure 2-3.

In cases where the Normal, Emergency, and Load connections are made to a rear connected bus bar, a compression washer, flat washer, and a grade 5 bolt (minimum) must be used and torqued to the values in Figure 2-4.

Socket Size Across Flat	Torque		
	lb.-in.	lb.-ft.	Nm
1/8	45	4	5.1
5/32	100	8	11.3
3/16	120	10	13.6
7/32	150	12	17.0
1/4	200	17	22.6
5/16	275	23	31.1
3/8	375	31	42.3
1/2	500	42	56.5
9/16	600	50	67.8

Figure 2-3 Tightening Torque for Lugs

Bolt Size	Torque Bolt (Grade 5)		
	in. lb.	ft. lb.	Nm
1/4-20	72	6	8.1
5/16-18	132	11	14.9
3/8-16	300	25	33.9
1/2-13	720	60	81.4

Figure 2-4 Tightening Torque for Bus Bars

2.3.2 Start Generator Connection

The generator start signal connections are located on a terminal block on the transfer switch contactor. The terminal block location is marked by a red decal inside the enclosure. Connect the generator conductors for the start signal to terminals 3 and 4 and tighten the connections to 19 in. lb.

2.3.3 Other Accessory Connections

Any external connections necessary for accessories are described in the applicable Logic Controller Operation and Installation Manual. See List of Related Manuals in the Introduction.

3.1 Introduction

This manual describes the operation of the power switching device. Refer to the Controller Operation Manual for transfer switch operation instructions. See List of Related Materials for manual part numbers.

3.2 Bypass/Isolation Switch Description

See Figure 3-1 for the locations of the transfer switch components described in the following sections.




Figure 3-1 Bypass/Isolation Switch

3.2.1 Switches and Indicators

Disconnect Switch. The disconnect switch controls the ATS coil operation. In the auto position, the ATS operation is controlled by the logic controller. In the inhibit position, the logic controller cannot energize the ATS coils. See Figure 3-1.

ATS Location Pointer. The ATS location pointer indicates the three positions of the ATS switch:

Auto: The ATS is connected to all of the buses.

Test: The ATS is disconnected from the load bus but connected to the normal and emergency buses.

Isolate: The ATS is disconnected from all buses.

3.2.2 Bypass/Isolation Cabinet Lamps

See Figure 3-1 for the locations of the cabinet lamps.

Bottom Door

The switches and indicators for the automatic transfer switch are determined by the controller used in that switch. For details on this subject, refer to the Logic Controller Operation and Installation Manual. See List of Related Materials in the Introduction.

Top Door

Lamps marked with an asterisk (*) will illuminate when any of the following are true.

- The disconnect switch is in the inhibit position.
- The bypass selector switch is in the normal or emergency position.
- The ATS is not in the auto location.

LNA Lamp. Lamp illuminates when the normal power source is available.

LEA Lamp. Lamp illuminates when the emergency power source is available.

LBN Lamp.* Lamp illuminates when the normal bypass contacts are closed.

LBE Lamp.* Lamp illuminates when the emergency bypass contacts are closed.

LAT Lamp.* Lamp illuminates when the ATS is in the test location.

LAI Lamp.* Lamp illuminates when the ATS is isolated from the switch.

LAH Lamp.* Lamp illuminates when the ATS is not in the automatic mode (600–1200 amp switches only).

LIT Lamp.* Lamp illuminates when the ATS is not in the automatic mode (all except 600–1200 amp switches).

LDS Lamp.* Lamp flashes when the ATS coils are prevented from operating by the disconnect switch.

3.2.3 Bypass/Isolation Switch Components

Bypass Normal Contacts. The bypass normal contacts connect the load directly to the normal source, bypassing the ATS.

Bypass Emergency Contacts. The bypass emergency contacts connect the load directly to the emergency source, bypassing the ATS.

Bypass Operator. The bypass operator opens and closes the bypass normal or emergency contacts.

Manual Bypass Handle. The manual bypass handle actuates the bypass operator. In the lower (open) position, the bypass normal and emergency contacts are open. In the upper (bypass) position, the bypass normal or emergency contacts are closed.

Bypass Selector Switch. The bypass selector switch determines which contacts the manual bypass handle actuates. Turn the bypass selector switch to the right to close the bypass normal contacts, center to open the bypass normal and emergency contacts, and left to close the bypass emergency contacts.

ATS Location Handle (150- to 400-amp switches only). The position of the ATS location handle determines the ATS mode of operation: auto, test, or isolate. The ATS location handle can be moved only when the manual bypass handle is in the bypass position.

Crank Mechanism (600- to 3000-amp switches only). The crank mechanism determines the ATS mode of operation: auto, test, or isolate. Turn the crank mechanism clockwise to raise the ATS and counterclockwise to lower the ATS through the three positions. The crank mechanism can be rotated only when the manual bypass handle is in the bypass position.

3.3 ATS Sequence of Operation

Operation of the typical automatic transfer switch is divided into two separate sequences: (1) failure of normal power and the resulting transfer to emergency power and (2) restoration of normal power and the resulting transfer back to normal power. A brief description of both sequences is provided below and illustrated in Figure 3-2.




Figure 3-2 Logic Board Operation

Note that these sequences may be affected by accessories described in the applicable controller operation and installation manual. In addition, for more specific details on circuit operation including time delays, refer to the applicable Logic Controller Operation and Installation Manual. See List of Related Materials in the Introduction.

3.3.1 Failure of Normal Power

Failure of normal power, either loss or deterioration of one or more phases (logic depending), is detected by monitors within the controller. The monitor that detects the failure starts the Time Delay Engine Start (TDES). If power is restored before the time delay expires, the timer is reset. But, if the failure persists and the time delay expires, the controller issues a signal to start the standby (emergency) generator set. This time delay scheme is used to prevent starting of the generator set during short power interruptions.

A second set of monitors within the controller checks the status of the emergency power. When the voltage and frequency of the emergency (generator) power are acceptable, these monitors start a timing cycle called Time Delay Normal to Emergency (TDNE), which allows the generator outputs to stabilize. At the end of this timing cycle, the controller issues a signal to the transfer switch operators to remove normal power and then connect emergency power to the load.

Once the power is switched, the transfer switch is mechanically latched in the emergency position, supplying emergency source power to the load until normal power is restored.

3.3.2 Restoration of Normal Power

Restoration of normal power automatically begins a sequence that transfers the load back to the normal power source. The monitors within the controller continue to check the status of the normal power, even when the load is operating on emergency power. When these monitors detect stable normal power, the Time Delay Emergency to Normal (TDEN) is started. If the normal power fails again before the time delay expires, the time delay is reset. This timing period is included to ensure that the normal power is stabilized before it is reconnected to the load.

If the normal power remains acceptable and the time delay expires, the controller will issue a signal to the transfer switch to remove emergency power and reconnect normal power to the load. After switching, the transfer switch is mechanically latched in the normal position. The controller starts the Time Delay Engine Cooldown (TDEC) simultaneously with the power transfer. After this time delay expires, the engine start signal is removed.

3.4 Automatic Operation


3.4.1 Initial Settings

Before turning on the power for the first time or when returning from manual operation to automatic operation, manually operate the automatic transfer switch to select the normal power source as described in Section 3.5, Manual Operation of Automatic Transfer Switch. Before closing the enclosure door and activating the normal power source, return the disconnect (DS) switch to its normal position to reconnect the logic controller to the transfer switch solenoids.

3.4.2 Automatic Operation Procedures

Automatic operation is a function of the logic controller installed in the unit. For automatic operation details and procedures, refer to the Logic Controller Operation and Installation Manual. See List of Related Materials in the Introduction.

3.5 Manual Operation of Automatic Transfer Switch



An operator handle is provided for maintenance purposes only. Disconnect both power sources before manually operating the switch. Do not use the manual operation handle to transfer the load when power is connected.

1. Disconnect or turn off both the normal and emergency power sources.
2. Open enclosure door of automatic transfer switch.
3. Set the disconnect switch (DS) to disconnect the controller from the switch solenoid(s).
4. Insert the operator handle and set the switch shown in Figure 3-3 to the desired position.




Figure 3-3 ATS Disconnect Switch

5. Remove and stow the operator handle.
6. Close the enclosure door.
7. Reconnect or turn on the applicable (normal or emergency) power source.

3.6 Operation of Bypass/Isolation Switch

An automatic transfer switch equipped with a bypass/isolation switch allows withdrawal of the ATS for testing and/or service without interrupting power to the load.

Normally the bypass switch is open and the ATS feeds the load. See Figure 3-4. Closing the bypass switch allows withdrawal of the ATS to the TEST or ISOLATE positions. Mechanical and electrical interlocks prevent cross-servicing or bypassing to an unacceptable source.




Figure 3-4 Automatic Position

In the TEST position, the ATS is disconnected from the load but the controller is powered to allow testing. See Figure 3-5.




Figure 3-5 Test Position

In the ISOLATE position, the ATS is completely withdrawn and can be removed from the enclosure for maintenance or service. See Figure 3-6.




Figure 3-6 Isolate Position

If the normal source fails while the ATS is bypassed, an auxiliary contact on the bypass switch starts the generator set. Use the manual handle to transfer the load to the available source. Interlocks prevent transfer if the ATS is in the circuit and connected to the opposite source.

Interlocks prevent reconnection of the ATS after bypass if the ATS and bypass switch source positions do not match. See Figure 3-7.




Figure 3-7 Bypass Position

3.6.1 Bypass/Isolation Switch Operation Notes

All bypass/isolation switches:

1. When the ATS is in the test or isolate position, the bypass switch acts as a manual transfer switch. The transfer from the bypass emergency contacts to the bypass normal contacts results in a momentary loss of power to the load while the bypass switch is open.
2. The ATS will not operate if any of the following are true:
 - a. The harness plugs are not connected.
 - b. The disconnect switch is in the inhibit position.
 - c. The ATS is not in the auto or test positions.
 - d. The ATS is in the auto position and the bypass switch is not open.

150- to 400-amp switches only:

3. The manual bypass handle will not close in the bypass position if any of the following are true:
 - a. The ATS location handle is not engaged in one of the following positions: auto, test, or isolate.
 - b. The source selected is opposite of the ATS position while in the auto position.
 - c. The ATS is in the test or isolate position and the selected source is not available.
4. The ATS location handle will not operate if any of the following are true:
 - a. The bypass switch and ATS are not positioned to the same source. See Figure 3-7.
 - b. Power is not available.
 - c. The harness plugs are not connected.
 - d. The ATS has reached its limit of travel in the auto or isolate positions.

600- to 3000-amp switches only:

5. The manual bypass handle will not close in the bypass position if any of the following are true:
 - a. The bypass selector switch is turned to the source opposite the ATS.
 - b. The bypass selector switch is turned to the source opposite the ATS.
 - c. The ATS location handle is not engaged in one of the following positions: auto, test, or isolate.

- d. The source selected is opposite of the ATS position while in the auto position. See Figure 3-7.
 - e. The ATS is in the test or isolate position and the source selected is not available.
6. The manual bypass handle will not open the bypass if any of the following are true:
 - a. The ATS is not in one of the following positions: auto, test, or isolate.
 - b. The ATS is in the test or isolate position and the opposite source is not available.
 7. The crank handle will not operate if any of the following are true:
 - a. The bypass switch and ATS are not positioned to the same source.
 - b. Power is not available.
 - c. The harness plugs are not connected.
 - d. The ATS has reached its limit of travel in the auto or isolate positions (clutch device on the crank mechanism slips).

3.7 Operation, 150- to 400-Amp Switches

See Figure 3-8.




Figure 3-8 Bypass Switch Handle Positions, 150-400 Amp Switches

3.7.1 Placing ATS in Automatic Mode

1. Verify that the ATS contacts are in the same position as the bypass contacts.
2. Turn the disconnect switch to the inhibit position.
3. Move the ATS location handle to the auto position.
4. Move the manual bypass handle to the open position.
5. Turn the disconnect switch to the auto position.

3.7.2 Bypassing ATS

1. Open the bottom cabinet door and turn the disconnect switch to the inhibit position.
2. Position the manual bypass handle to the same power source as the ATS.

Note: The bypass switch uses safety interlocks to prevent cross phasing.

3.7.3 Testing ATS

1. Open the bottom cabinet door and turn the disconnect switch to the inhibit position.
2. Position the manual bypass handle to the ATS power source.
3. Move the ATS location handle to the test position.
4. Turn the disconnect switch to the auto position.
5. Run a loaded test. Refer to the ATS controller Operation Manual for instructions.

3.7.4 Isolating ATS

1. Open the bottom cabinet door and turn the disconnect switch to the inhibit position.
2. Position the manual bypass handle to the power source that powers the ATS.
3. Move the ATS location handle to the isolate position; the ATS isolate position lamp will illuminate.

3.7.5 Removing ATS

1. Open the cabinet door and turn the disconnect switch to the inhibit position. See Figure 3-3.
2. Position the manual bypass handle to the same power source as the ATS.
3. Move the ATS location handle to the release position.
4. Disconnect the multipin plugs and external connections from the ATS.
5. Lift the ATS out of its drawer.

3.7.6 Reconnecting ATS

1. Turn the disconnect switch to the inhibit position.
2. Place the ATS into its drawer slots (front rollers first).
3. Manually position the ATS to the same source as the bypass switch.
4. Reconnect the multipin plugs and external connections to the ATS.
5. Push the ATS inward to engage the carriage.
6. Move the ATS location handle to the test position.
7. Turn the disconnect switch to the auto position and use the test switch on the logic controller to electrically operate the ATS.
8. Move the ATS location handle to the auto position.
9. Turn the disconnect to the auto position and move the manual bypass handle to the open position.
10. To ensure correct ATS operation, run a test of the automatic operation. Refer to the controller Operation Manual for the automatic operation test procedure.

3.8 Operation, 600- to 1200-Amp Switches

See Figure 3-9.




Figure 3-9 Bypass Switch Crank Mechanism Location, 600-1200 Amp Switches

3.8.1 Placing ATS in Automatic Mode

1. Verify that the ATS contacts are in the same position as the bypass contacts.
2. Turn the disconnect switch to the inhibit position.
3. Rotate the crank mechanism clockwise until the ATS is in the auto position.
4. Move the manual bypass handle to the open position.
5. Turn the bypass selector switch to the off position.
6. Turn the disconnect switch to the auto position.

3.8.2 Bypassing ATS

1. Open the bottom cabinet door and turn the disconnect switch to the inhibit position.
2. Position the bypass selector switch to the same power source as the ATS.

Note: The bypass switch uses safety interlocks to prevent cross phasing.

3. Move the manual bypass handle to the BYPASS POSITION.

3.8.3 Testing ATS

1. Open the bottom cabinet door and turn the disconnect switch to the inhibit position.
2. Position the bypass selector switch to the source that powers the ATS.
3. Move the manual bypass handle to the bypass position.
4. Rotate the crank mechanism counterclockwise until the ATS location pointer is aligned with isolate; the ATS isolate position lamp will illuminate.
5. Turn the disconnect switch to the auto position.
6. Run a loaded test. Refer to the ATS controller Operation Manual for instructions.

3.8.4 Isolating ATS

1. Open the bottom cabinet door and turn the disconnect switch to the inhibit position.
2. Position the bypass selector switch to the source that powers the ATS.
3. Move the manual bypass handle to the bypass position.
4. Rotate the crank mechanism counterclockwise until the ATS location pointer is aligned with isolate; the ATS isolate position lamp will illuminate.

3.8.5 Removing ATS

1. Open the cabinet door and turn the disconnect switch to the inhibit position. See Figure 3-3.
2. Move the bypass selector switch to the source that powers the ATS.
3. Move the manual bypass handle to the BYPASS position.
4. Rotate the crank mechanism counterclockwise until the ATS location pointer is aligned with isolate.
5. Disconnect the multipin plugs and external connections from the ATS.

6. Rotate the four panel latches to the vertical position. See Figure 3-10.




Figure 3-10 Rotation Of The Panel Latch

7. Pull the ATS outward until the slide brackets are fully extended.
8. Engage the slide locks to prevent movement of the brackets.
9. Connect a lift bar to the ATS lifting brackets.

3.8.6 Reconnecting ATS

1. Turn the disconnect switch to the inhibit position.
2. Seat the ATS on the slide brackets.
3. Remove the lift bar assembly.
4. Release the slide locks. Raise the slide locks approximately 60° to disengage. See Figure 3-11.




Figure 3-11 Slide Locks

5. Push the ATS in until the power panel latches can be engaged and rotated to the horizontal position.
6. Confirm that the bypass switch is in the isolate position.

7. Reconnect the multipin harness plugs.
8. Rotate the crank mechanism clockwise until the ATS is in the auto position.
9. Move the manual bypass handle to the AUTO position.
10. Turn bypass selector switch to the off position.
11. Turn the disconnect switch to the auto position.
12. To ensure correct ATS operation, run a test of the automatic operation. Refer to the controller Operation Manual for the automatic operation test procedure.

3.9 Operation, 1600- to 3000-Amp Switches

See Figure 3-12.

3.9.1 Placing ATS in Automatic Mode

1. Verify that the ATS contacts are in the same position as the bypass contacts.
2. Turn the disconnect switch to the inhibit position.
3. Rotate the crank mechanism clockwise until the ATS is in the auto position.
4. Move the manual bypass handle to the open position.
5. Turn the bypass selector switch to the off position.
6. Turn the disconnect switch to the auto position.

3.9.2 Bypassing ATS

1. Open the bottom cabinet door and turn the disconnect switch to the inhibit position.
2. Position the bypass selector switch to the same power source as the ATS.

Note: The bypass switch uses safety interlocks to prevent cross phasing.

3. Move the manual bypass handle to the BYPASS POSITION.




Figure 3-12 1600–3000 Amp Bypass Handle Positions

3.9.3 Testing ATS

1. Open the bottom cabinet door and turn the disconnect switch to the inhibit position.
2. Position the bypass selector switch to the source that powers the ATS.
3. Move the manual bypass handle to the bypass position.
4. Rotate the crank mechanism counterclockwise until the ATS location pointer is aligned with isolate; the ATS isolate position lamp will illuminate.
5. Turn the disconnect switch to the auto position.
6. Run a loaded test. Refer to the ATS controller Operation Manual for instructions.

3.9.4 Isolating ATS

1. Open the bottom cabinet door and turn the disconnect switch to the inhibit position.
2. Position the bypass selector switch to the source that powers the ATS.
3. Move the manual bypass handle to the bypass position.

4. Rotate the crank mechanism counterclockwise until the ATS location pointer is aligned with isolate; the ATS isolate position lamp will illuminate.

3.9.5 Removing ATS

1. Open the cabinet door and turn the disconnect switch to the inhibit position. See Figure 3-3.
2. Move the bypass selector switch to the source that powers the ATS.
3. Move the manual bypass handle to the bypass position.
4. Rotate the crank mechanism counterclockwise until the ATS location pointer is aligned with isolate.
5. Disconnect the multipin plugs and external connections from the ATS.
6. Slide the four corner latches of the ATS to the innermost position.
7. The ATS can now be rolled out of the cabinet on the built-in cart.

3.9.6 Reconnecting ATS

1. Turn the disconnect switch to the inhibit position.
2. Roll cart back into the cabinet.
3. Slide the four corner latches of the ATS to the outermost position.
4. Turn the disconnect switch to the inhibit position.
5. Manually position the ATS to the same source as the bypass switch.
6. Reconnect the multipin harness plugs.
7. Rotate the crank mechanism clockwise until the ATS is in the auto location.
8. Move the manual bypass switch to the OPEN position.
9. Turn the disconnect switch to the auto position.
10. To ensure correct ATS operation, run a test of the automatic operation. Refer to the controller Operation Manual for the automatic operation test procedure.

Section 4 Scheduled Maintenance

Scheduled preventive maintenance ensures safe and reliable operation and extends the life of the transfer switch. Preventive maintenance includes periodic testing, cleaning, inspection, and replacement of worn or missing components.


A local authorized distributor or dealer can provide complete preventive maintenance and services to keep the transfer switch in top condition. Contact a local distributor or dealer for additional information. See the Service Assistance section in this manual for how to locate a local distributor or dealer.

Read this entire section carefully before attempting any maintenance or service. Unless otherwise specified, have maintenance or service performed by an authorized service center that has trained and qualified personnel who follow all applicable codes and standards.

Keep records of all maintenance or service.

Replace all barriers and close and lock the enclosure door after maintenance or service and before reapplying power.

WARNING



Accidental starting. Can cause severe injury or death.

Disconnect the battery cables before working on the generator set. Remove the negative (-) lead first when disconnecting the battery. Reconnect the negative (-) lead last when reconnecting the battery.

Disabling the generator set. Accidental starting can cause severe injury or death. Before working on the generator set or equipment connected to the set, disable the generator set as follows: (1) Move the generator set master switch to the OFF position. (2) Disconnect the power to the battery charger. (3) Remove the battery cables, negative (-) lead first. Reconnect the negative (-) lead last when reconnecting the battery. Follow these precautions to prevent starting of the generator set by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer.

DANGER



Hazardous voltage. Will cause severe injury or death.

Disconnect all power sources before servicing. Install the barrier after adjustments, maintenance, or servicing.

DANGER



Hazardous voltage. Will cause severe injury or death.

Only authorized personnel should open the enclosure.

Grounding electrical equipment. Hazardous voltage can cause severe injury or death. Electrocutation is possible whenever electricity is present. Ensure you comply with all applicable codes and standards. Electrically ground the generator set, transfer switch, and related equipment and electrical circuits. Turn off the main circuit breakers of all power sources before servicing the equipment. Never contact electrical leads or appliances when standing in water or on wet ground because these conditions increase the risk of electrocution.

Short circuits. Hazardous voltage/current can cause severe injury or death. Short circuits can cause bodily injury and/or equipment damage. Do not contact electrical connections with tools or jewelry while making adjustments or repairs. Remove all jewelry before servicing the equipment.

Servicing the transfer switch. Hazardous voltage can cause severe injury or death. Deenergize all power sources before servicing. Turn off the main circuit breakers of all transfer switch power sources and disable all generator sets as follows: (1) Move all generator set master controller switches to the OFF position. (2) Disconnect power to all battery chargers. (3) Disconnect all battery cables, negative (-) leads first. Reconnect negative (-) leads last when reconnecting the battery cables after servicing. Follow these precautions to prevent the starting of generator sets by an automatic transfer switch, remote start/stop switch, or engine start command from a remote computer. Before servicing any components inside the enclosure: (1) Remove all jewelry. (2) Stand on a dry, approved electrically insulated mat. (3) Test circuits with a voltmeter to verify that they are deenergized.

NOTICE

The transfer switch may use both American Standard and metric hardware. Use the correct size tools to prevent rounding of the bolt heads and nuts.

NOTICE

Electrostatic discharge damage. Electrostatic discharge (ESD) damages electronic circuit boards. Prevent electrostatic discharge damage by wearing an approved grounding wrist strap when handling electronic circuit boards or integrated circuits. An approved grounding wrist strap provides a high resistance (about 1 megohm), *not a direct short*, to ground.

NOTICE

Improper operator handle usage. Use the manual operator handle on the transfer switch for maintenance purposes only. Return the transfer switch to the normal position. Remove the manual operator handle, if used, and store it in the place provided on the transfer switch when service is completed.

Screws and nuts are available in different hardness ratings. To indicate hardness, American Standard hardware uses a series of markings and metric hardware uses a numeric system. Check the markings on the bolt heads and nuts for identification.

4.1 Inspection and Service

Contact an authorized distributor/dealer to inspect and service the transfer switch when any wear, damage, deterioration, or malfunction of the transfer switch or its components is evident or suspected.

4.1.1 General Inspection

External Inspection Keep the transfer switch clean and in good condition by performing a weekly general external inspection of the transfer switch for any signs of vibration, leakage, unusual noise, excessive temperature, contamination, or deterioration. Remove accumulations of dirt, dust, and other contaminants from the transfer switch's external components or enclosure with a vacuum cleaner or by wiping with a dry cloth or brush.

Note: Do not use compressed air to clean the switch because it can cause debris to lodge in the components and cause damage.

Replace any worn, missing, or broken external components with manufacturer-recommended replacement parts. Contact a local authorized distributor/dealer for specific part information and part ordering. Tighten loose external hardware.

Internal Inspection Disconnect all power sources, open the transfer switch enclosure door, and inspect internal components monthly or when any condition noticed during an external inspection may have affected internal components.

Contact an authorized distributor/dealer to inspect and service the transfer switch if any of the following conditions are found inside the transfer switch.

- Accumulations of dirt, dust, moisture, or other contaminants
- Signs of corrosion
- Worn, missing, or broken components
- Loose hardware
- Wire or cable insulation deterioration, cuts, or abrasion
- Signs of overheating or loose connections: discoloration of metal, melted plastic, or a burning odor
- Other evidence of wear, damage, deterioration, or malfunction of the transfer switch or its components.

If the power interruption required to perform an internal inspection is unacceptable in the application, have an internal inspection performed by an authorized distributor/dealer.

4.1.2 Other Inspections and Service

Have an authorized distributor/dealer perform scheduled maintenance, service, and other maintenance that ensures the safe and reliable operation of the transfer switch including annual inspection and testing. See Section 4.3, Service Schedule, for the recommended maintenance items and service intervals.

Have an authorized distributor/dealer repair or replace components inside the transfer switch enclosure with manufacturer-recommended replacement parts.

4.2 Testing

The manual operation handle is provided with the switch for maintenance purposes only. Disconnect both power sources before manually operating the switch. Do not use the manual operation handle to transfer the load with power connected.

4.2.1 Weekly Generator Set Exercise

Use a plant exerciser or manual test to start and run the generator set under a load once a week to maximize the reliability of the emergency power system. See the logic controller operation and installation manual for the procedure to exercise the generator set. See List of Related Materials in the Introduction section in this manual.

4.2.2 Monthly Automatic Control System Test

Test the transfer switch's automatic control system monthly. See the logic controller operation and installation manual for the test procedure. Verify that the expected sequence of operations occurs as the switch transfers the load to the emergency source when a normal source failure occurs or is simulated. Observe the indicators (incandescent lamps and LEDs) included on the transfer switch to check their operation. When the switch transfers the load to the emergency source (after a time delay in the off position on programmed transition units), end the test and verify that the expected sequence of operations occurs as the transfer switch retransfers to the available normal source (after a time delay in the off position on programmed transition units) and signals the generator set to shut down after a cooldown period.

4.3 Service Schedule

Follow the service schedule below for the recommended service intervals. Have all service

performed by an authorized service center except for activities limited to the items designated by an X.

System Component or Procedure	See Section	Visually Inspect	Check	Change	Clean	Test	Frequency
Electrical System							
Check for signs of overheating or loose connections: discoloration of metal, melted plastic, or a burning odor	4.1.1	X	X				M
Check the contactor's external operating mechanism for cleanliness and clean and relubricate if dirty *	4.1.1	X		D, R (lubricant)	D		M
Check wiring insulation for deterioration, cuts, or abrasion and repair or replace wiring to regain the properties of the original wiring	4.1.1	X		D, R (wiring)			M
	4.1.2	D	D				Q
Check the transfer switch's main power switching mechanisms' mechanical operation and integrity	4.1.2	D	D			D	Y
Tighten control and power wiring connections to specifications	4.1.2, L		D			D	Y
Check the transfer switch's main power switching contacts' condition and clean or replace the main contacts or replace the contactor assembly as necessary	4.1.2	D		D, R	D		Y
Perform a thermal scan or millivolt drop test to check for high contact resistances on power circuits. Tighten connections, clean main contacts, adjust or replace main contacts or contactor assembly to eliminate high contact resistances	4.1.2		D	D, R	D	D	Y
Test wire and cable insulation for electrical breakdown	4.1.2					D	Every 3 years
Check calibration of voltage-sensing circuitry and setpoints, and recalibrate circuitry as necessary	4.1.2		D			D	Every 5 years
Control System							
Exercise the generator set under load	4.2.1, L					X	W
Test the transfer switch's automatic control system	4.2.2, L	X				X	M
Test all indicators (incandescent lamps and LEDs) and all remote control systems for operation	L	D	D	D, R		D	Y
General Equipment Condition							
Inspect the outside of the transfer switch for any condition of vibration, leakage, noise, temperature, contamination, or deterioration to keep the transfer switch clean and in good condition *	4.1.1	X			X		W
Check that all external hardware is in place, tightened, and not badly worn	4.1.1	X	X	R			W
Inspect the inside of transfer switch for any condition of vibration, leakage, noise, temperature, contamination, or deterioration to keep the inside of the transfer switch clean, dry, and in good condition *	4.1.1	X	X		D		M
	4.1.2	D	D		D		Y
Check that all internal hardware is in place, tightened, and not badly worn	4.1.2	X	D				M
<p>* Service more frequently if operated in dusty or dirty areas.</p> <p>See Section Read these sections carefully for additional information before attempting maintenance or service.</p> <p>Visually Inspect Examine these items visually.</p> <p>Check Requires physical contact with, or movement of, system components or the use of nonvisual indications.</p> <p>Change May require replacement of components depending upon the severity of the problem.</p> <p>Clean Remove accumulations of dirt and contaminants from external transfer switch's components or enclosure with a vacuum cleaner or by wiping with a dry cloth or brush. <i>Do not use compressed air to clean the switch because it can cause debris to lodge in the components and cause damage.</i></p> <p>Test May require tools, equipment, or training available only through an authorized service center.</p> <p>L See the transfer switch logic controller operation and installation manual for more information.</p> <p>D Have service performed by an authorized service center.</p> <p>X Operator action.</p> <p>R May require replacement of components.</p>							<p>W=Weekly</p> <p>M=Monthly</p> <p>Q=Quarterly</p> <p>S=Six Months</p> <p>Y=Yearly</p>

Section 5 Diagrams and Drawings

Use the table below to identify the drawing numbers for your ZCB-5 or ZCM-5 bypass/isolation switch. The drawings are arranged in alpha-numeric order on the following pages.

ATS Model	Poles	Amps	Dimension Drawing NEMA 1	Bypass Schematic	Schematic with MPAC 1500 Conversion	Wiring Diagram with MPAC 1500 Conversion
ZCB-5xx231-0150	2	150	ADV-5958A-A	321444	GM99368	GM99369
ZCB-5xx231-0225		225				
ZCB-5xx231-0260		260				
ZCB-5xx231-0400		400				
ZCM-5xx231-0150	2	150	ADV-6828A-B	GM29622 * GM55095 †	GM99366 * GM99360 †	GM99367 * GM99361 †
ZCM-5xx231-0225		225				
ZCM-5xx231-0260		260				
ZCM-5xx231-0400		400				
ZCB-5xx231-0600	2	600	ADV-5959A-D	321484	GM99362	GM99363
ZCB-5xx231-0800		800				
ZCB-5xx341-0150	3	150	ADV-5958A-A	321444	GM99368	GM99369
ZCB-5xx341-0225		225				
ZCB-5xx341-0260		260				
ZCB-5xx341-0400		400				
ZCM-5xx341-0150	3	150	ADV-6828A-B	GM29622 * GM55095 †	GM99366 * GM99360 †	GM99367 * GM99361 †
ZCM-5xx341-0225		225				
ZCM-5xx341-0260		260				
ZCM-5xx341-0400		400				
ZCB-5xx341-0600	3	600	ADV-5959A-D	321484	GM99362	GM99363
ZCB-5xx341-0800		800				
ZCB-5xx341-1000		1000				
ZCB-5xx341-1200		1200				
ZCB-5xx341-1600	3	1600	ADV-5960A-C ADV-5960D-A	321454	GM99364	GM99365
ZCB-5xx341-2000		2000				
ZCB-5xx341-2500		2500				
ZCB-5xx341-3000		3000				
ZCB-5xx341-4000		4000				
ZCB-5xx641-0150	4	150	ADV-5958A-A	321444	GM99368	GM99369
ZCB-5xx641-0225		225				
ZCB-5xx641-0260		260				
ZCB-5xx641-0400		400				
ZCM-5xx641-0150	4	150	ADV-6828A-B	GM29622 * GM55095 †	GM99366 * GM99360 †	GM99367 * GM99361 †
ZCM-5xx641-0225		225				
ZCM-5xx641-0260		260				
ZCM-5xx641-0400		400				
ZCB-5xx641-0600	4	600	ADV-5959A-D	321484	GM99362	GM99363
ZCB-5xx641-0800		800				
ZCB-5xx641-1000		1000				
ZCB-5xx641-1200		1200				
ZCB-5xx641-1600	4	1600	ADV-5960A-C ADV-5960D-A	321454	GM99364	GM99365
ZCB-5xx641-2000		2000				
ZCB-5xx641-2500		2500				
ZCB-5xx641-3000		3000				
ZCB-5xx641-4000		4000				
xx =See Figure 5-1, Voltage Codes			* Before rectifier change. † With new rectifiers. See Figure 5-2.			

Code (xx)	Voltage and Frequency
53	220 V, 60 Hz
60	600 V, 60 Hz
63	220 V, 50 Hz
64	240 V, 60 Hz
66	480 V, 60 Hz
68	208 V, 60 Hz
71	380 V, 50 Hz
72	380 V, 60 Hz
73	416 V, 50 Hz

Figure 5-1 Voltage Codes





Figure 5-2 New Rectifiers with MOVs (150-400 Amp Model ZCM)




REV	DATE	DESCRIPTION	BY	CHK
A	3-28-94	WIRE NUMBERS REVISED	AH	F
B	8-25-99	(C-3,2) D2 AND D3 WAS BR-3, (B-3) ADDED JUMPER [85028]	FCH	

LEGEND

AA-1,2 LIMIT SWITCH, ATS AUTO LOCATION
 AB3-1 LIMIT SWITCH, BYPASS EMERGENCY
 AB4 LIMIT SWITCH, BYPASS NORMAL
 AI LIMIT SWITCH, ATS IN ISOLATE
 ALH ATS LOCATION HANDLE
 ALL LIMIT SWITCH, ATS LOCK LOCATION
 AT-1,2 LIMIT SWITCH, ATS TEST LOCATION
 ATR AUTO/TEST RELAY
 BFS LIMIT SWITCH, BYPASS LOCK LOCATION
 BTE BYPASS SOLENOID
 BTN LIMIT SWITCH, BYPASS TRANSFER EMERGENCY (MBH MOVEMENT TO NORMAL)
 BR BRIDGE RECTIFIER
 DS ATS DISCONNECT SWITCH
 EA-3 LIMIT SWITCH, ATS IN EMERGENCY
 LBE BYPASS EMERGENCY LIGHT
 LBN BYPASS NORMAL LIGHT
 LAI ATS ISOLATE LIGHT
 LNA ATS TEST LOCATION
 LNA DISCONNECT SWITCH INHIBIT POSITION
 LUT EMERGENCY AVAILABLE LIGHT
 LUT ATS INHIBIT LIGHT
 LNA NORMAL AVAILABLE LIGHT
 NA-4 LIMIT SWITCH, ATS IN NORMAL
 PLS-1,2 PERMISSIVE LIMIT SWITCH
 RNH NORMAL VOLTAGE RELAY
 TSE SOLENOID, TRANSFER RELEASE
 TSE LIMIT SWITCH, TRANSFER SWITCH ENGAGED
 81 TERMINAL ON BYPASS SUBPANEL

LIMIT SWITCH CHART

LIMIT SWITCH	ATS LOCATION		BYPASS MODE		ACTIVATED WHEN ALH IS OPERATED
	TEST	AUTO	REMOVE	EMERGENCY	
AA	X	X			
AI	X	X			
ALL	X	X	X	X	
TSE	X	X	X	X	
AE	X	X			
NA			X		
EA				X	
AB4				X	
AB3				X	
BLL				X	
PLS				X	



MODEL ZCB-1, 5
 100-400 AMP
 3 & 4 POLE
 FOR INTERCONNECTION DIAGRAM SEE DWG. 321558

UNLESS OTHERWISE SPECIFIED -
 1) DIMENSIONS IN INCHES
 2) TOLERANCES ARE:
 .XXX ± .010 ANGLES ± 1/2
 .XX ± .030 SURFACE FINISH
 X ± .060 MAX.

APPROVALS DATE
 DRAWN WJB 1-11-94
 CHECKED AH 2-14-94
 APPROVED AH 2-14-94

SCALE NONE
 SHEET 1-1

CAD NO. 321444.DWG
 DWG. NO. 321444


KOHLER CO.
 GENERATOR DIVISION, KOHLER, WI 53044 U.S.A.
 THIS DRAWING IS THE PROPERTY OF KOHLER CO. PROPERTY AND
 MUST BE KEPT IN CONFIDENTIALITY. ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED.

SCHEMATIC DIAGRAM

Bypass Schematic, Model ZCB-5, 150-400 Amps, 3 and 4 Poles, 321444

NO. POLES	CABINET DIMENSIONS			LUG RANGE	WIRE BENDING SPACE			WIRE GUTTERS		
	A	B	C		D (TOP)	E (BOTTOM)	F (LEFT)	G (RIGHT)		
BYPASS STANDARD SWITCH	2,3	30.00 [762]	23.00 [584]	28.00 [711]	3/0-250 MCM	15.25 [387]	13.88 [353]	4.38 [111]	1.38 [35]	
	4	36.00 [914]	29.00 [737]	34.00 [864]	3/0-250 MCM	15.25 [387]	13.88 [353]	4.38 [111]	5.00 [127]	
100-225 AMP	2,3	30.00 [762]	23.00 [584]	28.00 [711]	3/0-250 MCM	15.25 [387]	13.88 [353]	4.38 [111]	1.38 [35]	
	4	36.00 [914]	29.00 [737]	34.00 [864]	3/0-250 MCM	15.25 [387]	13.88 [353]	4.38 [111]	5.00 [127]	
260-400 AMP	2,3	30.00 [762]	23.00 [584]	28.00 [711]	3/0-250 MCM	15.25 [387]	13.88 [353]	4.38 [111]	1.38 [35]	
	4	36.00 [914]	29.00 [737]	34.00 [864]	3/0-250 MCM	15.25 [387]	13.88 [353]	4.38 [111]	5.00 [127]	
BYPASS PROGRAMMED TRANSITION SWITCH	2,3	30.00 [762]	23.00 [584]	28.00 [711]	3/0-250 MCM	15.25 [387]	13.88 [353]	4.38 [111]	1.38 [35]	
	4	36.00 [914]	29.00 [737]	34.00 [864]	3/0-250 MCM	15.25 [387]	13.88 [353]	4.38 [111]	5.00 [127]	

REV	DATE	REVISION	BY
A	9-16-94	GENERIC TITLEBLOCK ADDED	PWF




TYPICAL DIMENSIONS		DATE		REVISION	
1) DIMENSIONS ARE IN INCHES	2) DIMENSIONS ARE IN MILLIMETERS	DATE	REVISION	BY	DATE
3) DIMENSIONS ARE IN INCHES	4) DIMENSIONS ARE IN MILLIMETERS	1-26-94	1-26-94	PWF	1-26-94
5) DIMENSIONS ARE IN INCHES	6) DIMENSIONS ARE IN MILLIMETERS	2-22-94	2-22-94		2-22-94
7) DIMENSIONS ARE IN INCHES	8) DIMENSIONS ARE IN MILLIMETERS	2-22-94	2-22-94		2-22-94

APPROVALS	DATE	FILE
DESIGN	1-26-94	ADV5958A-010
CHECKED	2-22-94	ADV5958A-010
APPROVED	2-22-94	ADV-5958

DIMENSION PRINT			
SCALE	1/8	DR NO.	ADV5958A-010
SHEET	1-3	DATE	2-22-94
BYPASS ISOLATION TRANSFER SWITCH		STANDARD & PROGRAMMED TRANSITION	
100-400 AMP, 2,3 & 4 POLE			

NEMA 1 ENCLOSURE

NEMA Type 1 Enclosure, 150-400 Amp Model ZCB, ADV-5958A-A (Discontinued in 2003)




REV	DATE	REVISION	BY
A	6-3-97	(0-4, D-7) SPACER WAS SPACE [50729]	RSH

UNLESS OTHERWISE SPECIFIED:		TITLE	
1) DIMENSIONS ARE IN INCHES	2) DIMENSIONS ARE IN MILLIMETERS	DATE	9-5-95
3) ANGLES ± 1/2	4) SURFACE FINISH	SCALE	1/2
5) SURFACE FINISH	6) SURFACE FINISH	DRW NO.	ADV5960.DWG
7) SURFACE FINISH	8) SURFACE FINISH	FIGURED	4-4
9) SURFACE FINISH	10) SURFACE FINISH	DRW NO.	ADV-5960
11) SURFACE FINISH	12) SURFACE FINISH	SHEET	D 6


NOTE: DIMENSIONS IN [] ARE MILLIMETER EQUIVALENTS.

BYPASS ISOLATION TRANSFER SWITCH
STANDARD & PROGRAMMED TRANSITION
1600-2000, 3000 AMP 2, 3 & 4 POLE

Dimensions, Neutral and Bus Details, 1600-3000 Amps, ADV-5960D-A



BYPASS SUBPANEL




BYPASS/ISOLATION SCHEMATIC


- AA-1 - LIMIT SWITCH, ATS AUTO LOCATION
- BTN - LIMIT SWITCH, BYPASS TRANSFER NORMAL (MBH MOVEMENT TO NORMAL)
- BTE - LIMIT SWITCH, BYPASS TRANSFER EMERG. (MBH MOVEMENT TO EMERGENCY)
- BPS - BYPASS SOLENOID
- AA-2 - LIMIT SWITCH, ATS AUTO LOCATION
- AT-1 - LIMIT SWITCH, ATS LOCK LOCATION
- AT-2 - LIMIT SWITCH, ATS TEST LOCATION
- AI - LIMIT SWITCH, ATS ISOLATE LOCATION
- LAI - LIMIT SWITCH, BYPASS LOCK LOCATION
- PLS-1 - PERMISSIVE LIMIT SWITCH ENGAGED
- TRC - SWITCH, TRANSFER RELEASE
- EA-3 - LIMIT SWITCH, ATS IN NORMAL
- EA-4 - LIMIT SWITCH, ATS IN EMERGENCY
- LBE - LIGHT, BYPASS EMERGENCY
- AB4-1 - LIMIT SWITCH, BYPASS NORMAL
- AB3-1 - PERMISSIVE LIMIT SWITCH
- AB3-2 - PERMISSIVE LIMIT SWITCH
- ATR - AUTO/TEST RELAY
- AT-1 - LIMIT SWITCH, ATS TEST LOCATION
- LIT - LIGHT, ATS INHIBIT
- DS - LIGHT, DISCONNECT SWITCH INHIBIT
- ALH - ATS LOCATION HANDLE
- MBH - MANUAL BYPASS HANDLE
- XBN - BYPASS NORMAL CONTROL
- XBE - BYPASS EMERGENCY CONTROL
- LNA - NORMAL TRANSFORMER
- LEA - EMERGENCY AVAILABLE LIGHT
- D1 - DIODE
- R1 - RESISTOR, RNH
- C - CAPACITOR, RNH
- BR-1, 2, 3 - BRIDGE RECTIFIER

ATS TEST PLUGS (TP)

LOOKING AT PINS



LOOKING AT SOCKETS



LIMIT SWITCH CHART

	ATS	ATS BYPASS
	LOCATION	MODE
X = ACTUATED		
	OPEN	
	EMERG.	
	NORM.	
	REMOVE	
AA	ISO	X
AT	TEST	X
AI	LOC	X
ALL	LOC	X
TSE	LOC	X
AE	LOC	X
NA	LOC	X
EA	LOC	X
AB4	LOC	X
AB3	LOC	X
BLL	LOC	X
PLS	ACTIVATED WHEN ALH IS OPERATED	X


UNLESS OTHERWISE SPECIFIED - 1) DIMENSIONS IN INCHES 2) TOLERANCES ARE: .XXX ± .010 .XX ± .030 .X ± .060 FRACTIONS ± MAX.	APPROVALS	DATE	SCALE	CAD NO.	SHEET
	AJH	9-12-03	NONE	GM29622.DWG	1-1
	WSD	10-20-03			
	AJH	10-20-03			

MODEL ZCM-5
150-400A
2, 3 & 4 POLE


FOR SCHEMATIC DIAGRAM SEE GM29621
FOR INTERCONNECTION DIAGRAM SEE GM29623

KOHLER CO.
GENERATOR DIVISION, KOHLER, WI 53044 U.S.A.
THIS DRAWING IS THE PROPERTY OF KOHLER CO. ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED.

SCHEMATIC DIAGRAM



Schematic Diagram, ZCM-5 with Decision-Maker® MPAC 1500 Controls, 150-400 Amps, GM99360 (with new rectifiers)




BYPASS/ISOLATION TRANSFER SWITCH

SEE BELOW FOR LUG CONFIGURATION


WIRE NUMBERING CHART

LIMIT SWITCHES	C	NC	NO
AA-1	60		61
AA-2	64	80	87
AB3-1	83A	83B	86
AB3-2	E12		E11
AB3-3	E12A	12A	
AB3-4	ABE		ABE
AB3-5	87D		85
AB4-1	80	83A	85
AB4-2	ABN		ABN
AB4-3	87D		86
AE-1	E11	11	11R
AE-2	E13	13	13R
A1	63		89
A1/2	87		87C
A1/3	87C		87D
ALL	64		63
AT-1	80		83B
AT-2	63		88
BLL	87C		87A
BTE	61		62
BTN	60		62
EA-3	86		87
NA-4	85		87
PLS-1	87A		87B
PLS-2	83B	83C	
TSE	87B		84

INTERCONNECTION PLUG DIAGRAM




BYPASS/ISOLATION DIAGRAM



ATS LOCATION	LOAD CARRYING CONTACTS	ATS TEST PLUG (TP)
1	2	3
2	3	4
3	4	5
4	5	

ATS LOCATION	1	2	3	4	5
AUTO	X	X	X	X	X
TEST	O	O	O	X	X
ISOLATE	O	O	O	O	O

X = CLOSED
O = OPEN



NOTE:
ATS SHOWN IN NORMAL POSITION WITH NO POWER AVAILABLE.

MODEL ZCM-5
150-400 AMP
3 & 4 POLE, LOGIC MPAC 1500
FOR SCHEMATIC SEE DWG. GM99360
FOR BYPASS SCHEMATIC SEE DWG. GM55095


DATE: 12-21-15
DRAWN BY: BTW
CHECKED BY: HC
APPROVED BY: MTL

DATE: 12-21-15
DRAWN BY: BTW
CHECKED BY: HC
APPROVED BY: MTL


SCALE: 1/1
SHEET: 2-2
PAGE NO: GM99361
D

KOHLER CO.
POWER SYSTEMS, KOHLER, WI 53044, U.S.A.
DESIGN, MANUFACTURE, ASSEMBLY, AND
INSTALLATION OF ELECTRICAL EQUIPMENT
DO NOT IMPLY ENDORSEMENT OR RECOMMENDATION BY KOHLER CO.
ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED.


DIAGRAM, WIRING



Schematic Diagram, ZCB-5 with Decision-Maker[®] MPAC 1500 Controls, 600-1200 Amps, 3 and 4 Poles, GM99362



Wiring Diagram, ZCB-5 with Decision-Maker® MPAC 1500 Controls, 600-1200 Amps, 3 and 4 Poles, GM99363



REV	DATE	REVISION	BY
-	1-5-16	NEW DRAWING (101189643)	BTM

APPROVALS	DATE	SCALE	SHEET
DESIGNED	1-5-16	1-1	1-1
CHECKED	1-5-16		
APPROVED	1-5-16		

MODEL ZCB-5
1600-3000 AMP
3 & 4 POLE
LOGIC - MPAC 1500

FOR WIRING DIAGRAM SEE DWG. GM99365
FOR BYPASS SCHEMATIC SEE DWG. 321454

KOHLER CO.
POWER SYSTEMS, KOHLER, WI 53044, USA
ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED.


NOTES:
1. ATS SHOWN IN NORMAL POSITION WITH NORMAL POWER PRESENT
2. NEUTRAL CONTACTS NTS & ETS PRESENT ON 4 POLE UNITS ONLY.
3. OPTIONAL NEUTRAL BUS

LEGEND
AB3-3 LIMIT SWITCH, BYPASS EMERGENCY
AE-1 LIMIT SWITCH, ENGINE START TRANSFER
ATR AUTO/TEST RELAY
CCE EMERGENCY TRANSFER OPERATOR (TRANSFER TO EMERGENCY)
CCE COIL CONTROL RELAY (TRANSFER TO EMERGENCY)
RE EMERGENCY OPERATOR BRIDGE RECTIFIER
CN NORMAL TRANSFER OPERATOR (TRANSFER TO NORMAL)
RN NORMAL TRANSFER OPERATOR BRIDGE RECTIFIER
DS DISCONNECT SWITCH
ECPT EMERGENCY CONTROL POWER TRANSFORMER
ETS EMERGENCY POWER TRANSFER SWITCH CONTACTS
NCPT NORMAL POWER TRANSFER SWITCH CONTACTS
NTS NORMAL POWER TRANSFER SWITCH CONTACTS
RNH NORMALLY HELD RELAY
SE LIMIT SWITCH - EMERGENCY
SN LIMIT SWITCH, NORMAL
COMPONENT CONNECTION TERMINAL
LEAD
P#-# PLUG/SOCKET CONNECTOR
● CONNECTION NODE
A4-1 TERMINAL BLOCK ON TRANSFER SWITCH PANEL
4 TERMINAL BLOCK ON LOGIC BOARD

MPAC POWER/CONTROL BOARD
MEMBRANE SWITCH
LCD DISPLAY
ETHERNET INTERFACE
STANDARD ON MPAC1500
OPTIONAL ON MPAC750, MPAC1200

AUXILIARY CONTACTS 15A, 240VAC
ENGINE START TERMINALS
MEMBRANE SWITCH
LCD DISPLAY
ETHERNET INTERFACE
STANDARD ON MPAC1500
OPTIONAL ON MPAC750, MPAC1200

MPAC POWER/CONTROL BOARD
MEMBRANE SWITCH
LCD DISPLAY
ETHERNET INTERFACE
STANDARD ON MPAC1500
OPTIONAL ON MPAC750, MPAC1200



REV	DATE	DESCRIPTION	BY
-	1-5-16	NEW DRAWING (CT138643)	BTW

REV	DATE	DESCRIPTION	BY
-	1-5-16	NEW DRAWING (CT138643)	BTW

REV	DATE	DESCRIPTION	BY
-	1-5-16	NEW DRAWING (CT138643)	BTW

REV	DATE	DESCRIPTION	BY
-	1-5-16	NEW DRAWING (CT138643)	BTW

REV	DATE	DESCRIPTION	BY
-	1-5-16	NEW DRAWING (CT138643)	BTW

REV	DATE	DESCRIPTION	BY
-	1-5-16	NEW DRAWING (CT138643)	BTW

REV	DATE	DESCRIPTION	BY
-	1-5-16	NEW DRAWING (CT138643)	BTW

REV	DATE	DESCRIPTION	BY
-	1-5-16	NEW DRAWING (CT138643)	BTW

TO LOAD

FROM NORMAL SOURCE

FROM EMERGENCY SOURCE

AT MECHANISM

AT INNER PANEL

GD

GD

LEGEND

AB3-2 LIMIT SWITCH, BYPASS EMERGENCY

AE-1 LIMIT SWITCH, ENGINE START TRANSFER

ATR AUTO/TEST RELAY

CE EMERGENCY TRANSFER OPERATOR (TRANSFER TO EMERGENCY)

CN COIL CONTROL RELAY (TRANSFER TO EMERGENCY)

CCN NORMAL TRANSFER OPERATOR (TRANSFER TO NORMAL)

RE EMERGENCY TRANSFER OPERATOR (TRANSFER TO EMERGENCY)

CCN NORMAL TRANSFER OPERATOR (TRANSFER TO NORMAL)

RN NORMAL OPERATOR BRIDGE RECTIFIER

DS DISCONNECT SWITCH

ECPT EMERGENCY CONTROL POWER TRANSFORMER

ETS EMERGENCY POWER TRANSFER SWITCH CONTACTS

NCPT NORMAL CONTROL POWER TRANSFORMER

NTS NORMAL POWER TRANSFER SWITCH CONTACTS

RNH NORMALLY HELD RELAY

SE LIMIT SWITCH - EMERGENCY

SN LIMIT SWITCH, NORMAL

COMPONENT CONNECTION TERMINAL

LEAD

P#-# PLUG/SOCKET CONNECTOR

● CONNECTION NODE

AA-1 TERMINAL BLOCK ON TRANSFER SWITCH PANEL

4 TERMINAL BLOCK ON LOGIC BOARD

NOTES:

1. ATS SHOWN IN NORMAL POSITION WITH NORMAL POWER PRESENT

2. NEUTRAL CONTACTS NTS & ETS PRESENT ON 4 POLE UNITS ONLY.

3. OPTIONAL NEUTRAL BUS

FOR WIRING DIAGRAM SEE DWR. GM99366

FOR BYPASS SCHEMATIC SEE DWR. GM29622

MODEL ZCM-5

150-400 AMP

3 & 4 POLE

LOGIC - MPAC 1500

GM99366

DATE

DATE

DATE

DATE

DATE

DATE

DATE

BY

BY

BY

BY

BY

BY

BY

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

DATE

DATE

DATE

DATE

DATE

DATE

DATE

BY

BY

BY

BY

BY

BY

BY

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

DATE

DATE

DATE

DATE

DATE

DATE

DATE

BY

BY

BY

BY

BY

BY

BY

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

DATE

DATE

DATE

DATE

DATE

DATE

DATE

BY

BY

BY

BY

BY

BY

BY

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

DATE

DATE

DATE

DATE

DATE

DATE

DATE

BY

BY

BY

BY

BY

BY

BY

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

DATE

DATE

DATE

DATE

DATE

DATE

DATE

BY

BY

BY

BY

BY

BY

BY

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

SCALE

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

APPROVALS

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

TITLE

DATE

DATE

DATE

DATE

DATE

DATE

DATE

BY

BY

BY

BY


BY

BY

BY

SCALE

</



- NOTES**
1. SWITCH SHOWN DE-ENERGIZED CONNECTED TO NORMAL SOURCE.
 2. OPERATORS MANUAL IS FURNISHED WITH EACH AUTOMATIC TRANSFER SWITCH REFER TO THIS PUBLICATION PRIOR TO INSTALLATION AND OPERATION OF THE SWITCH.
 3. ALL PLUGS & SOCKETS VIEWED FROM MATING SIDE.
- LEGEND**
- BR CNE BRIDGE RECTIFIER
 - CCE COIL CONTROL RELAY (TRANSFER TO EMERGENCY)
 - CCN COIL CONTROL RELAY (TRANSFER TO NORMAL)
 - CNE NORMAL TRANSFER OPERATOR (TRANSFER TO EMERGENCY)
 - DS DISCONNECT SWITCH
 - E EMERGENCY CONTACTOR
 - ER EMERGENCY RELAY
 - F FUSE
 - J JUMPER
 - NR NORMAL RELAY
 - P PLUG
 - SCE CNE CUTOFF SWITCH
 - SCN CNE CUTOFF SWITCH
 - SE LIMIT SWITCH - EMERGENCY
 - SN LIMIT SWITCH - NORMAL
 - TB TERMINAL BLOCK
 - TDOE TIME DELAY OFF TO EMERGENCY
 - TDOEN TIME DELAY OFF TO NORMAL

REV	DATE	REVISION
-	12-21-15	NEW DRAWING [DT1.90943]
BY		BTW


APPROVALS	DATE
DESIGNED BY	12-21-15
CHECKED BY	12-21-15
APPROVED BY	12-21-15
PROJECT NO.	GM99367
DRAWING NO.	GM99367
SHEET	1-2

36 PIN CONNECTOR VIEWED FROM MATING END	1	209A	306
	4	EA	209
	8	EA	209
	12	57A	58
	16	EC	EB
	20	33	206
	24	NC	NA
	28	GD	76
	32	13	14
	36	77	76

36 PIN CONNECTOR VIEWED FROM MATING END	1	308	209A
	4	EA	209
	8	EA	209
	12	57A	58
	16	EC	EB
	20	33	206
	24	NC	NA
	28	GD	76
	32	13	14
	36	77	76

24 PIN CONNECTOR VIEWED FROM MATING END	1	14	8	13
	4	1	14	13
	8	57	58	EA
	12	NC	NA	EA
	16	EA	EB	EA
	20	EA	EB	EA
	24	EA	EB	EA


24 PIN CONNECTOR VIEWED FROM MATING END	1	14	8	13
	4	1	14	13
	8	57	58	EA
	12	NC	NA	EA
	16	EA	EB	EA
	20	EA	EB	EA
	24	EA	EB	EA




WIRE NUMBERING CHART

LIMIT SWITCHES	C	NC	NO
AA-1	60		61
AA-2	64	80	87
AB3-1	83A	83B	86
AB3-2	E12		E11
AB3-3	E12A	12A	
AB3-4	ABE		ABE
AB3-5	87D		85
AB4-1	80	83A	85
AB4-2	ABN		ABN
AB4-3	87D		86
AE-1	E11	11	11R
AE-2	E13	13	13R
A1	63		89
A1/2	87		87C
A1/3	87C		87D
ALL	64		63
AT-1	80		83B
AT-2	63		88
BLL	87C		87A
BTE	61		62
BTN	60		62
EA-3	86		87
NA-4	85		87
PLS-1	87A		87B
PLS-2	83B	83C	
TSE	87B		84

INTERCONNECTION PLUG DIAGRAM




BYPASS/ISOLATION DIAGRAM



ATS LOCATION	LOAD CARRYING CONTACTS	ATS TEST PLUG CONTACTS (TP)
1	2	3
2	3	4
3	4	5
4	5	
5		

AUTO X X X X X
 TEST 0 0 0 0 0
 ISOLATE 0 0 0 0 0

X = CLOSED
O = OPEN




NOTE:
ATS SHOWN IN NORMAL POSITION WITH NO POWER AVAILABLE.

MODEL ZCM-5
 150-400 AMP
 3 & 4 POLE, LOGIC MPAC 1500
 FOR SCHEMATIC SEE DWG. GM99366
 FOR BYPASS SCHEMATIC SEE DWG. GM29622

KOHLER CO.
 POWER SYSTEMS, KOHLER, WI 53044, U.S.A.
 THE INFORMATION CONTAINED HEREIN IS THE PROPERTY OF KOHLER CO.
 AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF KOHLER CO.

TITLE: **DIAGRAM, WIRING**
 SHEET: **2-2**
 OF: **2**



Schematic Diagram, ZCB-5 with Decision-Maker[®] MPAC 1500 Controls, 150-400 Amps, 2, 3, and 4 Poles, GM99368

Appendix A Abbreviations

The following list contains abbreviations that may appear in this publication.

A, amp	ampere	cfm	cubic feet per minute	est.	estimated
ABDC	after bottom dead center	CG	center of gravity	E-Stop	emergency stop
AC	alternating current	CID	cubic inch displacement	etc.	et cetera (and so forth)
A/D	analog to digital	CL	centerline	exh.	exhaust
ADC	advanced digital control; analog to digital converter	cm	centimeter	ext.	external
adj.	adjust, adjustment	CMOS	complementary metal oxide substrate (semiconductor)	F	Fahrenheit, female
ADV	advertising dimensional drawing	cogen.	cogeneration	fglass.	fiberglass
Ah	amp-hour	com	communications (port)	FHM	flat head machine (screw)
AHWT	anticipatory high water temperature	coml	commercial	fl. oz.	fluid ounce
AISI	American Iron and Steel Institute	Coml/Rec	Commercial/Recreational	flex.	flexible
ALOP	anticipatory low oil pressure	conn.	connection	freq.	frequency
alt.	alternator	cont.	continued	FS	full scale
Al	aluminum	CPVC	chlorinated polyvinyl chloride	ft.	foot, feet
ANSI	American National Standards Institute (formerly American Standards Association, ASA)	crit.	critical	ft. lb.	foot pounds (torque)
AO	anticipatory only	CRT	cathode ray tube	ft./min.	feet per minute
APDC	Air Pollution Control District	CSA	Canadian Standards Association	ftp	file transfer protocol
API	American Petroleum Institute	CT	current transformer	g	gram
approx.	approximate, approximately	Cu	copper	ga.	gauge (meters, wire size)
AQMD	Air Quality Management District	cUL	Canadian Underwriter's Laboratories	gal.	gallon
AR	as required, as requested	CUL	Canadian Underwriter's Laboratories	gen.	generator
AS	as supplied, as stated, as suggested	cu. in.	cubic inch	genset	generator set
ASE	American Society of Engineers	cw.	clockwise	GFI	ground fault interrupter
ASME	American Society of Mechanical Engineers	CWC	city water-cooled	GND, ⊕	ground
assy.	assembly	cyl.	cylinder	gov.	governor
ASTM	American Society for Testing Materials	D/A	digital to analog	gph	gallons per hour
ATDC	after top dead center	DAC	digital to analog converter	gpm	gallons per minute
ATS	automatic transfer switch	dB	decibel	gr.	grade, gross
auto.	automatic	dB(A)	decibel (A weighted)	GRD	equipment ground
aux.	auxiliary	DC	direct current	gr. wt.	gross weight
avg.	average	DCR	direct current resistance	H x W x D	height by width by depth
AVR	automatic voltage regulator	deg., °	degree	HC	hex cap
AWG	American Wire Gauge	dept.	department	HCHT	high cylinder head temperature
AWM	appliance wiring material	DFMEA	Design Failure Mode and Effects Analysis	HD	heavy duty
bat.	battery	dia.	diameter	HET	high exhaust temp., high engine temp.
BBDC	before bottom dead center	DI/EO	dual inlet/end outlet	hex	hexagon
BC	battery charger, battery charging	DIN	Deutsches Institut fur Normung e. V. (also Deutsche Industrie Normenausschuss)	Hg	mercury (element)
BCA	battery charging alternator	DIP	dual inline package	HH	hex head
BCI	Battery Council International	DPDT	double-pole, double-throw	HHC	hex head cap
BDC	before dead center	DS	disconnect switch	HP	horsepower
BHP	brake horsepower	DVR	digital voltage regulator	hr.	hour
blk.	black (paint color), block (engine)	E, emer.	emergency (power source)	HS	heat shrink
blk. htr.	block heater	ECM	electronic control module, engine control module	hsg.	housing
BMEP	brake mean effective pressure	EDI	electronic data interchange	HVAC	heating, ventilation, and air conditioning
bps	bits per second	EFR	emergency frequency relay	HWT	high water temperature
br.	brass	e.g.	for example (<i>exempli gratia</i>)	Hz	hertz (cycles per second)
BTDC	before top dead center	EG	electronic governor	IC	integrated circuit
Btu	British thermal unit	EGSA	Electrical Generating Systems Association	ID	inside diameter, identification
Btu/min.	British thermal units per minute	EIA	Electronic Industries Association	IEC	International Electrotechnical Commission
C	Celsius, centigrade	EI/EO	end inlet/end outlet	IEEE	Institute of Electrical and Electronics Engineers
cal.	calorie	EMI	electromagnetic interference	IMS	improved motor starting
CAN	controller area network	emiss.	emission	in.	inch
CARB	California Air Resources Board	eng.	engine	in. H ₂ O	inches of water
CB	circuit breaker	EPA	Environmental Protection Agency	in. Hg	inches of mercury
cc	cubic centimeter	ES	engineering special, engineered special	in. lb.	inch pounds
CCA	cold cranking amps	ESD	electrostatic discharge	Inc.	incorporated
ccw.	counterclockwise			ind.	industrial
CEC	Canadian Electrical Code			int.	internal
cert.	certificate, certification, certified			int./ext.	internal/external
cfh	cubic feet per hour			I/O	input/output
				IP	iron pipe
				ISO	International Organization for Standardization
				J	joule
				JIS	Japanese Industry Standard

k	kilo (1000)	MTBO	mean time between overhauls	rms	root mean square
K	kelvin	mtg.	mounting	rnd.	round
kA	kiloampere	MTU	Motoren-und Turbinen-Union	ROM	read only memory
KB	kilobyte (2 ¹⁰ bytes)	MW	megawatt	rot.	rotate, rotating
KBus	Kohler communication protocol	mW	milliwatt	rpm	revolutions per minute
kg	kilogram	μF	microfarad	RS	right side
kg/cm ²	kilograms per square centimeter	N, norm.	normal (power source)	RTU	remote terminal unit
kgm	kilogram-meter	NA	not available, not applicable	RTV	room temperature vulcanization
kg/m ³	kilograms per cubic meter	nat. gas	natural gas	RW	read/write
kHz	kilohertz	NBS	National Bureau of Standards	SAE	Society of Automotive Engineers
kJ	kilojoule	NC	normally closed	scfm	standard cubic feet per minute
km	kilometer	NEC	National Electrical Code	SCR	silicon controlled rectifier
kOhm, kΩ	kilo-ohm	NEMA	National Electrical Manufacturers Association	s, sec.	second
kPa	kilopascal	NFPA	National Fire Protection Association	SI	<i>Systeme internationale d'unites</i> , International System of Units
kph	kilometers per hour	Nm	newton meter	SI/EO	side in/end out
kV	kilovolt	NO	normally open	sil.	silencer
kVA	kilovolt ampere	no., nos.	number, numbers	SN	serial number
KVAR	kilovolt ampere reactive	NPS	National Pipe, Straight	SNMP	simple network management protocol
kW	kilowatt	NPSC	National Pipe, Straight-coupling	SPDT	single-pole, double-throw
kWh	kilowatt-hour	NPT	National Standard taper pipe thread per general use	SPST	single-pole, single-throw
kWm	kilowatt mechanical	NPTF	National Pipe, Taper-Fine	spec	specification
kWth	kilowatt-thermal	NR	not required, normal relay	specs	specification(s)
L	liter	ns	nanosecond	sq.	square
LAN	local area network	OC	overcrank	sq. cm	square centimeter
L x W x H	length by width by height	OD	outside diameter	sq. in.	square inch
lb.	pound, pounds	OEM	original equipment manufacturer	SS	stainless steel
lbm/ft ³	pounds mass per cubic feet	OF	overfrequency	std.	standard
LCB	line circuit breaker	opt.	option, optional	stl.	steel
LCD	liquid crystal display	OS	oversize, overspeed	tach.	tachometer
ld. shd.	load shed	OSHA	Occupational Safety and Health Administration	TD	time delay
LED	light emitting diode	OV	overvoltage	TDC	top dead center
Lph	liters per hour	oz.	ounce	TDEC	time delay engine cooldown
Lpm	liters per minute	p., pp.	page, pages	TDEN	time delay emergency to normal
LOP	low oil pressure	PC	personal computer	TDES	time delay engine start
LP	liquefied petroleum	PCB	printed circuit board	TDNE	time delay normal to emergency
LPG	liquefied petroleum gas	pF	picofarad	TDOE	time delay off to emergency
LS	left side	PF	power factor	TDON	time delay off to normal
L _{wa}	sound power level, A weighted	ph., ∅	phase	temp.	temperature
LWL	low water level	PHC	Phillips® head Crimptite® (screw)	term.	terminal
LWT	low water temperature	PHH	Phillips® hex head (screw)	THD	total harmonic distortion
m	meter, milli (1/1000)	PHM	pan head machine (screw)	TIF	telephone influence factor
M	mega (10 ⁶ when used with SI units), male	PLC	programmable logic control	TIR	total indicator reading
m ³	cubic meter	PMG	permanent magnet generator	tol.	tolerance
m ³ /hr.	cubic meters per hour	pot	potentiometer, potential	turbo.	turbocharger
m ³ /min.	cubic meters per minute	ppm	parts per million	typ.	typical (same in multiple locations)
mA	milliampere	PROM	programmable read-only memory	UF	underfrequency
man.	manual	psi	pounds per square inch	UHF	ultrahigh frequency
max.	maximum	psig	pounds per square inch gauge	UL	Underwriter's Laboratories, Inc.
MB	megabyte (2 ²⁰ bytes)	pt.	pint	UNC	unified coarse thread (was NC)
MCCB	molded-case circuit breaker	PTC	positive temperature coefficient	UNF	unified fine thread (was NF)
MCM	one thousand circular mils	PTO	power takeoff	univ.	universal
meggar	megohmmeter	PVC	polyvinyl chloride	US	undersize, underspeed
MHz	megahertz	qt.	quart, quarts	UV	ultraviolet, undervoltage
mi.	mile	qty.	quantity	V	volt
mil	one one-thousandth of an inch	R	replacement (emergency) power source	VAC	volts alternating current
min.	minimum, minute	rad.	radiator, radius	VAR	voltampere reactive
misc.	miscellaneous	RAM	random access memory	VDC	volts direct current
MJ	megajoule	RDO	relay driver output	VFD	vacuum fluorescent display
mJ	millijoule	ref.	reference	VGA	video graphics adapter
mm	millimeter	rem.	remote	VHF	very high frequency
mOhm, mΩ	milliohm	Res/Coml	Residential/Commercial	W	watt
MOhm, MΩ	megohm	RFI	radio frequency interference	WCR	withstand and closing rating
MOV	metal oxide varistor	RH	round head	w/	with
MPa	megapascal	RHM	round head machine (screw)	w/o	without
mpg	miles per gallon	rly.	relay	wt.	weight
mph	miles per hour			xfrm	transformer
MS	military standard				
ms	millisecond				
m/sec.	meters per second				
MTBF	mean time between failure				

Notes

Notes

KOHLER[®] Power Systems

KOHLER CO. Kohler, Wisconsin 53044
Phone 920-457-4441, Fax 920-459-1646
For the nearest sales/service outlet in the
US and Canada, phone 1-800-544-2444
KOHLERPower.com

Kohler Power Systems
Asia Pacific Headquarters
7 Jurong Pier Road
Singapore 619159
Phone (65) 6264-6422, Fax (65) 6264-6455

TP-7038 3/16

© 2016 by Kohler Co. All rights reserved.