

General Maintenance Lit Kits

February 2017

Model	Kit Number	Generator				Engine		
		Installation	Operation	Wiring Diagram	Parts	Installation	Operation	Parts
KD800 60Hz	GM101562-KP	TP-5700	TP-7070	TP-7071	TP-7064	33508003101	33521029401	TP-7052
KD800 50Hz	GM101574-KP	TP-5700	TP-7070	TP-7071	TP-7064	33508003101	33521029401	TP-7053
KD900 60Hz	GM101558-KP	TP-5700	TP-7070	TP-7071	TP-7064	33508003101	33521029401	TP-7052
KD900 50Hz	GM101570-KP	TP-5700	TP-7070	TP-7071	TP-7064	33508003101	33521029401	TP-7053
KD1000 60Hz	GM101554-KP	TP-5700	TP-7070	TP-7071	TP-7064	33508003101	33521029401	TP-7052
KD1000 50Hz	GM101566-KP	TP-5700	TP-7070	TP-7071	TP-7064	33508003101	33521029401	TP-7053
KD1250 60Hz	GM101500-KP	TP-5700	TP-7070	TP-7071	TP-7066	33508003101	33521030001	TP-7056
KD1250 50Hz	GM101516-KP	TP-5700	TP-7070	TP-7071	TP-7066	33508003101	33521030001	TP-7057
KD1500 60Hz	GM101504-KP	TP-5700	TP-7070	TP-7071	TP-7066	33508003101	33521030001	TP-7056
KD1500 50Hz	GM101520-KP	TP-5700	TP-7070	TP-7071	TP-7066	33508003101	33521030001	TP-7057
KD1600 60Hz	GM101508-KP	TP-5700	TP-7070	TP-7071	TP-7066	33508003101	33521030001	TP-7056
KD1600 50Hz	GM101524-KP	TP-5700	TP-7070	TP-7071	TP-7066	33508003101	33521030001	TP-7057
KD1750 60Hz	GM101512-KP	TP-5700	TP-7070	TP-7071	TP-7066	33508003101	33521030001	TP-7056
KD1750 50Hz	GM101528-KP	TP-5700	TP-7070	TP-7071	TP-7066	33508003101	33521030001	TP-7057
KD2000 60Hz	GM101749-KP	TP-5700	TP-7070	TP-7071	TP-7067	33508003101	33521030301	TP-7058
KD2250 60Hz	GM101753-KP	TP-5700	TP-7070	TP-7071	TP-7067	33508003101	33521030301	TP-7058
KD2250 50Hz	GM101765-KP	TP-5700	TP-7070	TP-7071	TP-7067	33508003101	33521030301	TP-7058
KD2500 60Hz	GM101757-KP	TP-5700	TP-7070	TP-7071	TP-7067	33508003101	33521030301	TP-7058